BENTLEY ETC Function List(Note:For reference only)								
NOTES:								
• This function is supp	orted.							
		h depends on the actual condition of the vehicle.						
O This function is not	supported.							
▲ This function is the	new feature in	this version.						
Vehicle	Year	ETC						
4V - Bentayga	2017 - 2021	•						
ZV - Bentayga	2017 - 2021	•						
3S - Continental Series	2018 - 2021	•						
3W - Continental Series	2004 - 2018	•						
ZG - Continental Series	2018 - 2021	•						
ZA - Continental Series	2004 - 2018	•						
3S - Flying Spur	2020 - 2021	•						
3W - Flying Spur	2014 - 2019	•						
ZG - Flying Spur	2020 - 2021	•						
ZA - Flying Spur	2014 - 2019	•						
3Y - Mulsanne	2011 - 2020	•						
711 W 1	0011 0000							

ETC Function List

Electronic throttle sensor reset

2011 - 2020

ZH - Mulsanne

BENTLEY INJ Function List(Note:For reference only)								
NOTES:	NOTES:							
• This function is supp	orted.							
* This function may be	supported, whic	h depends on the actual condition of the vehicle.						
O This function is not	supported.							
▲ This function is the	new feature in	this version.						
Vehicle	Year	INJ						
4V - Bentayga	2017 - 2021	•						
ZV - Bentayga	2017 - 2021	•						
3S - Continental Series	2018 - 2021	•						
3W - Continental Series	2004 - 2018	•						
ZG - Continental Series	2018 - 2021	•						
ZA - Continental Series	2004 - 2018	•						
3S - Flying Spur	2020 - 2021	•						
3W - Flying Spur	2014 - 2019	•						
ZG - Flying Spur	2020 - 2021	•						
ZA - Flying Spur	2014 - 2019	•						
3Y - Mulsanne	2011 - 2020	•						
ZH - Mulsanne	2011 - 2020	•						
	INJ	Function List						

Injector matching

BENTLEY	OIL Function	n List(Note:For reference only)
NOTES:		
• This function is sup	ported.	
		ch depends on the actual condition of the vehicle.
O This function is not		•
▲ This function is the		this version.
Vehicle	Year	OIL
4V - Bentayga	2017 - 2021	•
ZV - Bentayga	2017 - 2021	•
3S - Continental Series		•
3W - Continental Series	2004 - 2018	•
ZG - Continental Series		•
ZA - Continental Series	2004 - 2018	•
3S - Flying Spur	2020 - 2021	•
3W - Flying Spur	2014 - 2019	•
ZG - Flying Spur	2020 - 2021	•
ZA - Flying Spur	2014 - 2019	•
3Y - Mulsanne	2011 - 2020	•
ZH - Mulsanne	2011 - 2020	•

OIL Function List

Adapting Vehicle To Fixed Interval Adapting Vehicle To Flexible Service Interval

BENTLEY SAS Function List(Note:For reference only)								
NOTES:								
• This function is supp	orted.							
* This function may be	supported, whic	h depends on the actual condition of the vehicle.						
O This function is not	supported.							
▲ This function is the	new feature in	this version.						
Vehicle	Year	SAS						
4V - Bentayga	2017 - 2021	•						
ZV - Bentayga	2017 - 2021							
3S - Continental Series	2018 - 2021	•						
3W - Continental Series	2004 - 2018	•						
ZG - Continental Series	2018 - 2021							
ZA - Continental Series	2004 - 2018	•						
3S - Flying Spur	2020 - 2021							
3W - Flying Spur	2014 - 2019							
ZG - Flying Spur	2020 - 2021	•						
ZA - Flying Spur	2014 - 2019							
3Y - Mulsanne	2011 - 2020	•						
ZH - Mulsanne	2011 - 2020	•						

SAS Function List

Steering Angle Learning

BENTLEY BMS Function List(Note:For reference only)									
DENTEET DMG Tunection List (Note: Por Telefence Only)									
NOTES:	IOTES:								
• This function is supp	orted.								
※ This function may be :	supported, whic	h depends on the actual condition of the vehicle.							
O This function is not	supported.								
▲ This function is the	new feature in	this version.							
Vehicle	Year	BMS							
4V - Bentayga	2017 - 2021	•							
ZV - Bentayga	2017 - 2021	•							
3S - Continental Series	2018 - 2021	•							
3W - Continental Series	2012 - 2018	•							
ZG - Continental Series	2018 - 2021	•							
ZA - Continental Series	ZA - Continental Series 2012 - 2018								
3Y - Mulsanne	2011 - 2020	•							
ZH - Mulsanne	2011 - 2020	•							

BMS Function List

Configure new battery parameter

BENTLEY Diagnostic Function List(Note:For reference only)

NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported.▲ This function is the new feature in this version.

Vehicle	Year
4V - Bentayga	2017 - 2021
ZV - Bentayga	2017 - 2021
3S - Continental Series	2018 - 2021
3W - Continental Series	2004 - 2018
ZG - Continental Series	2018 - 2021
ZA - Continental Series	2004 - 2018
3S - Flying Spur	2020 - 2021
3W - Flying Spur	2014 - 2019
ZG - Flying Spur	2020 - 2021
ZA - Flying Spur	2014 - 2019
3Y - Mulsanne	2011 - 2020
ZH - Mulsanne	2011 - 2020

3Y - Mulsanne	2011 - 2020									
ZH - Mulsanne						1 - 2020				
Systemlist	EcuInf o.				Actuatio n Test	Basic Setting	Adaptatio n	Securit y Login		Codin
01 Engine Control Module 1	•	•	•	•	•	•	•	•	*	*
02 Transmission Control Module	•	•	•	•	•	•	•	•	*	*
03 Brakes 1	•	•	•	•	•	•	•	•	*	*
04 Steering Angle Sender	•	•	•	•	•	•	•	•	*	*
05 Kessy	•	•	•	•	•	•	•	•	*	*
06 Seat Adjustment Passenger Side	•	•	•	•	•	•	•	•	*	*
07 Display Control Unit	•	•	•	•	•	•	•	•	*	*
08 Air Conditioning	•	•	•	•	•	•	•	•	*	*
09 Central Electrics	•	•	•	•	•	•	•	•	*	*
OB Auxiliary Air Heater	•	•	•	•	•	•	•	•	*	*
OC Rear Axle Steering 2	•	•	•	•	•	•	•	•	*	*
OD Sliding Door Left	•	•	•	•	•	•	•	•	*	*
OE Media Player Position 1	•	•	•	•	•	•	•	•	*	*
OF Radio Tuner - Digital	•	•	•	•	•	•	•	•	*	*
10 Parking Assistance 2	•	•	•	•	•	•	•	•	*	*
11 Engine Control Module 2	•	•	•	•	•	•	•	•	*	*
12 Clutch Control Unit	•	•	•	•	•	•	•	•	*	*
13 Adaptive Cruise Control	•	•	•	•	•	•	•	•	*	*
14 Wheel Dampening Electronics	•	•	•	•	•	•	•	•	*	*
15 Airbag	•	•	•	•	•	•	•	•	*	*
16 Steering Column Electronics	•	•	•	•	•	•	•	•	*	*
17 Dash Board	•	•	•	•	•	•	•	•	*	*
18 Auxiliary Parking Heater	•	•	•	•	•	•	•	•	*	*
19 Gateway	•	•	•	•	•	•	•	•	*	*
1A Fuel Cell Engine	•	•	•	•	•	•	•	•	*	*
1B Active Steering	•	•	•	•	•	•	•	•	*	*
1C Vehicle Position Detection	•	•	•	•	•	•	•	•	*	*
1D Driver Identification	•	•	•	•	•	•	•	•	*	*
1E Media Player Position 2	•	•	•	•	•	•	•	•	*	*
20 High Beam Assistance	•	•	•	•	•	•	•	•	*	*
21 Battery Energy Control Module 2	•	•	•	•	•	•	•	•	*	*
22 All Wheel Control	•	•	•	•	•	•	•	•	*	*
23 Brake Boost	•	•	•	•	•	•	•	•	*	*
25 Immobilizer	•	•	•	•	•	•	•	•	*	*

26 Electronic Roof Control	•				_		•		*	*
27 Display Control Unit Rear	÷				-				*	*
28 Climate Control Unit Rear	-	•							*	*
29 Light Control Left		•	•	•	•	•		•	*	*
2A Control Unit Wireless Charging	•	•	•						*	*
2B Steering Column Locking		•							*	*
2D Voice Amplifier		•	•	•		•	•		*	*
2E Media Player Position 3		•	•	•					*	*
30 Special Function 2		•	•	•	•			•	*	*
31 Engine Electronics Group		•		•		•	•		*	*
32 Lock Electronics	•	•	•	•	•	•	•	•	*	*
33 All OBD Systems		•	•	•	•	•	•	•	*	*
34 Ride Control System	•	•	•	•	•	•	•	•	*	*
35 Central Locking Control Module	•		•	•	•		•		*	*
36 Seat Adjustment Driver Side	•	•	•	•	•	•	•	•	*	*
37 Navigation	•	•	•	•	•	•	•	•	*	*
38 Roof Electronic Control Module	•			•	•		•	•	*	*
39 Light Control Right	•	•	•	•	•	•	•	•	*	*
3A Special Vehicle Assistant	•	•	•		•		•		*	*
3B Sensor Electronics	•	•	•	•	•		•	•	*	*
3C Lane Change Assistant	•	•	•	•	•	•	•		*	*
3D Special Function	•	•	•	•	•		•	•	*	*
3E Media Player Position 4				•					*	*
3F Dynamic Assembly Mounting	•	•	•		<u> </u>			•	*	*
40 Air Conditioning Compressor		•		•					*	*
41 Diesel Pump Electronics		•		•					*	*
42 Door Electronics Driver Side	•	•	•	•	•	•	•	•	*	*
43 Bremskraftunterstutzung	•	•	•	•	•	•	•	•	*	*
44 Steering Assistance	•	•	•	•	•	•	•	•	*	*
45 Interior Monitoring	•	•	•	•	•	•	•	•	*	*
46 Central Module Comfort System	•		•	•	•		•		*	*
47 Sound System	•	•	•	•	•	•	•	•	*	*
48 Seat Adjustment Rear Driver Side	•	•	•	•	•	•	•	•	*	*
4A Rear Light	•	•	•	•	•	•	•	•	*	*
4B Multifunction Module	•	•	•	•	•		•	•	*	*
4C Tire Pressure Monitoring 2	•	•	•	•	•	•	•		<u>**</u>	*
4D Data Transfer Car2X XXX	<u> </u>	•	•	•	•	•	•	•	*	*
4E Control Head Rear Right	•	•	•	•	•	•	•	•	<u>**</u>	*
4F Central Electrics 2	•	•	•	•	•	•	•	•	*	*
50 Seat Adjustment 3rd Row	•	•	•	•	•	•	•	•	*	*
51 Drive Motor Control Module	•	•	•	•	•	•	•	•	<u>**</u>	*
52 Door Electronics Passenger Side	•	•	•	•	•	•	•		*	*
53 Parking Brake	•	•	•	•	•	•	•	•	*	*
54 Rear Spoiler	•	•	•	•	•	•	•		*	*
55 Headlight Regulation	•	•	•	•	•	•	•	•	<u>**</u>	*
56 Radio	•	•	•		•		•		*	*
57 TV Tuner	•	•			•		•	•	*	*
58 Fuel Supply	•	•	•		•	•	•		*	*
5A Longitudinal Control	•	•		•	•			•	*	*
5B Seat Adjustment Rear Passenger Side	•	•	•		•	•	•	•	*	*
5C Lane Departure Warning System	•	•	•	•	•		•		*	*
5D Operation		•	•		•				*	*
5E Control Head Rear Left	•	•	•		•		•		*	*
5F Information Control Unit 1	-	•							*	*
or information control unit 1				_					//\	<i>^</i> ∧∖

60 Tachograph	_				•		•		*	*
61 Battery Regulation	÷	•	•					•	*	*
62 Door Electronics Rear Left	<u> </u>	•	•		•	•	•	•	*	*
63 Entry Assistance Driver Side	•	•	•	•	•	•	•	•	*	*
64 Stabilizers	•	•	•	•	•	•	•	•	*	*
65 Tire Pressure Monitoring 1	•	•	•	•	•	•	•	•	*	*
66 Seat Adjustment Rear	•	•	•	•	•	•	•	•	*	*
67 Voice Control	•	•	•	•	•	•	•	•	*	*
68 Wiper Control Unit	•	•	•	•	•	•	•	•	*	*
69 Trailer Function	•	•	•	•	•	•	•	•	*	*
6A Door Automatic Rear Driver Side	•	•	•	•	•	•	•	•	*	*
6B Aerodynamics Control Unit	•	•	•	•	•	•	•	•	*	*
6C Camera System Rear View	•	•	•	•	•	•	•	•	*	*
6D Deck Lid Control Unit	•	•	•	•	•	•	•	•	*	*
6E Display Control Roof	•	•	•	•	•	•	•	•	*	*
6F Central Module Comfort System 2	•	•	•	•	•	•	•	•	*	*
71 Battery Charger	•	•	•	•	•	•	•	•	*	*
72 Door Electronics Rear Right	•	•	•	•	•	•	•	•	*	*
73 Entry Assistance Passenger Side	•	•	•	•	•	•	•	•	*	*
74 Chassis Control	•	•	•	•	•	•	•	•	*	*
75 Telematics Communication Unit	•	•	•	•	•	•	•	•	*	*
76 Parking Assistance	•	•	•	•	•	•	•	•	*	*
77 Telephone	•	•	•	•	•	•	•	•	*	*
78 Sliding Door Right	•	•	•	•	•	•	•	•	*	*
7A Door Automatic Rear Passenger Side	•	•	•		•	•	•	•	*	*
7D Auxiliary Heater	•		•	•	•	•	•	•	*	*
7E Dash Board Display Unit	•	•	•	•	•	•	•	•	*	*
7F Information Control Unit 2	•	•	•	•	•	•	•	•	*	*
80 Battery Regulation Auxiliary									*	*
Accumulator 1				_						
81 Gear Shift Control Module	•	•	•	•	•	•	•	•	*	*
82 Head Up Display	•	•	•	•	•	•	•	•	*	*
84 Night Vision	<u> </u>	•	•	•	•	•	•	•	*	*
85 On-Board Camera	•	•	•	•	•	•	•	•	*	*
87 Lane Assist LT3	•	•	•	•	•	•	•	•	*	*
88 Multi Contour Seat Driver Side	<u> </u>	•	•	•	•	•	•	•	*	*
89 Multi Contour Seat Passenger Side	•	•	•	•	•	•	•	•	*	*
8A Multi Contour Seat Rear Driver Side	<u> </u>	•	•	•	•	•	•	•	*	*
8B Adaptive Cruise Control 2		•	•	•	•	•	•	•	*	*
8C Battery Energy Control Module	•	•	•	•		•	•	•	*	*
8D Multi Contour Seat Rear Passenger Side	•	•	•	•	•	•	•	•	*	*
8E Image Processing Electronics		•	•	•		•	•	•	*	*
8F Pretensioner Front Left		•	•	•		•	•	•	*	*
90 Pretensioner Front Right		•	•	•	•	•	•	•	*	*
91 Engine Control Module (ECM)		•	•	•	•	•	•	•	*	*
92 Transmission Electronics		•	•	•	•	•	•	•	*	*
93 Immobilizer		•	•	•	•	•	•	•	*	*
94 Airbag (SRS)	<u> </u>	•	•	•	•	•	•	•	*	*
95 Electronic Stability Program		•	•	•	•	•	•	•	*	*
96 Instrument Cluster	<u> </u>	•	•	•	•	•	•	•	*	*
97 Tachograph		•			•		•		*	*
98 Tire Pressure Monitoring		•	•	•	•	•	•		*	*
99 Electrical Ignition/starter Switch		•	•	•	•		•		*	*
9A Remote Control		•			•				*	*
9B Driver's Door Electronics					•				*	*

9C A/C Electronics	_				•		•		*	*
9D Auxiliary Heater (Fuel)	_								*	*
9E Auxiliary Heater (Electric)	_								*	*
9F Parking Heater, Water	_		•		•		•	•	*	*
AO Audio 5 Radio,	_				<u> </u>				*	*
ŕ	_						•		*	<u>*</u>
A1 Navigation A2 CD Changer	<u> </u>		•		•		•	•	*	<u>*</u>
	_		•						*	<u> </u>
A3 Telephone	_		•		•		•	•	<u>*</u>	
A5 Front Sensors Driver Assistance System A6 Microphone Control Unit	•				•		•		<u>*</u>	* *
A7 Infotainment Interface	_				•				_	
	•	<u> </u>	•						*	<u>*</u>
A8 External Communication Interface	-	•	-		•	•	•	•	* *	* *
A9 Actuator For Structure-Borne Sound	_			\vdash						
AA Wheel Brake Rear Right				•					*	*
AB Wheel Brake Rear Left	•	•	•	•	•	•	•	•	*	*
AC Reductant Control Module		•	•	•	•	•	•	•	*	*
AD Sensors Brake Systems				•	•				*	*
AE Telemetry Diagnostic Control Unit	•	•	•	•	•	•	•	•	*	*
BO Roof Display/control Head (Roof Control Head)	•			•	•	•	•	•	*	*
B1 Upper Operating Field	•	•			•				*	*
B2 Parking Aid									*	*
B3 Trailer Function	<u> </u>	•	•			•	•	•	*	*
B4 Vehicle Electrical System Control		_	_			_	_			
Module	•	•	•	•	•	•	•	•	*	*
B5 Programmable Special Module	•	•	•	•	•	•	•	•	*	*
B6 Steering Column Jacket Switch Module	•	•	•	•	•	•	•	•	*	*
B7 Access Startsystem Interface	•	•	•	•	•	•	•	•	*	*
B8 Electronic Roof Control 2	•	•	•	•	•	•	•	•	*	*
B9 Auxiliary Display Control Unit	•	•	•	•	•	•	•	•	*	*
BA Assembly Mounting	•	•	•	•	•	•	•	•	*	*
BB Door Electronics Rear Driver Side	•	•	•	•	•	•	•	•	*	*
BC Door Electronics Rear Passenger Side	•	•	•	•	•	•	•	•	*	*
BD High Voltage Battery Charge Management	•	•	•	•	•	•	•	•	*	*
BE Sliding Door Rear Left	•	•	•	•	•	•	•	•	*	*
BF Sliding Door Rear Right	•	•	•	•	•	•	•	•	*	*
CO Actuator For Exterior Noise	•	•	•	•	•	•	•	•	*	*
C1 Battery Regulation	•	•	•		•	•	•	•	*	*
C2 Transmission Control Module 2	•	•	•	•	•	•	•	•	*	*
C3 Drive Motor Control Module 3	•	•	•	•	•	•	•	•	*	*
C4 DC/DC Converter Control Module	•	•	•		•	•	•	•	*	*
C5 Thermal Management	•	•	•	•	•	•	•	•	*	*
C6 Battery Charger Control Module	•	•	•		•	•	•	•	*	*
C7 Pedestrian Protection	•	•	•	•	•	•	•	•	*	*
C8 Auxiliary Display Control Unit 2	•	•	•		•	•	•	•	*	*
C9 Rear Mirror	•	•			•	•	•	•	*	*
CA Control Module For Sunroof	•	•	•		•	•	•	•	*	*
CB Rear Axle Steering	•	•	•		•		•	•	*	*
CC Starter / Generator Control Module	•	•	•			•			*	*
CD Laser Scanner			•						*	*
CE Drive Motor Control Module 2	•	•	•		•		•	•	*	*
CF Control Unit Lane Change Assistant 2	•		•	•	-		•		*	<u> </u>
DO Front Axle Lift System		•	•		•		•		*	*
D1 Center Display	•	•	•		•		•	•	*	<u>**</u>
					•				<u>*</u>	<u>**</u>
D2 Sliding Door Left					•				*	*

D3 Sliding Door Right	•	•	•	•	•	•	•	•	*	*
D4 Roll Control System 1	•	•	•	•	•	•	•	•	*	*
D5 Roll Control System 2	•	•	•	•	•	•	•	•	*	*
D6 Light Control Left 2	•	•	•	•	•	•	•	•	*	*
D7 Light Control Right 2	•	•	•	•	•	•	•	•	*	*
D8 Projection Module in Left Matrix Headlamp	•	•	•	•	•	•	•	•	*	*
D9 Projection Module in Right Matrix Headlamp	•	•	•	•	•	•	•	•	*	*
DB Front Corner Radar 1	•	•	•	•	•	•	•	•	*	*
DC Front Corner Radar 2	•	•	•	•	•	•	•	•	*	*
DD Control Module 2 For Sunroof	•	•	•	•	•	•	•	•	*	*
DE Charger 1 Mobile Devices	•	•	•	•	•	•	•	•	*	*
DF Charger 2 Mobile Devices	•	•	•	•	•	•	•	•	*	*
EO Auxiliary Display Control Unit 1	•	•	•	•	•	•	•	•	*	*
EF Reference Control Unit	•	•	•	•	•	•	•	•	*	*

BENTLEY EPB Function List(Note:For reference only)

NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	EPB
4V - Bentayga	2017 - 2021	
ZV - Bentayga	2017 - 2021	
3S - Continental Series	2018 - 2021	
3W - Continental Series	2004 - 2018	•
ZG - Continental Series	2018 - 2021	•
ZA - Continental Series	2004 - 2018	
3S - Flying Spur	2020 - 2021	
3W - Flying Spur	2014 - 2019	•
ZG - Flying Spur	2020 - 2021	
ZA - Flying Spur	2014 - 2019	
3Y - Mulsanne	2011 - 2020	
ZH - Mulsanne	2011 - 2020	

EPB Function List

Open Rear Brake Calipers(Ready to change brake pads)

Close Rear Brake Calipers(After replacement of brake pads)

Brake Calipers Function Test

Brake Pads Thickness Input

Put the brake pads in the installation position

Checking the basic setting of parking braking

Hand brake pad running-in

Hand brake calibration