BUGATTI Diagnostic Function List(Note:For reference only)

NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	lis vers.	1011.				Year					
Chiron	2017 - 2021										
Veyron	2005 - 2016										
	EcuInf	Read	Erase	Live	Actuatio		Adaptatio	Securit	Code	Codin	
Systemlist	0.				n Test	Setting	n	y Login	II	g	
01 Engine Control Module 1	•	•	•	•	•	•	•	•	*	*	
02 Transmission Control Module	•	•	•	•	•	•	•	•	*	*	
03 Brakes 1	•	•	•	•	•	•	•	•	*	*	
04 Steering Angle Sender	•	•	•	•	•	•	•	•	*	*	
05 Kessy	•	•	•	•	•	•	•	•	*	*	
06 Seat Adjustment Passenger Side	•	•	•	•	•	•	•	•	*	*	
07 Display Control Unit	•	•	•	•	•	•	•	•	*	*	
08 Air Conditioning	•	•	•	•	•	•	•	•	*	*	
09 Central Electrics	•	•	•	•	•	•	•	•	*	**	
OB Auxiliary Air Heater	•	•	•	•	•	•	•	•	*	*	
OC Rear Axle Steering 2	•	•	•	•	•	•	•	•	*	*	
OD Sliding Door Left	•	•	•	•	•	•	•	•	*	*	
OE Media Player Position 1	•	•	•	•	•	•	•	•	*	*	
OF Radio Tuner - Digital	•	•	•	•	•	•	•	•	*	*	
10 Parking Assistance 2	•	•	•	•	•	•	•	•	*	*	
11 Engine Control Module 2	•	•	•	•	•	•	•	•	*	*	
12 Clutch Control Unit	•	•	•	•	•	•	•	•	*	*	
13 Adaptive Cruise Control	•	•	•	•	•	•	•	•	*	*	
14 Wheel Dampening Electronics	•	•	•	•	•	•	•	•	*	*	
15 Airbag	•	•	•	•	•	•	•	•	*	*	
16 Steering Column Electronics	•	•	•	•	•	•	•	•	*	*	
17 Dash Board	•	•	•	•	•	•	•	•	*	*	
18 Auxiliary Parking Heater	•	•	•	•	•	•	•	•	*	*	
19 Gateway	•	•	•	•	•	•	•	•	*	*	
1A Fuel Cell Engine	•	•	•	•	•	•	•	•	*	*	
1B Active Steering	•	•	•	•	•	•	•	•	*	*	
1C Vehicle Position Detection	•	•	•	•	•	•	•	•	*	*	
1D Driver Identification	•	•	•	•	•	•	•	•	*	*	
1E Media Player Position 2	•	•	•	•	•	•	•	•	*	*	
20 High Beam Assistance	•	•	•		•	•	•	•	*	*	
21 Battery Energy Control Module 2	•	•	•	•	•	•	•	•	*	*	
22 All Wheel Control		•	•	•	•	•	•	•	*	*	
23 Brake Boost		•	•		•		•	•	*	*	
25 Immobilizer		•	•	•	•	•	•	•	*	*	
26 Electronic Roof Control		•	•	•	•	•	•	•	*	*	
27 Display Control Unit Rear		•	•		•		•	•	*	*	
28 Climate Control Unit Rear		•	•	•	•	•	•	•	*	*	
29 Light Control Left		•	•	•	•		•	•	*	*	
2A Control Unit Wireless Charging		•	•						*	<u>*</u>	
2B Steering Column Locking		•	•	•					*	*	
2D Voice Amplifier				•	•		•		*	<u>*</u>	
2E Media Player Position 3			•	•	•				*	<u>*</u>	
30 Special Function 2		•			•		•		*	<u>*</u>	
31 Engine Electronics Group					•		•		<u>*</u>	<u> </u>	
of rustue recommes group										*	

33 All ORD Systems	32 Lock Electronics	_				•		•		 	*
24 Ride Control System		<u> </u>	_							_	
35 Central Locking Control Module	·				-						
28 Seat Adjustment Driver Side					├					_	
37 Novigation											
38 Roof Electronic Control Wodule	3	•	<u> </u>	•	•	•	•	•	•	_	
39 Light Control Right		•		•	•	•	•		•	_	
38 Sensor Electronics		•	_			•		•		_	
38 Senor Electronics		•	— <u> </u>			•	•	•	•		
30 Special Function		•			•		•		•	_	
3D Special Function		•	<u> </u>		⊢ •	•	•	•	•	_	
3E Media Player Position 4		•	•			•	•	•	•		
3F Dynamic Assembly Mounting 40 Air Conditioning Compressor 41 Diesel Pupe Electronics 42 Door Electronics Driver Side 43 Bremskraftunterstutzung 44 Steoring Assistance 45 Interior Monitoring 46 Central Module Confort System 47 Sound System 48 Seat Adjustment Rear Driver Side 48 Rear Light 48 Rear Light 48 Rear Light 49 Bultifunction Module 40 Tire Pressure Monitoring 2 40 Data Transfer Car2X XXX 41 Control Read Rear Right 42 Control Read Rear Right 43 Drive Motor Control Module 54 Door Electronics Passenger Side 55 Parking Brake 55 Reading Rake 56 Radio 57 TV Tunce 58 Fuel Supply 58 Longitudinal Control 58 Sear Adjustment Rear Passenger Side 56 Lane Departure Warning System 56 Cantrol Head Rear Left 57 Information Control Unit 1 58 Sear Adjustment System 59 Operation 50 Cand Departure Warning System 50 Operation 50 Cand Departure Warning System 50 Canden Canden Control Unit 1 50 Canden Canden Control Unit 1 50 Tachograph 51 Drive Motor Control Unit 1 52 Door Plectronics Rear Left 58 Furl Supply 59 Canden Control Unit 1 50 Tachograph 50 Canden Control Unit 1 50 Tachograph 51 Drive Motor Control Unit 1 52 Door Plectronics Rear Left 53 Furl Supply 54 Canden Control Unit 1 55 Canden Control Unit 1 56 Canden Control Unit 1 56 Canden Control Unit 1 57 TV Tunce 58 Canden Control Unit 1 58 Sear Adjustment Rear Passenger Side 59 Door Plectronics Rear Left 50 Tre Pressure Monitoring 1 50 Sear Adjustment Rear Canden Control Unit 1 56 Sear Adjustment Rear Canden Control Unit 1 56 Sear Adjustment Rear Canden Control Unit 1 58 Sear Adjustment Rear Canden Control Unit 1 59 Sear Adjustment Rear Canden Control Unit 1 50 Tachograph 50 Sear Adjustment Rear Canden Control Unit 1 50 Tachograph 51 Control Unit 1 52 Door Electronics Rear Left 53 Furl Canden Control Unit 1 54 Sear Adjustment Rear Canden Control Unit 1 58 Sear Adjustment Rear Canden Control Unit 1 59 Sear Adjustment Rear Canden Control Unit 1 50 Sear Adjustment Rear Canden Control Unit 1 50 Sear Adjustment Rear Canden Control Unit 1 50 Sear Adjustment Rear Canden Cont		•			•	•			•		
40 Air Conditioning Compressor 41 Direct Pump Electronics 42 Door Electronics Driver Side 43 Bremskraftunterstutzung 44 Steering Assistance 45 Interior Monitoring 46 Central Module Comfort System 47 Sound System 48 Seat Adjustment Raar Priver Side 48 Real Light 48 Hultifunction Module 40 Tire Pressure Monitoring 2 40 Daor Electronics Passenger Side 50 Door Electronics Passenger Side 51 Drive Motor Control Module 52 Door Electronics Passenger Side 53 Parking Brake 54 Rear Spoiler 55 Readlight Regulation 55 Readi Gaster Control 56 Seat Adjustment Raar Passenger Side 56 Seat Adjustment Raar Passenger Side 56 Lane Departure Warning System 56 Seat Adjustment Control Inti 58 Seat Adjustment Control Inti 59 Try Tuner 50 Departure Warning System 50 Seat Adjustment Control Inti 50 Tachograph 51 Drive Notor Control Inti 51 Drive Motor Control Inti 52 Departure Warning System 53 Parking Brake 54 Canne Departure Warning System 55 Seat Adjustment Control Inti 56 Seat Adjustment Control Inti 57 Try Tuner 58 Fuel Supply 58 Control Rear Left 59 Information Control Inti 50 Tachograph 51 Drive Steeparture Warning System 52 Control Rear Left 53 Door Electronics Rear Left 54 Canne Departure Warning System 55 Control Head Rear Left 56 Tart Prossure Monitoring 1 56 Seat Adjustment Rear 57 Vices Control 58 Wiper Control Unit 1 58 Wiper Control Unit 1 59 Tarty Assistance Driver Side 50 Seat Adjustment Rear 50 Tyr Control Unit 1 50 Tachograph 51 Drive Seat Adjustment Rear 52 Door Electronics Rear Left 58 Entry Assistance Driver Side 59 Seat Adjustment Rear 50 Tyr Control Unit 1 50 Tachograph 51 Drive Seat Adjustment Rear 52 Door Electronics Rear Left 53 Entry Assistance Driver Side 54 Stabilizers 55 Seat Adjustment Rear 56 Tortro Control Unit 1 50 Tachograph 51 Drive Control Unit 1 50 Tachograph 51 Drive Control Unit 1 51 Drive Control Unit 1 52 Tachograph 53 Drive Control Unit 1 54 Drive Control Unit 1 55 Drive Control Unit 1 56 Seat Adjustment Rear 57 Voice Control Unit 1 58 Wiper Control Unit 1 59 Tachograph 50 Drive Control Unit 1	·	•	•	•	•	•	•	•	•	_	
41 Diesel Pump Electronics		•	•			•	•	•	•	_	
42 Door Electronics Driver Side		•	_	•	•	•	•	_	•	_	
## Steering Assistance		•			 	•	•	•	•	_	
44 Steering Assistance 45 Interior Monitoring 46 Central Module Comfort System 47 Sound System 48 Seat Adjustment Rear Driver Side 48 Rear Light 48 Holtifunction Module 40 Data Transfer Car2X XXX 48 Control Head Rear Right 47 Countal Electrics 2 50 Seat Adjustment Ranger Side 51 Drive Motor Control Module 52 Door Electronics Passenger Side 53 Farking Brake 54 Rear Spoiler 55 Radio 57 TV Tuner 58 Fuel Supply 58 Longitudinal Control 59 Seat Adjustment Rear Passenger Side 50 Cantor Head Rear Left 50 Cantor Head Rear Left 50 Cantor Head Rear Left 51 Dirtyer Regulation 52 Door Electronics Passenger Side 53 Lanc Departure Warning System 54 Cantor Head Rear Left 55 Control Head Rear Left 56 Cantor Head Rear Left 57 Information Control Unit I 58 Event Adjustment Rear Fassenger Side 59 Control Head Rear Left 50 Control Unit I		•			 	•	•	•	•	_	
## 45 Interior Monitoring ## 46 Central Module Comfort System ## 47 Sound System ## 48 Seat Adjustment Rear Driver Side ## 48 Seat Adjustment Rear Driver Side ## 48 Maltifunction Module ## 46 Maltifunction Module ## 46 Maltifunction Module ## 46 Tire Pressure Monitoring 2 ## 49 Data Transfer Car2X XXX ## 48 Control Head Rear Right ## 67 Control Head Rear Right ## 68 Seat Adjustment 3rd Row ## 47 Control Head Rear Right ## 68 Seat Adjustment 3rd Row ## 48 Seat Rear Spoiler ## 55 Dearling Brake ## 48 Seat Seat Regulation ## 48 Seat Regulation ## 48 Seat Regulation ## 48 Seat Regulation ## 48 Seat Adjustment Rear Passenger Side ## 88 Seat Adjustment		•							•	_	
46 Central Module Comfort System 47 Sound System 48 Seat Adjustment Rear Driver Side 4A Rear Light 4B Multifunction Module 4B Multifunction Module 4C Tire Pressure Monitoring 2 4C Control Head Rear Right 4F Control Module 5D Seat Adjustment Rear Passenger Side 5D Factor Spoiler 5F Headlight Regulation 5F Control Head Rear Left 5F Lane Departure Warning System 5F Control Head Rear Left 5F Information Control Unit I 5F Information		•	•	•	•	•	•	•	•	_	
47 Sound System 48 Seat Adjustment Rear Driver Side 48 Rear Light 40		•	•	•	•	•	•	•	•	_	
48 Seat Adjustment Rear Driver Side 40 A Rear Light 40 C Tire Pressure Monitoring 2 40 Data Transfer Car2X XXX 41 Data Transfer Car2X XXX 42 Control Head Rear Right 43 C Seat Adjustment 3rd Row 54 F Central Electrics 2 50 Seat Adjustment 3rd Row 51 Drive Motor Control Module 52 Door Electronics Passenger Side 53 Parking Brake 54 Rear Spoiler 55 Headlight Regulation 56 Radio 57 TV Tuner 58 Fuel Supply 50 Lane Departure Warning System 50 Operation 55 Cantrol Head Rear Left 56 Can Departure Warning System 57 Information Control Unit 1 58 Control Head Rear Left 59 Can Departure Warning System 50 Departion 50 Can Departure Warning System 50 Departion 50 Can Departure Warning System 51 Directronics Rear Left 52 Door Electronics Rear Left 55 Information Control Unit 1 56 Can Departure Warning System 57 Information Control Unit 1 58 Control Head Rear Left 59 Can Departure Warning System 50 Departion 50 Can Departure Warning System 50 Departion 50 Can Departure Warning System 51 Directronics Rear Left 52 Door Electronics Rear Left 53 Each Adjustment Rear Passenger Side 54 Stabilizers 55 Finformation Control Unit 1 56 Seat Adjustment Rear 57 Vice Control 58 Seat Adjustment Rear 59 Control Wait Rear 50 Control Wait Rear 50 Control		•	•	•	•	•	•	•	•	_	
4A Rear Light 4B Multifunction Module 4C Tire Pressure Monitoring 2 4D Data Transfer Car2X XXX 4D Data Transfer Car2X XXX 4E Control Head Rear Right 4F Central Electrics 2 5O Seat Adjustment 3rd Row 51 Drive Motor Control Module 52 Door Electronics Passenger Side 53 Parking Brake 54 Rear Spoiler 55 Headlight Regulation 56 Radio 57 TV Tuner 58 Fuel Supply 58 Longitudinal Control 59 Seat Adjustment Rear Passenger Side 50 Seat Adjustment Rear Passenger Side 50 Lane Departure Warning System 50 Operation 50 Carchograph 51 Econtrol Head Rear Left 52 Control Head Rear Left 53 Pirive Regulation 54 Carchograph 55 Econtrol Head Rear Left 56 Seat Adjustment Rear Diver Side 57 Tru Pressure Monitoring 1 58 Supply 59 Carchograph 50 Departics Rear Left 50 Seat Adjustment Rear Diver Side 51 Econtrol Head Rear Left 52 Door Electronics Rear Left 53 Pirive Pressure Monitoring 1 54 Carchograph 55 Seat Adjustment Rear 56 Seat Adjustment Rear 57 Voice Control 58 Super Control Unit 59 Seat Adjustment Rear 50 Seat Adjustment Rear 51 Seat Rear Spoiler 52 Seat Adjustment Rear 53 Seat Rear Spoiler 54 Seat Adjustment Rear 55 Seat Rear Spoiler 56 Seat Adjustment Rear 57 Seat Rear Spoiler 58 Seat Rear Spoiler 59 Seat Rear Spoiler 50 Seat Rear Spoiler 51 Seat Rear Spoiler 52 Seat Rear Spoiler 53 Seat Rear Spoiler 54 Seat Rear Spoiler 55 Seat Rear Spoiler 56 Seat Rear Spoiler 57 Seat Rear Spoiler 58 Seat Rear Spoiler 59 Seat Rear Spoiler 50 Seat Rear Sp		•	•	•	•	•	•	•	•		
## Multifunction Module		•	•	•	•	•	•	•	•	_	
4C Tire Pressure Monitoring 2 4D Data Transfer Car2X XXX 4E Control Head Rear Right 4F Central Electrics 2 5D Seat Adjustment 3rd Row 51 Drive Motor Control Module 52 Door Electronics Passenger Side 53 Parking Brake 54 Rear Spoiler 55 Headlight Regulation 56 Radio 57 TV Tuner 58 Fuel Supply 58 Fuel Supply 59 Seat Adjustment Rear Passenger Side 50 Longitudinal Control 50 Operation 51 Doperation 52 Door Electronics Rear Left 53 Entry Assistance Driver Side 54 Stabilizers 55 Enerosupt W		•	•	•	•	•	•	•	•	_	
## 4D Data Transfer Car2X_XXX		•	•	•	•	•	•	•	•	_	
4E Control Head Rear Right 4F Central Electrics 2 5O Seat Adjustment 3rd Row 51 Drive Motor Control Module 52 Door Electronics Passenger Side 53 Parking Brake 54 Rear Spoiler 55 Headlight Regulation 56 Radio 57 TV Tuner 58 Fuel Supply 50 Lane Departure Warning System 50 Operation 50 C Lane Departure Warning System 50 Departure Warning System 51 Information Control Unit 1 52 Control Head Rear Left 53 Information Control Unit 1 54 Rear Spoiler 55 Information Control Unit 1 56 Radios 57 TV Tuner 58 Seat Adjustment Rear Passenger Side 59 Seat Adjustment Rear Passenger Side 50 Seat Adjustment Rear Passenger Side 50 Seat Adjustment Rear Left 50 Seat Adjustment Rear Left 50 Seat Adjustment Rear Left 55 Information Control Unit 1 56 Radios 57 TV Tuner 58 Seat Adjustment Rear Left 59 Seat Adjustment Rear Left 50 Seat Adjustment Rear 51 Seat Adjustment Rear 52 Seat Adjustment Rear 53 Seat Adjustment Rear 54 Seat Adjustment Rear 55 Seat Adjustment Rear 56 Seat Adjustment Rear 57 Seat Adjustment Rear 58 Seat Adjustment Rear 59 Seat Adjustment Rear 50 Seat Adjustment Rear 50 Seat Adjustment Rear 51 Seat Adjustment Rear 52 Seat Adjustment Rear 53 Seat Adjustment Rear 54 Seat Adjustment Rear 55 Seat Adjustment Rear 56 Seat Adjustment Rear		•	•	•	•	•	•	•	•	_	
## Central Electrics 2	_	•	•	•	•	•	•	•	•		
50 Seat Adjustment 3rd Row		•	•	•	•	•	•	•	•		
51 Drive Motor Control Module 52 Door Electronics Passenger Side 53 Parking Brake 54 Rear Spoiler 55 Headlight Regulation 56 Radio 57 TV Tuner 58 Fuel Supply 59 A Longitudinal Control 59 Departure Warning System 50 Departure Warning System 50 Departure Warning System 51 Control Head Rear Left 52 Technograph 53 Eath Adjustment Rear Passenger Side 54 Eather Regulation 55 E Control Head Rear Left 56 Tire Pressure Monitoring 1 56 Seat Adjustment Rear 57 Voice Control 58 Seat Adjustment Rear 59 Sear Adjustment Rear 50 Sear Adjustment Rear 51 Eather Side 52 Eather Assistance Driver Side 53 Entry Assistance Driver Side 54 Stabilizers 55 Voice Control 56 Seat Adjustment Rear 57 Voice Control 58 Seat Adjustment Rear 58 Sear Adjustment Rear 59 Sear Adjustment Rear 60 Seat Adjustment Rear 61 Seat Adjustment Rear 62 Seat Adjustment Rear 63 Seat Adjustment Rear 64 Stabilizers 65 Voice Control 66 Seat Adjustment Rear 67 Voice Control 68 Wiper Control Unit 69 Wiper Control Unit 69 Wiper Control Unit 60 Wiper Cont		•	•	•	•	•	•	•	•	_	
52 Door Electronics Passenger Side		•	•	•	•	•	•	•	•	_	
53 Parking Brake		•	•	•	•	•	•	•	•		
54 Rear Spoiler	53 Parking Brake	•	•	•	•	•	•	•	•		
55 Headlight Regulation		•	•	•	•	•	•	•	•	_	
56 Radio	55 Headlight Regulation	•	•	•	•	•	•	•	•	_	
57 TV Tuner	56 Radio	•	•	•	•	•	•	•	•	*	
58 Fuel Supply	57 TV Tuner	•	•	•	•	•	•	•	•	*	
5A Longitudinal Control	58 Fuel Supply	•	•	•	•	•	•	•	•	_	
5C Lane Departure Warning System	5A Longitudinal Control	•	•	•	•	•	•	•	•	*	*
5D Operation		•	•	•	•	•	•	•	•	*	*
5D Operation	5C Lane Departure Warning System	•	•	•	•	•	•	•	•	*	*
5E Control Head Rear Left • • • • • • • • • • * * 5F Information Control Unit 1 • • • • • • • • * 60 Tachograph • • • • • • • • • * 61 Battery Regulation • • • • • • • • * 62 Door Electronics Rear Left • • • • • • • • * 63 Entry Assistance Driver Side • • • • • • • • • * 64 Stabilizers • • • • • • • • • • * 65 Tire Pressure Monitoring 1 • • • • • • • • • • * 66 Seat Adjustment Rear • • • • • • • • • • • * 67 Voice Control • • • • • • • • • • • * 68 Wiper Control Unit • • • • • • • • • • • *		•	•	•	•	•	•	•	•	*	*
60 Tachograph 61 Battery Regulation 62 Door Electronics Rear Left 63 Entry Assistance Driver Side 64 Stabilizers 65 Tire Pressure Monitoring 1 66 Seat Adjustment Rear 67 Voice Control 68 Wiper Control Unit 68 Wiper Control Unit 68 ■ ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ●		•	•	•	•	•	•	•	•	*	
61 Battery Regulation 62 Door Electronics Rear Left 63 Entry Assistance Driver Side 64 Stabilizers 65 Tire Pressure Monitoring 1 66 Seat Adjustment Rear 67 Voice Control 68 Wiper Control Unit 68 Wiper Control Unit 68 Seat Adjustment Unit 69 Seat Adjustment Unit 60 Seat Adjustment Unit	5F Information Control Unit 1	•	•	•	•	•	•	•	•	*	*
62 Door Electronics Rear Left • • • • • • • • • • * * * * 63 Entry Assistance Driver Side • • • • • • • • • * * * * * * 64 Stabilizers • • • • • • • • • * * * * * * 65 Tire Pressure Monitoring 1 • • • • • • • • • * * * * * * 65 Seat Adjustment Rear • • • • • • • • • • • * * * * * * 67 Voice Control • • • • • • • • • • • * * * * * * 68 Wiper Control Unit • • • • • • • • • • * * * * * *	60 Tachograph	•	•	•	•	•	•	•	•	*	*
62 Door Electronics Rear Left • • • • • • • • • * * 63 Entry Assistance Driver Side • • • • • • • • • * 64 Stabilizers • • • • • • • • • * 65 Tire Pressure Monitoring 1 • • • • • • • • • * 66 Seat Adjustment Rear • • • • • • • • • * 67 Voice Control • • • • • • • • • • * 68 Wiper Control Unit • • • • • • • • • • *	61 Battery Regulation	•	•	•	•	•	•	•	•	_	
63 Entry Assistance Driver Side 64 Stabilizers 65 Tire Pressure Monitoring 1 66 Seat Adjustment Rear 67 Voice Control 68 Wiper Control Unit 68 Entry Assistance Driver Side 69		•	•	•	•	•	•	•	•		
64 Stabilizers • • • • • • • • • * * * 65 Tire Pressure Monitoring 1 • • • • • • • • * * * 66 Seat Adjustment Rear • • • • • • • • * * * 67 Voice Control • • • • • • • • * * * 68 Wiper Control Unit • • • • • • • • • * * *		•	•	•	•	•	•	•	•	_	
65 Tire Pressure Monitoring 1 • • • • • • • * * 66 Seat Adjustment Rear • • • • • • • * 67 Voice Control • • • • • • • * 68 Wiper Control Unit • • • • • • • • *	64 Stabilizers	•	•	•	•	•	•	•	•	_	
66 Seat Adjustment Rear ● ● ● ● ● ※ ※ 67 Voice Control ● ● ● ● ● ● ※ ※ 68 Wiper Control Unit ● ● ● ● ● ● ※ ※	65 Tire Pressure Monitoring 1	•	•	•	•	•	•	•	•	_	
68 Wiper Control Unit	66 Seat Adjustment Rear	•	•	•	•	•	•	•	•	_	
68 Wiper Control Unit	67 Voice Control	•	•	•	•	•	•	•	•	*	*
	68 Wiper Control Unit	•	•	•		•	•	•	•	_	
	69 Trailer Function	•	•	•	•	•	•	•	•	*	

6A Door Automatic Rear Driver Side	•								 	*
6B Aerodynamics Control Unit	-				-				<u>*</u>	*
6C Camera System Rear View		•							<u>**</u>	*
6D Deck Lid Control Unit			•		•		•		*	*
6E Display Control Roof	<u> </u>				•				*	*
6F Central Module Comfort System 2		•							*	*
71 Battery Charger	•	•	•		•	•	•		*	*
72 Door Electronics Rear Right		•	•						*	*
73 Entry Assistance Passenger Side	<u> </u>	•	•		•		•	•	*	*
74 Chassis Control		•		•			•		*	*
75 Telematics Communication Unit	•		•		•	•	•	•	*	*
76 Parking Assistance	•	•	•	•	•	•	•	•	*	*
77 Telephone	•	•	•	•	•	•	•	•	*	*
78 Sliding Door Right	•		•	•	•	•	•	•	*	*
7A Door Automatic Rear Passenger Side	•	•	•	•	•	•	•	•	*	*
7D Auxiliary Heater	•	•	•	•	•	•	•	•	*	*
7E Dash Board Display Unit	•	•	•	•	•	•	•	•	*	*
7F Information Control Unit 2	•	•	•	•	•	•	•	•	*	*
80 Battery Regulation Auxiliary										
Accumulator 1	•				•				*	*
81 Gear Shift Control Module	•	•	•	•	•	•	•	•	*	*
82 Head Up Display	•	•	•	•	•	•	•	•	*	*
84 Night Vision	•	•	•	•	•	•	•	•	*	*
85 On-Board Camera	•	•	•	•	•	•	•	•	*	*
87 Lane Assist LT3	•	•	•	•	•	•	•	•	*	*
88 Multi Contour Seat Driver Side	•	•	•	•	•	•	•	•	*	*
89 Multi Contour Seat Passenger Side	•	•	•	•	•	•	•	•	*	*
8A Multi Contour Seat Rear Driver Side	•	•	•	•	•	•	•	•	*	*
8B Adaptive Cruise Control 2	•	•	•	•	•	•	•	•	*	*
8C Battery Energy Control Module	•	•	•	•	•	•	•	•	*	*
8D Multi Contour Seat Rear Passenger Side	•	•	•		•	•	•	•	*	*
8E Image Processing Electronics	•	•	•	•	•	•	•	•	*	*
8F Pretensioner Front Left	•	•	•	•	•	•	•	•	*	*
90 Pretensioner Front Right	•	•	•	•	•	•	•	•	*	*
91 Engine Control Module (ECM)		•	•	•	•	•	•	•	*	*
92 Transmission Electronics	•	•	•		•	•	•	•	*	*
93 Immobilizer		•	•	•	•	•	•	•	*	*
94 Airbag (SRS)	•	•	•	•	•	•	•	•	*	*
95 Electronic Stability Program	•	•	•	•	•	•	•	•	*	*
96 Instrument Cluster	•	•	•	•	•	•	•	•	*	*
97 Tachograph	•	•	•	•	•	•	•	•	*	*
98 Tire Pressure Monitoring	•	•	•	•	•	•	•	•	*	*
99 Electrical Ignition/starter Switch	•	•	•	•	•	•	•	•	*	*
9A Remote Control	•	•	•	•	•	•	•	•	*	*
9B Driver's Door Electronics	•	•	•	•	•	•	•	•	*	*
9C A/C Electronics	•	•	•	•	•	•	•	•	*	*
9D Auxiliary Heater (Fuel)	•	•	•	•	•	•	•	•	*	*
9E Auxiliary Heater (Electric)	•	•	•	•	•	•	•	•	*	*
9F Parking Heater, Water	•	•	•	•	•	•	•	•	*	*
AO Audio 5 Radio,	•	•	•	•	•	•	•	•	*	*
Al Navigation	•	•	•	•	•	•	•	•	*	*
A2 CD Changer	•	•	•	•	•	•	•	•	*	*
A3 Telephone	•	•	•	•	•	•	•	•	*	*
A5 Front Sensors Driver Assistance System	•	•	•	•	•	•	•	•	*	*
A6 Microphone Control Unit	•		•		•	•	•	•	*	*

A7 Infotainment Interface	•			•	•		•	•	*	*
A8 External Communication Interface	•	•	•	•	•	•	•	•	*	*
A9 Actuator For Structure-Borne Sound	•	•	•	•	•	•	•	•	<u>**</u>	*
AA Wheel Brake Rear Right	•	•	•	•	•	•	•	•	<u>*</u>	*
AB Wheel Brake Rear Left	•	•	•	•	•	•	•	•	*	*
AC Reductant Control Module		•	•	•	•	•	•	•	<u>**</u>	*
AD Sensors Brake Systems	•	•	•	•	•	•	•	•	<u>**</u>	*
AE Telemetry Diagnostic Control Unit		•	•	•	•			•	<u>*</u>	*
BO Roof Display/control Head (Roof							_		1	
Control Head)	•	•	•		•	•	•	•	**	*
B1 Upper Operating Field	•	•	•	•	•	•	•	•	*	*
B2 Parking Aid	•	•	•	•	•	•	•	•	*	*
B3 Trailer Function	•	•	•	•	•	•	•	•	*	*
B4 Vehicle Electrical System Control									*	*
Module										
B5 Programmable Special Module	•	•	•	•	•	•	•	•	*	*
B6 Steering Column Jacket Switch Module	•	•	•	•	•	•	•	•	*	*
B7 Access Startsystem Interface	•	•	•	•	•	•	•	•	*	*
B8 Electronic Roof Control 2	•	•	•	•	•	•	•	•	*	*
B9 Auxiliary Display Control Unit	•	•	•	•	•	•	•	•	*	*
BA Assembly Mounting	•	•	•	•		•	•	•	*	*
BB Door Electronics Rear Driver Side	•	•	•	•	•	•	•	•	*	*
BC Door Electronics Rear Passenger Side	•	•	•	•		•	•	•	*	*
BD High Voltage Battery Charge Management	•	•	•	•	•	•	•	•	*	*
BE Sliding Door Rear Left	•	•	•	•	•	•	•	•	*	*
BF Sliding Door Rear Right	•	•	•	•	•	•	•	•	*	*
CO Actuator For Exterior Noise	•	•	•	•	•	•	•	•	*	*
C1 Battery Regulation	•	•	•	•	•	•	•	•	*	*
C2 Transmission Control Module 2	•	•	•	•	•	•	•	•	*	*
C3 Drive Motor Control Module 3	•	•	•	•	•	•	•	•	*	*
C4 DC/DC Converter Control Module	•	•	•	•	•	•	•	•	*	*
C5 Thermal Management	•	•	•	•		•	•	•	*	*
C6 Battery Charger Control Module	•	•	•	•	•	•	•	•	*	*
C7 Pedestrian Protection	•	•	•	•	<u> </u>	•	•	•	*	*
C8 Auxiliary Display Control Unit 2	•	•	•	•	•	•	•	•	*	*
C9 Rear Mirror	•	•	•	•	•	•	•	•	*	*
CA Control Module For Sunroof	•	•	•	•	•	•	•	•	*	*
CB Rear Axle Steering	•	•	•	•	•	•	•	•	*	*
CC Starter / Generator Control Module	•	•	•	•	•	•	•	•	*	*
CD Laser Scanner	•	•	•	•	•	•	•	•	*	*
CE Drive Motor Control Module 2	•	•	•	•	•	•	•	•	*	*
CF Control Unit Lane Change Assistant 2	•	•	•	•	•	•	•	•	*	*
DO Front Axle Lift System	•	•	•	•	•	•	•	•	*	*
D1 Center Display	•	•	•	•	•	•	•	•	*	*
D2 Sliding Door Left	•	•	•	•	•	•	•	•	*	*
D3 Sliding Door Right	•	•	•	•	•	•	•	•	*	*
D4 Roll Control System 1	•	•	•	•	•	•	•	•	*	*
D5 Roll Control System 2	•	•	•	•	•	•	•	•	*	*
D6 Light Control Left 2	•	•	•	•	•	•	•	•	*	*
D7 Light Control Right 2	•	•	•	•	•	•	•	•	*	*
D8 Projection Module in Left Matrix			•	•	•	•	•	•	 	*
Headlamp						1				
D9 Projection Module in Right Matrix Headlamp	•	•	•	•	•	•	•	•	*	*
DB Front Corner Radar 1								•	*	*
TIOHT COTHET Madal I	_	•	•						<i>*</i> *	<i>*</i> *

DC Front Corner Radar 2	•	•	•	•	•	•	•	•	*	*
DD Control Module 2 For Sunroof	•	•	•	•	•	•	•	•	*	*
DE Charger 1 Mobile Devices	•	•	•	•	•	•	•	•	*	*
DF Charger 2 Mobile Devices	•	•	•	•	•	•	•	•	*	*
EO Auxiliary Display Control Unit 1	•	•	•	•	•	•	•	•	*	*
EF Reference Control Unit	•	•	•	•	•	•	•	•	*	*

BUGATTI EPB Function List(Note:For reference only)							
OTES:							
This function is supported.							
This function may be supported, which depends on the actual condition of the vehicle.							
This function is not supported.							
This function is the new feature in this version.							
Vehicle Year EPB							
eyron 2005 - 2016 •							
EPB Function List							
pen Rear Brake Calipers(Ready to change brake pads)							
lose Rear Brake Calipers(After replacement of brake pads)							
rake Calipers Function Test							
Brake Pads Thickness Input							
Put the brake pads in the installation position							
Checking the basic setting of parking braking							
Hand brake pad running-in							

Hand brake calibration

BUGATTI ETC Function List(Note:For reference only)								
NOTES:								
• This functi	● This function is supported.							
X This functi	* This function may be supported, which depends on the actual condition of the vehicle.							
O This functi	on is not supp	orted.						
▲ This functi	on is the new	feature in this version.						
Vehicle	Year	ETC						
Chiron	2017 - 2021							
Veyron	2005 - 2016							
ETC Function List								
Electronic thr	Electronic throttle sensor reset							

BUGATTI INJ Function List(Note:For reference only)							
NOTES:							
This function is supported.							
X This function may be supported, which depends on the actual condition of the vehicle.							
O This function is not supported.							
▲ This function is the new feature in this version.							
Vehicle Year INJ							
Chiron 2017 - 2021							
Veyron 2005 - 2016							
INJ Function List							

BUGATTI OIL Function List(Note:For reference only)								
NOTES:								
• This functi	ion is supporte	d.						
※ This function	ion may be supp	orted, which depends on the actual condition of the vehicle.						
O This functi	ion is not supp	orted.						
▲ This functi	ion is the new	feature in this version.						
Vehicle	Year	OIL						
Chiron	2017 - 2021	•						
Veyron	2005 - 2016							
	OIL Function List							
Adapting Vehicle To Fixed Interval								
Adapting Vehic	cle To Flexible	Service Interval						

BUGATTI SAS Function List(Note:For reference only)								
NOTES:								
• This function i	● This function is supported.							
X This function m	* This function may be supported, which depends on the actual condition of the vehicle.							
O This function i	s not supp	orted.						
▲ This function i	s the new	feature in this version.						
Vehicle	Year	SAS						
Chiron 2017	- 2021	•						
Veyron 2005	- 2016	•						
SAS Function List								
Steering Angle Learning								

BU	GATTI BMS	Function List(Note:For reference only)						
NOTES:								
● This functi	● This function is supported.							
※ This function	X This function may be supported, which depends on the actual condition of the vehicle.							
O This functi	on is not supp	orted.						
▲ This functi	on is the new	feature in this version.						
Vehicle	Year	BMS						
Veyron	2005 - 2016	•						
BMS Function List								
Configure new battery parameter								