

VAUXHALL DWR Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Year	Model	DWR
2009	Insignia	●
2010	Astra-J	●
2010	Insignia	●
2011	Astra-J	●
2011	Insignia	●
2012	Ampera	●
2012	Astra-J	●
2012	Insignia	●
2012	Zafira-C	●
2013	Adam	●
2013	Ampera	●
2013	Astra-J	●
2013	Cascada	●
2013	Insignia	●
2013	Mokka	●
2013	Zafira-C	●
2014	Adam	●
2014	Ampera	●
2014	Astra-J	●
2014	Cascada	●
2014	Insignia	●
2014	Meriva-B	●
2014	Mokka	●
2014	Zafira-C	●
2015	Adam	●
2015	Ampera	●
2015	Astra-J	●
2015	Cascada	●
2015	Corsa-E	●
2015	Insignia	●
2015	Meriva-B	●
2015	Mokka	●
2015	Zafira-C	●
2016	Adam	●
2016	Astra-J	●
2016	Astra-K	●
2016	Cascada	●
2016	Corsa-E	●
2016	Insignia	●
2016	Karl-Viva	●
2016	Meriva-B	●
2016	Mokka	●
2016	Zafira-C	●
2017	Adam	●
2017	Ampera-E	●
2017	Astra-J	●
2017	Astra-K	●
2017	Cascada	●
2017	Corsa-E	●
2017	Insignia	●
2017	Karl-Viva	●
2017	Meriva-B	●
2017	Mokka	●

2017	Zafira-C	●
2018	Adam	●
2018	Ampera-E	●
2018	Astra-J	●
2018	Astra-K	●
2018	Cascada	●
2018	Corsa-E	●
2018	Insignia-B	●
2018	Karl-Viva	●
2018	Mokka	●
2018	Zafira-C	●
2019	Adam	●
2019	Ampera-E	●
2019	Astra-J	●
2019	Astra-K	●
2019	Cascada	●
2019	Corsa-E	●
2019	Insignia-B	●
2019	Karl-Viva	●
2019	Mokka	●
2019	Zafira-C	●
2020	Astra-J	●
2020	Astra-K	●
2020	Insignia-B	●
DWR Function List		
Clear Driver Window Learned Values		
Clear Passenger Window Learned Values		
Clear Left Rear Window Learned Values		
Clear Right Rear Window Learned Values		

VAUXHALL FPP Function List(Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Year	Model	FPP
2004	Astra-H	●
2004	Combo	●
2004	Corsa-C	●
2004	Meriva	●
2004	Vectra-C-Signum	●
2005	Astra-H	●
2005	Combo	●
2005	Corsa-C	●
2005	Meriva	●
2005	Vauxhall-Monaro	●
2005	Vectra-C-Signum	●
2005	Zafira-B	●
2006	Astra-H	●
2006	Meriva	●
2006	Vauxhall-Monaro	●
2006	Vectra-C-Signum	●
2006	Zafira-B	●
2007	Antara-CaptivaShort-Body	●
2007	Astra-H	●
2007	CaptivaLong-Body	●
2007	Corsa-D	●
2007	Meriva	●
2007	Vauxhall-VXR8	●
2007	Vectra-C-Signum	●
2007	Zafira-B	●
2008	Agila-B	●
2008	Antara-CaptivaShort-Body	●
2008	Astra-H	●
2008	CaptivaLong-Body	●
2008	Corsa-D	●
2008	Meriva	●
2008	Vauxhall-VXR8	●
2008	Vectra-C-Signum	●
2008	Zafira-B	●
2009	Agila-B	●
2009	Antara-CaptivaShort-Body	●
2009	Astra-H	●
2009	CaptivaLong-Body	●
2009	Corsa-D	●
2009	Insignia	●
2009	Meriva	●
2009	Vauxhall-VXR8	●
2009	Zafira-B	●
2010	Agila-B	●
2010	Antara-CaptivaShort-Body	●
2010	Astra-H	●
2010	Astra-J	●
2010	CaptivaLong-Body	●
2010	Corsa-D	●
2010	Insignia	●
2010	Meriva	●
2010	Meriva-B	●

2010	Zafira-B	●
2011	Agila-B	●
2011	Antara	●
2011	Antara-CaptivaShort-Body	●
2011	Astra-H	●
2011	Astra-J	●
2011	CaptivaLong-Body	●
2011	Corsa-D	●
2011	Insignia	●
2011	Meriva-B	●
2011	Vauxhall-VXR8	●
2011	Zafira-B	●
2012	Agila-B	●
2012	Ampera	●
2012	Antara	●
2012	Astra-H	●
2012	Astra-J	●
2012	Corsa-D	●
2012	Insignia	●
2012	Meriva-B	●
2012	Vauxhall-VXR8	●
2012	Zafira-B	●
2012	Zafira-C	●
2013	Adam	●
2013	Agila-B	●
2013	Ampera	●
2013	Antara	●
2013	Astra-H	●
2013	Astra-J	●
2013	Cascada	●
2013	Corsa-D	●
2013	Insignia	●
2013	Meriva-B	●
2013	Mokka	●
2013	Zafira-B	●
2013	Zafira-C	●
2014	Adam	●
2014	Agila-B	●
2014	Ampera	●
2014	Antara	●
2014	Astra-H	●
2014	Astra-J	●
2014	Cascada	●
2014	Corsa-D	●
2014	Insignia	●
2014	Meriva-B	●
2014	Mokka	●
2014	Zafira-B	●
2014	Zafira-C	●
2015	Adam	●
2015	Ampera	●
2015	Antara	●
2015	Astra-J	●
2015	Cascada	●
2015	Corsa-E	●
2015	Insignia	●
2015	Meriva-B	●
2015	Mokka	●
2015	Zafira-C	●
2016	Adam	●
2016	Antara	●

2016	Astra-J	●
2016	Astra-K	●
2016	Cascada	●
2016	Corsa-E	●
2016	Insignia	●
2016	Karl-Viva	●
2016	Meriva-B	●
2016	Mokka	●
2016	Zafira-C	●
2017	Adam	●
2017	Antara	●
2017	Astra-J	●
2017	Astra-K	●
2017	Cascada	●
2017	Corsa-E	●
2017	Insignia	●
2017	Karl-Viva	●
2017	Meriva-B	●
2017	Mokka	●
2017	Zafira-C	●
2018	Adam	●
2018	Astra-J	●
2018	Astra-K	●
2018	Cascada	●
2018	Corsa-E	●
2018	Insignia-B	●
2018	Karl-Viva	●
2018	Mokka	●
2018	Zafira-C	●
2019	Adam	●
2019	Astra-J	●
2019	Astra-K	●
2019	Cascada	●
2019	Corsa-E	●
2019	Insignia-B	●
2019	Karl-Viva	●
2019	Mokka	●
2019	Zafira-C	●
2020	Astra-J	●
2020	Astra-K	●
2020	Insignia-B	●

FPP Function List

All Cylinders Fuel Injector Correction Value Reset
Cylinder 1 Fuel Injector Correction Value Reset
Cylinder 2 Fuel Injector Correction Value Reset
Cylinder 3 Fuel Injector Correction Value Reset
Cylinder 4 Fuel Injector Correction Value Reset
Fuel Composition Reset
Fuel Consumption Correction
Fuel Pressure Regulator Fast Learn
Fuel Pressure Regulator Learn
Fuel Pump Distribution/Balance Reset
Fuel Pump Driver Control Module Configuration
Fuel Pump Trim Reset
Fuel Rail Pressure Sensor Or Fuel Rail Learn
Fuel Rail Pressure Sensor Reset
Fuel Rail Pressure Sensor or Fuel Rail Learn
Fuel Trim Reset
High Pressure Fuel Pump Learn
Replace Fuel Pump

VAUXHALL INJ Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Year	Model	INJ
2002	Combo	●
2004	Agila	●
2004	Astra-H	●
2004	Combo	●
2004	Corsa-C	●
2004	Vectra-C-Signum	●
2005	Agila	●
2005	Astra-H	●
2005	Combo	●
2005	Meriva	●
2005	Tigra-B	●
2005	Vectra-C-Signum	●
2005	Zafira-B	●
2006	Agila	●
2006	Astra-H	●
2006	Combo	●
2006	Meriva	●
2006	Tigra-B	●
2006	Vectra-C-Signum	●
2006	Zafira-B	●
2007	Agila	●
2007	Antara-CaptivaShort-Body	●
2007	Astra-H	●
2007	CaptivaLong-Body	●
2007	Combo	●
2007	Corsa-D	●
2007	Meriva	●
2007	Tigra-B	●
2007	Vectra-C-Signum	●
2007	Zafira-B	●
2008	Antara-CaptivaShort-Body	●
2008	Astra-H	●
2008	CaptivaLong-Body	●
2008	Corsa-D	●
2008	Meriva	●
2008	Tigra-B	●
2008	Vectra-C-Signum	●
2008	Zafira-B	●
2009	Antara-CaptivaShort-Body	●
2009	Astra-H	●
2009	CaptivaLong-Body	●
2009	Corsa-D	●
2009	Meriva	●
2009	Tigra-B	●
2009	Zafira-B	●
2010	Antara-CaptivaShort-Body	●
2010	Astra-H	●
2010	CaptivaLong-Body	●
2010	Corsa-D	●
2010	Meriva	●
2010	Meriva-B	●
2010	Zafira-B	●
2011	Antara	●
2011	Antara-CaptivaShort-Body	●
2011	Astra-H	●
2011	CaptivaLong-Body	●

2011	Corsa-D	●
2011	Meriva-B	●
2011	Zafira-B	●
2012	Antara	●
2012	Astra-H	●
2012	Corsa-D	●
2012	Meriva-B	●
2012	Zafira-B	●
2013	Antara	●
2013	Astra-H	●
2013	Astra-J	●
2013	Cascada	●
2013	Corsa-D	●
2013	Insignia	●
2013	Meriva-B	●
2013	Zafira-B	●
2013	Zafira-C	●
2014	Antara	●
2014	Astra-H	●
2014	Astra-J	●
2014	Cascada	●
2014	Corsa-D	●
2014	Insignia	●
2014	Meriva-B	●
2014	Zafira-B	●
2014	Zafira-C	●
2015	Antara	●
2015	Astra-J	●
2015	Cascada	●
2015	Insignia	●
2015	Meriva-B	●
2015	Zafira-C	●
2016	Astra-J	●
2016	Astra-K	●
2016	Zafira-C	●
2017	Astra-J	●
2017	Astra-K	●
2017	Crossland-X	●
2018	Astra-J	●
2018	Astra-K	●
2018	Crossland-X	●
2018	Grandland-X	●
2018	Mokka	●
2019	Astra-K	●
2019	Crossland-X	●
2019	Grandland-X	●
2019	Mokka	●
2019	Combo-E	●
2020	Crossland-X	●
2020	Grandland-X	●

INJ Function List

Cylinder 1 Injector
Cylinder 1 Injector Flow Identifier
Cylinder 2 Injector
Cylinder 2 Injector Flow Identifier
Cylinder 3 Injector
Cylinder 3 Injector Flow Identifier
Cylinder 4 Injector
Cylinder 4 Injector Flow Identifier
Injector Flow Rate Programming
Replace Injector

VAUXHALL MIS Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Year	Model	MIS
2009	Insignia	●
2010	Astra-J	●
2010	Insignia	●
2011	Antara	●
2011	Astra-J	●
2011	Insignia	●
2012	Ampera	●
2012	Antara	●
2012	Astra-J	●
2012	Combo-D	●
2012	Insignia	●
2012	Zafira-C	●
2013	Adam	●
2013	Ampera	●
2013	Antara	●
2013	Astra-J	●
2013	Cascada	●
2013	Combo-D	●
2013	Insignia	●
2013	Mokka	●
2013	Zafira-C	●
2014	Adam	●
2014	Ampera	●
2014	Antara	●
2014	Astra-J	●
2014	Cascada	●
2014	Combo-D	●
2014	Insignia	●
2014	Meriva-B	●
2014	Mokka	●
2014	Zafira-C	●
2015	Adam	●
2015	Ampera	●
2015	Antara	●
2015	Astra-J	●
2015	Cascada	●
2015	Combo-D	●
2015	Corsa-E	●
2015	Insignia	●
2015	Meriva-B	●
2015	Mokka	●
2015	Movano-B	●
2015	Vivaro-B	●
2015	Zafira-C	●
2016	Adam	●
2016	Antara	●
2016	Astra-J	●
2016	Astra-K	●
2016	Cascada	●
2016	Combo-D	●
2016	Corsa-E	●
2016	Insignia	●
2016	Karl-Viva	●

2016	Meriva-B	●
2016	Mokka	●
2016	Movano-B	●
2016	Vivaro-B	●
2016	Zafira-C	●
2017	Adam	●
2017	Ampera-E	●
2017	Antara	●
2017	Astra-J	●
2017	Astra-K	●
2017	Cascada	●
2017	Combo-D	●
2017	Corsa-E	●
2017	Crossland-X	●
2017	Insignia	●
2017	Karl-Viva	●
2017	Meriva-B	●
2017	Mokka	●
2017	Movano-B	●
2017	Vivaro-B	●
2017	Zafira-C	●
2018	Adam	●
2018	Ampera-E	●
2018	Astra-J	●
2018	Astra-K	●
2018	Cascada	●
2018	Combo-D	●
2018	Corsa-E	●
2018	Crossland-X	●
2018	Grandland-X	●
2018	Insignia-B	●
2018	Karl-Viva	●
2018	Mokka	●
2018	Movano-B	●
2018	Vivaro-B	●
2018	Zafira-C	●
2019	Adam	●
2019	Ampera-E	●
2019	Astra-J	●
2019	Astra-K	●
2019	Cascada	●
2019	Corsa-E	●
2019	Crossland-X	●
2019	Grandland-X	●
2019	Insignia-B	●
2019	Karl-Viva	●
2019	Mokka	●
2019	Movano-B	●
2019	Combo-E	●
2019	Vivaro-B	●
2019	Zafira-C	●
2020	Astra-J	●
2020	Astra-K	●
2020	Crossland-X	●
2020	Grandland-X	●
2020	Insignia-B	●
2020	Movano-B	●
2020	Combo-E	●

MIS Function List

AWD Disabled-by-Malfunction Counter Reset

Adjustable Pedals Softstops Learn
All Cameras Alignment Learn
Ambient Air Temperature Calculation Reset
Assembly Plant Mode
BARO Sensor Reset
Brake Pedal Travel Sensor Learn
Brake Pressure Sensor Reset
Brake System Plunger Motor Position Sensor Learn
Brake System Plunger Pressure Rise Starting Point Learn
Calculated Fuel Economy Setup
Catalyst Reset
Clear Disable History Data
Clutch Pedal Position Learn
Control Module Reset
Crankshaft Position Reluctor Ring Learn
Cylinder Deactivation Exhaust Flow Control Valve Learn
DC Charging Disabled Reset
Distance Sensing Cruise Control Module
EHU24 Audio
EHU24 General No AuxIn
EHU5 Audio
Engine Coolant Overtemperature Warning Reset
Engine Run-in Performance Limitation
Erase All Key Fobs
Erase Valet Mode Code
Erase/Program All Key Fobs
Excessive Clutch Slip Data Reset
Exhaust Flow Control Valve Learn
Exhaust Gas Temperature Sensor Reset
Front Camera Alignment Learn
Frontview Camera Learn
Fuel Economy Reset
Gear Position Sensor Learn
Generator Overtemperature Counter Reset
H02S Heater Learn
H02S Heater Resistance Learned Values Reset
HVAC Afterblow Configuration
Intake System Learned Values Reset
Key Fob 1
Key Fob 2
Key Fob 3
Key Fob 4
Key Fob 5
Key Fob 6
Key Fob 7
Key Fob 8
Knock Counter Reset
Left Camera Alignment Learn
Liftgate Disable History Reset
Long Range Radar Sensor Module Learn
Module Setup
N0x Adsorber Catalyst Data Reset
Neutral Position Sensor Learn
Next Available Slot
Overboost Counter Reset
Parking Heater Failed Start Counter Reset
Parking Heater Overheat Counter Reset
Passenger Compartment Heater Coolant Control Solenoid Valve Learn
Preferred Roaming List Update
Read LIN Bus Device ID Information

Rear Camera Alignment Learn
Remote Vehicle Start Disable History Reset
Reset Teen Driver Key PIN
Right Camera Alignment Learn
SIM Card Data
Service Interval Reset
Setup SDM Part Number in BCM
Showroom Mode
Starter Activations Reset
Temperature Code Index
Trailer Stability Control
Transmission Adaptive Pressure Reset
Transmission Adaptive Torque Reset
Transmission Adaptive Values Learn
Turbocharger Wastegate Learn
Vehicle Direction Camera Learn
Vehicle Health Data Upload
Vehicle Inclination Sensor

VAUXHALL EPB Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Year	Model	EPB
2007	Vauxhall-VXR8	●
2008	Vauxhall-VXR8	●
2009	Insignia	●
2009	Vauxhall-VXR8	●
2010	Astra-J	●
2010	Insignia	●
2010	Meriva-B	●
2011	Antara	●
2011	Antara-CaptivaShort-Body	●
2011	Astra-J	●
2011	Insignia	●
2011	Meriva-B	●
2011	Vauxhall-VXR8	●
2012	Ampera	●
2012	Antara	●
2012	Astra-J	●
2012	Insignia	●
2012	Meriva-B	●
2012	Vauxhall-VXR8	●
2012	Zafira-C	●
2013	Ampera	●
2013	Antara	●
2013	Astra-J	●
2013	Cascada	●
2013	Insignia	●
2013	Meriva-B	●
2013	Zafira-C	●
2014	Ampera	●
2014	Antara	●
2014	Astra-J	●
2014	Cascada	●
2014	Insignia	●
2014	Meriva-B	●
2014	Zafira-C	●
2015	Ampera	●
2015	Antara	●
2015	Astra-J	●
2015	Cascada	●
2015	Insignia	●
2015	Meriva-B	●
2015	Zafira-C	●
2016	Antara	●
2016	Astra-J	●
2016	Astra-K	●
2016	Cascada	●
2016	Insignia	●
2016	Meriva-B	●
2016	Zafira-C	●
2017	Antara	●
2017	Astra-J	●
2017	Astra-K	●

2017	Cascada	●
2017	Crossland-X	●
2017	Insignia	●
2017	Meriva-B	●
2017	Zafira-C	●
2018	Astra-J	●
2018	Astra-K	●
2018	Cascada	●
2018	Crossland-X	●
2018	Grandland-X	●
2018	Insignia-B	●
2018	Zafira-C	●
2019	Astra-J	●
2019	Astra-K	●
2019	Cascada	●
2019	Crossland-X	●
2019	Grandland-X	●
2019	Insignia-B	●
2019	Combo-E	●
2019	Zafira-C	●
2020	Astra-J	●
2020	Astra-K	●
2020	Crossland-X	●
2020	Grandland-X	●
2020	Insignia-B	●
2020	Combo-E	●
EPB Function List		
Brake Pedal Position Sensor Learn		
Park Brake Calibration		
Park Brake Cable Replacement Procedure		
Left Park Brake Actuator Reset		
Right Park Brake Actuator Reset		
Left Rear Brake Caliper Piston Reset		
Right Rear Brake Caliper Piston Reset		
Automatic Park Brake Apply Function		

VAUXHALL ETC Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Year	Model	ETC
2005	Vauxhall-Monaro	●
2006	Vauxhall-Monaro	●
2007	Antara-CaptivaShort-Body	●
2007	Vauxhall-VXR8	●
2008	Antara-CaptivaShort-Body	●
2008	Vauxhall-VXR8	●
2009	Antara-CaptivaShort-Body	●
2009	Insignia	●
2009	Vauxhall-VXR8	●
2010	Antara-CaptivaShort-Body	●
2010	Astra-J	●
2010	Corsa-D	●
2010	Insignia	●
2010	Meriva-B	●
2011	Antara-CaptivaShort-Body	●
2011	Astra-J	●
2011	Corsa-D	●
2011	Insignia	●
2011	Meriva-B	●
2011	Vauxhall-VXR8	●
2012	Astra-J	●
2012	Corsa-D	●
2012	Insignia	●
2012	Meriva-B	●
2012	Vauxhall-VXR8	●
2012	Zafira-C	●
2013	Adam	●
2013	Astra-J	●
2013	Cascada	●
2013	Corsa-D	●
2013	Insignia	●
2013	Meriva-B	●
2013	Mokka	●
2013	Zafira-C	●
2014	Adam	●
2014	Astra-J	●
2014	Cascada	●
2014	Corsa-D	●
2014	Insignia	●
2014	Meriva-B	●
2014	Mokka	●
2014	Zafira-C	●
2015	Adam	●
2015	Astra-J	●
2015	Cascada	●
2015	Corsa-E	●
2015	Insignia	●
2015	Meriva-B	●
2015	Mokka	●
2015	Zafira-C	●

2016	Adam	●
2016	Astra-J	●
2016	Astra-K	●
2016	Cascada	●
2016	Corsa-E	●
2016	Insignia	●
2016	Karl-Viva	●
2016	Meriva-B	●
2016	Mokka	●
2016	Zafira-C	●
2017	Adam	●
2017	Astra-J	●
2017	Astra-K	●
2017	Cascada	●
2017	Corsa-E	●
2017	Crossland-X	●
2017	Insignia	●
2017	Karl-Viva	●
2017	Meriva-B	●
2017	Mokka	●
2017	Zafira-C	●
2018	Adam	●
2018	Astra-J	●
2018	Astra-K	●
2018	Cascada	●
2018	Corsa-E	●
2018	Crossland-X	●
2018	Grandland-X	●
2018	Karl-Viva	●
2018	Mokka	●
2018	Zafira-C	●
2019	Adam	●
2019	Astra-J	●
2019	Astra-K	●
2019	Cascada	●
2019	Corsa-E	●
2019	Crossland-X	●
2019	Grandland-X	●
2019	Insignia-B	●
2019	Karl-Viva	●
2019	Mokka	●
2019	Zafira-C	●
2020	Astra-J	●
2020	Astra-K	●
2020	Crossland-X	●
2020	Grandland-X	●
2020	Insignia-B	●

ETC Function List

Read Throttle Again
Throttle Body Idle Air Flow Compensation Reset
Replace Throttle Actuator
Throttle Sweep
Throttle Actuator Reset
Throttle Position
Throttle Position Learn

VAUXHALL IDL Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Year	Model	IDL
2002	Vectra-C-Signum	●
2003	Astra-G	●
2003	Vectra-C-Signum	●
2004	Astra-G	●
2004	Astra-H	●
2004	Vectra-C-Signum	●
2005	Astra-G	●
2005	Astra-H	●
2005	Vectra-C-Signum	●
2005	Zafira-B	●
2006	Astra-G	●
2006	Astra-H	●
2006	Meriva	●
2006	Vectra-C-Signum	●
2006	Zafira-B	●
2007	Antara-CaptivaShort-Body	●
2007	Astra-G	●
2007	Astra-H	●
2007	CaptivaLong-Body	●
2007	Corsa-D	●
2007	Meriva	●
2007	Vectra-C-Signum	●
2007	Zafira-B	●
2008	Antara-CaptivaShort-Body	●
2008	Astra-G	●
2008	Astra-H	●
2008	CaptivaLong-Body	●
2008	Corsa-D	●
2008	Meriva	●
2008	Vectra-C-Signum	●
2008	Zafira-B	●
2009	Antara-CaptivaShort-Body	●
2009	Astra-G	●
2009	Astra-H	●
2009	CaptivaLong-Body	●
2009	Corsa-D	●
2009	Insignia	●
2009	Meriva	●
2009	Zafira-B	●
2010	Antara-CaptivaShort-Body	●
2010	Astra-G	●
2010	Astra-H	●
2010	Astra-J	●
2010	CaptivaLong-Body	●
2010	Corsa-D	●
2010	Insignia	●
2010	Meriva	●
2010	Meriva-B	●
2010	Zafira-B	●
2011	Antara	●
2011	Antara-CaptivaShort-Body	●
2011	Astra-G	●
2011	Astra-H	●
2011	Astra-J	●
2011	CaptivaLong-Body	●
2011	Corsa-D	●

2011	Insignia	●
2011	Meriva-B	●
2011	Zafira-B	●
2012	Ampera	●
2012	Antara	●
2012	Astra-H	●
2012	Astra-J	●
2012	Corsa-D	●
2012	Insignia	●
2012	Meriva-B	●
2012	Zafira-B	●
2013	Ampera	●
2013	Antara	●
2013	Astra-H	●
2013	Astra-J	●
2013	Cascada	●
2013	Corsa-D	●
2013	Insignia	●
2013	Meriva-B	●
2013	Zafira-B	●
2013	Zafira-C	●
2014	Ampera	●
2014	Antara	●
2014	Astra-H	●
2014	Astra-J	●
2014	Cascada	●
2014	Corsa-D	●
2014	Insignia	●
2014	Zafira-B	●
2014	Zafira-C	●
2015	Adam	●
2015	Ampera	●
2015	Antara	●
2015	Astra-J	●
2015	Cascada	●
2015	Corsa-E	●
2015	Insignia	●
2015	Zafira-C	●
2016	Adam	●
2016	Astra-J	●
2016	Astra-K	●
2016	Cascada	●
2016	Corsa-E	●
2016	Insignia	●
2016	Zafira-C	●
2017	Adam	●
2017	Astra-J	●
2017	Astra-K	●
2017	Cascada	●
2017	Corsa-E	●
2017	Insignia	●
2017	Mokka	●
2017	Zafira-C	●
2018	Adam	●
2018	Astra-J	●
2018	Astra-K	●
2018	Cascada	●
2018	Corsa-E	●
2018	Insignia-B	●
2018	Mokka	●
2018	Zafira-C	●
2019	Adam	●
2019	Astra-K	●

2019	Corsa-E	●
2020	Astra-K	●
IDL Function List		
Program Idle Speed		
Idle Learn		
Idle Speed Adjustment		
Throttle Body Idle Air Flow Compensation Reset		

VAUXHALL LAP Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Year	Model	LAP
2009	Insignia	●
2010	Astra-J	●
2010	Insignia	●
2011	Antara	●
2011	Astra-J	●
2011	Insignia	●
2012	Antara	●
2012	Astra-J	●
2012	Insignia	●
2012	Zafira-C	●
2013	Antara	●
2013	Astra-J	●
2013	Cascada	●
2013	Insignia	●
2013	Mokka	●
2013	Zafira-C	●
2014	Antara	●
2014	Astra-J	●
2014	Cascada	●
2014	Insignia	●
2014	Mokka	●
2014	Zafira-C	●
2015	Antara	●
2015	Astra-J	●
2015	Cascada	●
2015	Insignia	●
2015	Mokka	●
2015	Zafira-C	●
2016	Antara	●
2016	Astra-J	●
2016	Astra-K	●
2016	Cascada	●
2016	Insignia	●
2016	Mokka	●
2016	Zafira-C	●
2017	Antara	●
2017	Astra-J	●
2017	Astra-K	●
2017	Cascada	●
2017	Insignia	●
2017	Mokka	●
2017	Zafira-C	●
2018	Astra-J	●
2018	Astra-K	●
2018	Cascada	●
2018	Insignia-B	●
2018	Mokka	●
2018	Zafira-C	●
2019	Astra-J	●
2019	Astra-K	●
2019	Cascada	●
2019	Insignia-B	●
2019	Mokka	●

2019	Zafira-C	●
2020	Astra-J	●
2020	Astra-K	●
2020	Insignia-B	●
LAP Function List		
Headlamp Leveling Sensor Learn		

VAUXHALL OIL Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Year	Model	OIL
2002	Vectra-C-Signum	●
2003	Vectra-C-Signum	●
2004	Astra-H	●
2004	Vectra-C-Signum	●
2005	Astra-H	●
2005	Vauxhall-Monaro	●
2005	Vectra-C-Signum	●
2005	Zafira-B	●
2006	Astra-H	●
2006	Vauxhall-Monaro	●
2006	Vectra-C-Signum	●
2006	Zafira-B	●
2007	Antara-CaptivaShort-Body	●
2007	Astra-H	●
2007	Corsa-D	●
2007	Vauxhall-VXR8	●
2007	Vectra-C-Signum	●
2007	Zafira-B	●
2008	Agila-B	●
2008	Antara-CaptivaShort-Body	●
2008	Astra-H	●
2008	Corsa-D	●
2008	Vauxhall-VXR8	●
2008	Vectra-C-Signum	●
2008	Zafira-B	●
2009	Agila-B	●
2009	Antara-CaptivaShort-Body	●
2009	Astra-H	●
2009	Corsa-D	●
2009	Insignia	●
2009	Vauxhall-VXR8	●
2009	Zafira-B	●
2010	Agila-B	●
2010	Antara-CaptivaShort-Body	●
2010	Astra-H	●
2010	Astra-J	●
2010	Corsa-D	●
2010	Insignia	●
2010	Meriva-B	●
2010	Zafira-B	●
2011	Agila-B	●
2011	Antara	●
2011	Antara-CaptivaShort-Body	●
2011	Astra-H	●
2011	Astra-J	●
2011	Corsa-D	●
2011	Insignia	●
2011	Meriva-B	●
2011	Vauxhall-VXR8	●
2011	Zafira-B	●
2012	Agila-B	●
2012	Ampera	●
2012	Antara	●
2012	Astra-H	●

2012	Astra-J	●
2012	Corsa-D	●
2012	Insignia	●
2012	Meriva-B	●
2012	Vauxhall-VXR8	●
2012	Zafira-B	●
2012	Zafira-C	●
2013	Adam	●
2013	Ampera	●
2013	Antara	●
2013	Astra-H	●
2013	Astra-J	●
2013	Cascada	●
2013	Corsa-D	●
2013	Insignia	●
2013	Meriva-B	●
2013	Mokka	●
2013	Zafira-B	●
2013	Zafira-C	●
2014	Adam	●
2014	Ampera	●
2014	Antara	●
2014	Astra-H	●
2014	Astra-J	●
2014	Cascada	●
2014	Corsa-D	●
2014	Insignia	●
2014	Meriva-B	●
2014	Mokka	●
2014	Zafira-B	●
2014	Zafira-C	●
2015	Adam	●
2015	Ampera	●
2015	Antara	●
2015	Astra-J	●
2015	Cascada	●
2015	Corsa-E	●
2015	Insignia	●
2015	Meriva-B	●
2015	Mokka	●
2015	Zafira-C	●
2016	Adam	●
2016	Astra-J	●
2016	Astra-K	●
2016	Cascada	●
2016	Corsa-E	●
2016	Insignia	●
2016	Karl-Viva	●
2016	Meriva-B	●
2016	Mokka	●
2016	Zafira-C	●
2017	Adam	●
2017	Astra-J	●
2017	Astra-K	●
2017	Cascada	●
2017	Corsa-E	●
2017	Insignia	●
2017	Karl-Viva	●
2017	Meriva-B	●

2017	Mokka	●
2017	Zafira-C	●
2018	Adam	●
2018	Astra-J	●
2018	Astra-K	●
2018	Cascada	●
2018	Corsa-E	●
2018	Grandland-X	●
2018	Insignia-B	●
2018	Karl-Viva	●
2018	Mokka	●
2018	Zafira-C	●
2019	Adam	●
2019	Astra-J	●
2019	Astra-K	●
2019	Cascada	●
2019	Corsa-E	●
2019	Grandland-X	●
2019	Insignia-B	●
2019	Karl-Viva	●
2019	Mokka	●
2019	Zafira-C	●
2020	Astra-J	●
2020	Astra-K	●
2020	Grandland-X	●
2020	Insignia-B	●
OIL Function List		
Reset Service Interval		
Engine Oil Life Reset		

VAUXHALL SAS Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Year	Model	SAS
2002	Vectra-C-Signum	●
2003	Vectra-C-Signum	●
2004	Astra-H	●
2004	Vectra-C-Signum	●
2005	Astra-H	●
2005	Vauxhall-Monaro	●
2005	Vectra-C-Signum	●
2005	Zafira-B	●
2006	Astra-H	●
2006	Vauxhall-Monaro	●
2006	Vectra-C-Signum	●
2006	Zafira-B	●
2007	Antara-CaptivaShort-Body	●
2007	Astra-H	●
2007	CaptivaLong-Body	●
2007	Corsa-D	●
2007	Vauxhall-VXR8	●
2007	Vectra-C-Signum	●
2007	Zafira-B	●
2008	Agila-B	●
2008	Antara-CaptivaShort-Body	●
2008	Astra-H	●
2008	CaptivaLong-Body	●
2008	Corsa-D	●
2008	Vauxhall-VXR8	●
2008	Vectra-C-Signum	●
2008	Zafira-B	●
2009	Agila-B	●
2009	Antara-CaptivaShort-Body	●
2009	Astra-H	●
2009	CaptivaLong-Body	●
2009	Corsa-D	●
2009	Insignia	●
2009	Vauxhall-VXR8	●
2009	Zafira-B	●
2010	Agila-B	●
2010	Antara-CaptivaShort-Body	●
2010	Astra-H	●
2010	Astra-J	●
2010	CaptivaLong-Body	●
2010	Corsa-D	●
2010	Insignia	●
2010	Meriva-B	●
2010	Zafira-B	●
2011	Agila-B	●
2011	Antara	●
2011	Antara-CaptivaShort-Body	●
2011	Astra-H	●
2011	Astra-J	●
2011	CaptivaLong-Body	●

2011	Corsa-D	●
2011	Insignia	●
2011	Meriva-B	●
2011	Vauxhall-VXR8	●
2011	Zafira-B	●
2012	Agila-B	●
2012	Ampera	●
2012	Antara	●
2012	Astra-H	●
2012	Astra-J	●
2012	Corsa-D	●
2012	Insignia	●
2012	Meriva-B	●
2012	Vauxhall-VXR8	●
2012	Zafira-B	●
2012	Zafira-C	●
2013	Adam	●
2013	Agila-B	●
2013	Ampera	●
2013	Antara	●
2013	Astra-H	●
2013	Astra-J	●
2013	Cascada	●
2013	Corsa-D	●
2013	Insignia	●
2013	Meriva-B	●
2013	Mokka	●
2013	Zafira-B	●
2013	Zafira-C	●
2014	Adam	●
2014	Agila-B	●
2014	Ampera	●
2014	Antara	●
2014	Astra-H	●
2014	Astra-J	●
2014	Cascada	●
2014	Corsa-D	●
2014	Insignia	●
2014	Meriva-B	●
2014	Mokka	●
2014	Zafira-B	●
2014	Zafira-C	●
2015	Adam	●
2015	Ampera	●
2015	Antara	●
2015	Astra-J	●
2015	Cascada	●
2015	Corsa-E	●
2015	Insignia	●
2015	Meriva-B	●
2015	Mokka	●
2015	Movano-B	●
2015	Vivaro-B	●
2015	Zafira-C	●
2016	Adam	●
2016	Antara	●

2016	Astra-J	●
2016	Astra-K	●
2016	Cascada	●
2016	Corsa-E	●
2016	Insignia	●
2016	Karl-Viva	●
2016	Meriva-B	●
2016	Mokka	●
2016	Movano-B	●
2016	Vivaro-B	●
2016	Zafira-C	●
2017	Adam	●
2017	Ampera-E	●
2017	Antara	●
2017	Astra-J	●
2017	Astra-K	●
2017	Cascada	●
2017	Corsa-E	●
2017	Crossland-X	●
2017	Insignia	●
2017	Karl-Viva	●
2017	Meriva-B	●
2017	Mokka	●
2017	Movano-B	●
2017	Vivaro-B	●
2017	Zafira-C	●
2018	Adam	●
2018	Ampera-E	●
2018	Astra-J	●
2018	Astra-K	●
2018	Cascada	●
2018	Corsa-E	●
2018	Crossland-X	●
2018	Grandland-X	●
2018	Insignia-B	●
2018	Karl-Viva	●
2018	Mokka	●
2018	Movano-B	●
2018	Vivaro-B	●
2018	Zafira-C	●
2019	Adam	●
2019	Ampera-E	●
2019	Astra-J	●
2019	Astra-K	●
2019	Cascada	●
2019	Corsa-E	●
2019	Crossland-X	●
2019	Grandland-X	●
2019	Insignia-B	●
2019	Karl-Viva	●
2019	Mokka	●
2019	Movano-B	●
2019	Combo-E	●
2019	Vivaro-B	●
2019	Zafira-C	●
2020	Astra-J	●
2020	Astra-K	●
2020	Crossland-X	●

2020	Grandland-X	●
2020	Insignia-B	●
2020	Movano-B	●
2020	Combo-E	●
SAS Function List		
Steering Angle Sensor Calibration		
Read Crankshaft Angle Sensor Error		
Program PowerSteering Characteristic		
Steering Wheel Angle Sensor Reset		
Steering Wheel Angle Sensor Learn		
Yaw Rate Sensor Learn		
Steering Wheel Angle Sensor Centering		
Lateral Acceleration Sensor Learn		
Longitudinal Acceleration Sensor Learn		
Lateral Acceleration Sensor Reset		
Longitudinal Acceleration Sensor Reset		

VAUXHALL TPM Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Year	Model	TPM
2002	Vectra-C-Signum	●
2003	Vectra-C-Signum	●
2004	Astra-H	●
2004	Vectra-C-Signum	●
2005	Astra-H	●
2005	Vectra-C-Signum	●
2005	Zafira-B	●
2006	Astra-H	●
2006	Vectra-C-Signum	●
2006	Zafira-B	●
2007	Antara-CaptivaShort-Body	●
2007	Astra-H	●
2007	CaptivaLong-Body	●
2007	Corsa-D	●
2007	Vectra-C-Signum	●
2007	Zafira-B	●
2008	Antara-CaptivaShort-Body	●
2008	Astra-H	●
2008	CaptivaLong-Body	●
2008	Corsa-D	●
2008	Vectra-C-Signum	●
2008	Zafira-B	●
2009	Antara-CaptivaShort-Body	●
2009	Astra-H	●
2009	CaptivaLong-Body	●
2009	Corsa-D	●
2009	Insignia	●
2009	Zafira-B	●
2010	Antara-CaptivaShort-Body	●
2010	Astra-H	●
2010	Astra-J	●
2010	CaptivaLong-Body	●
2010	Corsa-D	●
2010	Insignia	●
2010	Zafira-B	●
2011	Antara	●
2011	Antara-CaptivaShort-Body	●
2011	Astra-H	●
2011	Astra-J	●
2011	CaptivaLong-Body	●
2011	Corsa-D	●
2011	Insignia	●
2011	Zafira-B	●
2012	Ampera	●
2012	Antara	●
2012	Astra-H	●
2012	Astra-J	●
2012	Corsa-D	●
2012	Insignia	●
2012	Zafira-B	●
2012	Zafira-C	●
2013	Adam	●

2013	Ampera	●
2013	Antara	●
2013	Astra-H	●
2013	Astra-J	●
2013	Cascada	●
2013	Corsa-D	●
2013	Insignia	●
2013	Mokka	●
2013	Zafira-B	●
2013	Zafira-C	●
2014	Adam	●
2014	Ampera	●
2014	Antara	●
2014	Astra-H	●
2014	Astra-J	●
2014	Cascada	●
2014	Corsa-D	●
2014	Insignia	●
2014	Meriva-B	●
2014	Mokka	●
2014	Zafira-B	●
2014	Zafira-C	●
2015	Adam	●
2015	Ampera	●
2015	Antara	●
2015	Astra-J	●
2015	Cascada	●
2015	Corsa-E	●
2015	Insignia	●
2015	Meriva-B	●
2015	Mokka	●
2015	Zafira-C	●
2016	Adam	●
2016	Antara	●
2016	Astra-J	●
2016	Astra-K	●
2016	Cascada	●
2016	Corsa-E	●
2016	Insignia	●
2016	Karl-Viva	●
2016	Meriva-B	●
2016	Mokka	●
2016	Zafira-C	●
2017	Adam	●
2017	Ampera-E	●
2017	Antara	●
2017	Astra-J	●
2017	Astra-K	●
2017	Cascada	●
2017	Corsa-E	●
2017	Insignia	●
2017	Karl-Viva	●
2017	Meriva-B	●

2017	Mokka	●
2017	Zafira-C	●
2018	Adam	●
2018	Ampera-E	●
2018	Astra-J	●
2018	Astra-K	●
2018	Cascada	●
2018	Corsa-E	●
2018	Insignia-B	●
2018	Karl-Viva	●
2018	Mokka	●
2018	Zafira-C	●
2019	Adam	●
2019	Ampera-E	●
2019	Astra-J	●
2019	Astra-K	●
2019	Cascada	●
2019	Corsa-E	●
2019	Insignia-B	●
2019	Karl-Viva	●
2019	Mokka	●
2019	Zafira-C	●
2020	Astra-J	●
2020	Astra-K	●
2020	Insignia-B	●

TPM Function List

Learn TP Sensors (Tyre Pressure)
Program Tyre Circumference
TP Sensor Exchange (Tyre Pressure)
TPM Learn Mode
Tire Pressure Sensor Signal Reset
Tire Pressure Sensors Learn
Tyre Type/Pressure Selection

VAUXHALL BLD Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Year	Model	BLD
2007	Vauxhall-VXR8	●
2008	Vauxhall-VXR8	●
2009	Insignia	●
2009	Vauxhall-VXR8	●
2010	Astra-J	●
2010	Insignia	●
2011	Antara	●
2011	Astra-J	●
2011	Insignia	●
2011	Vauxhall-VXR8	●
2012	Ampera	●
2012	Antara	●
2012	Astra-J	●
2012	Insignia	●
2012	Vauxhall-VXR8	●
2012	Zafira-C	●
2013	Adam	●
2013	Ampera	●
2013	Antara	●
2013	Astra-J	●
2013	Cascada	●
2013	Insignia	●
2013	Mokka	●
2013	Zafira-C	●
2014	Adam	●
2014	Ampera	●
2014	Antara	●
2014	Astra-J	●
2014	Cascada	●
2014	Insignia	●
2014	Meriva-B	●
2014	Mokka	●
2014	Zafira-C	●
2015	Adam	●
2015	Ampera	●
2015	Antara	●
2015	Astra-J	●
2015	Cascada	●
2015	Corsa-E	●
2015	Insignia	●
2015	Meriva-B	●
2015	Mokka	●
2015	Zafira-C	●
2016	Adam	●
2016	Antara	●
2016	Astra-J	●
2016	Cascada	●
2016	Corsa-E	●
2016	Insignia	●
2016	Karl-Viva	●
2016	Meriva-B	●
2016	Mokka	●

2016	Zafira-C	●
2017	Adam	●
2017	Antara	●
2017	Astra-J	●
2017	Cascada	●
2017	Corsa-E	●
2017	Insignia	●
2017	Karl-Viva	●
2017	Meriva-B	●
2017	Mokka	●
2017	Zafira-C	●
2018	Adam	●
2018	Astra-J	●
2018	Cascada	●
2018	Corsa-E	●
2018	Karl-Viva	●
2018	Mokka	●
2018	Zafira-C	●
2019	Adam	●
2019	Astra-J	●
2019	Cascada	●
2019	Corsa-E	●
2019	Karl-Viva	●
2019	Mokka	●
2019	Zafira-C	●
2020	Astra-J	●

BLD Function List

Automated Brake Bleed

Brake Bleed

VAUXHALL BMS Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Year	Model	BMS
2012	Ampera	●
2012	Combo-D	●
2013	Ampera	●
2013	Combo-D	●
2014	Ampera	●
2014	Combo-D	●
2015	Ampera	●
2015	Combo-D	●
2016	Combo-D	●
2017	Ampera-E	●
2017	Combo-D	●
2017	Crossland-X	●
2018	Ampera-E	●
2018	Combo-D	●
2018	Crossland-X	●
2018	Grandland-X	●
2019	Ampera-E	●
2019	Crossland-X	●
2019	Grandland-X	●
2020	Crossland-X	●
2020	Grandland-X	●

BMS Function List

Battery Learn
Battery Learned Values Reset
Battery Saver Mode
Battery Sensor Module Learn
Battery State of Charge Reset
Hybrid/EV Battery Contactor Open Reasons Reset
Hybrid/EV Battery Pack Capacity Learn
Hybrid/EV Battery Pack Charging Adaptive Learn Reset
Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn
Hybrid/EV Battery Pack Data Reset

VAUXHALL Diagnostic Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Year	Model	System Name	EcuInfo.	Read Codes	Erase Codes	LiveData	Actuation Test
1997	Astra-F	ECM (Engine Control Module)	●	●	●	●	※
1997	Astra-F	IMMO (Immobiliser)	※	●	●	●	※
1997	Astra-G-GMSA	ECM (Engine Control Module)	※	●	●	●	※
1997	Astra-G-GMSA	IMMO (Immobiliser)	※	●	●	●	※
1997	Calibra	ECM (Engine Control Module)	※	●	●	●	※
1997	Calibra	IMMO (Immobiliser)	※	●	●	●	※
1997	Corsa-B	ECM (Engine Control Module)	※	●	●	●	※
1997	Corsa-B	IMMO (Immobiliser)	※	●	●	●	※
1997	Corsa-B	PSCM (Power Steering Control Module)	※	●	●	●	※
1997	Corsa-B-GMSA	ECM (Engine Control Module)	※	●	●	●	※
1997	Corsa-B-GMSA	IMMO (Immobiliser)	※	●	●	●	※
1997	Frontera	IMMO (Immobiliser)	※	●	●	●	※
1997	Monterey	IMMO (Immobiliser)	※	●	●	●	※
1997	Omega-B	AR 25/35	※	●	●	●	※
1997	Omega-B	ECM (Engine Control Module)	※	●	●	●	※
1997	Omega-B	IMMO (Immobiliser)	※	●	●	●	※
1997	Sintra	BCM (Body Control Module)	※	●	●	●	※
1997	Sintra	IMMO (Immobiliser)	※	●	●	●	※
1997	Tigra	ECM (Engine Control Module)	※	●	●	●	※
1997	Tigra	IMMO (Immobiliser)	※	●	●	●	※
1997	Vectra-B	AOH (Add On Heater)	※	●	●	●	●
1997	Vectra-B	ECM (Engine Control Module)	※	●	●	●	※
1998	Arena	IMMO (Immobiliser)	※	●	●	●	※
1998	Astra-F	ECM (Engine Control Module)	●	●	●	●	※
1998	Astra-F	IMMO (Immobiliser)	※	●	●	●	※
1998	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
1998	Astra-G	Cruise Control	●	●	●	●	※
1998	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
1998	Astra-G-GMSA	ECM (Engine Control Module)	※	●	●	●	※
1998	Astra-G-GMSA	IMMO (Immobiliser)	※	●	●	●	※
1998	Corsa-B	ECM (Engine Control Module)	※	●	●	●	●
1998	Corsa-B	IMMO (Immobiliser)	※	●	●	●	※
1998	Corsa-B	PSCM (Power Steering Control Module)	※	●	●	●	※
1998	Corsa-B-GMSA	ECM (Engine Control Module)	※	●	●	●	※
1998	Corsa-B-GMSA	IMMO (Immobiliser)	※	●	●	●	※
1998	Frontera	IMMO (Immobiliser)	※	●	●	●	※
1998	Monterey	4L30-E	●	●	●	●	※
1998	Monterey	BCM (Body Control Module)	※	●	●	●	※
1998	Monterey	ECM (Engine Control Module)	●	●	●	●	※
1998	Monterey	IMMO (Immobiliser)	※	●	●	●	※
1998	Omega-B	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
1998	Omega-B	AOH (Add On Heater)	※	●	●	●	●
1998	Omega-B	AR 25/35	※	●	●	●	※
1998	Omega-B	ECM (Engine Control Module)	※	●	●	●	※
1998	Omega-B	HLD (HeadLamp Levelling Device)	※	●	●	●	●
1998	Omega-B	IMMO (Immobiliser)	※	●	●	●	※
1998	Sintra	BCM (Body Control Module)	※	●	●	●	※
1998	Sintra	ECM (Engine Control Module)	※	●	●	●	※
1998	Sintra	IMMO (Immobiliser)	※	●	●	●	※
1998	Tigra	ECM (Engine Control Module)	※	●	●	●	※

1998	Tigra	IMMO (Immobiliser)	※	●	●	●	※
1998	Vectra-B	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
1998	Vectra-B	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
1998	Vectra-B	AF 13-II/17/20/22	※	●	●	●	※
1998	Vectra-B	AOH (Add On Heater)	※	●	●	●	●
1998	Vectra-B	ECM (Engine Control Module)	※	●	●	●	※
1999	Arena	IMMO (Immobiliser)	※	●	●	●	※
1999	Astra-F	ECM (Engine Control Module)	●	●	●	●	●
1999	Astra-F	IMMO (Immobiliser)	※	●	●	●	※
1999	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
1999	Astra-G	Cruise Control	●	●	●	●	※
1999	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
1999	Astra-G	Info Display CART/CCRT	●	●	●	●	※
1999	Astra-G-GMSA	ECM (Engine Control Module)	※	●	●	●	※
1999	Astra-G-GMSA	IMMO (Immobiliser)	※	●	●	●	※
1999	Corsa-B	ECM (Engine Control Module)	※	●	●	●	●
1999	Corsa-B	IMMO (Immobiliser)	※	●	●	●	※
1999	Corsa-B	PSCM (Power Steering Control Module)	※	●	●	●	※
1999	Corsa-B-GMSA	ECM (Engine Control Module)	※	●	●	●	※
1999	Corsa-B-GMSA	IMMO (Immobiliser)	※	●	●	●	※
1999	Frontera-B	4L30-E	●	●	●	●	※
1999	Frontera-B	ABS	●	●	●	●	※
1999	Frontera-B	AR 25/35	※	●	●	●	※
1999	Frontera-B	ECM (Engine Control Module)	●	●	●	●	●
1999	Frontera-B	IMMO (Immobiliser)	※	●	●	●	※
1999	Monterey	4L30-E	●	●	●	●	※
1999	Monterey	ECM (Engine Control Module)	●	●	●	●	※
1999	Monterey	IMMO (Immobiliser)	※	●	●	●	※
1999	Movano	IMMO (Immobiliser)	※	●	●	●	※
1999	Omega-B	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
1999	Omega-B	AOH (Add On Heater)	※	●	●	●	●
1999	Omega-B	AR 25/35	※	●	●	●	※
1999	Omega-B	ECM (Engine Control Module)	※	●	●	●	※
1999	Omega-B	HLD (HeadLamp Levelling Device)	※	●	●	●	●
1999	Omega-B	IMMO (Immobiliser)	※	●	●	●	※
1999	Sintra	BCM (Body Control Module)	※	●	●	●	※
1999	Sintra	ECM (Engine Control Module)	※	●	●	●	※
1999	Sintra	IMMO (Immobiliser)	※	●	●	●	※
1999	Tigra	ECM (Engine Control Module)	※	●	●	●	※
1999	Tigra	IMMO (Immobiliser)	※	●	●	●	※
1999	Vectra-B	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
1999	Vectra-B	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
1999	Vectra-B	AF 13-II/17/20/22	※	●	●	●	※
1999	Vectra-B	AOH (Add On Heater)	※	●	●	●	●
1999	Vectra-B	ECM (Engine Control Module)	※	●	●	●	※
1999	Zafira	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
1999	Zafira	AF 13-II/17/20/22	※	●	●	●	※
1999	Zafira	ATW (Anti Theft Warning)	※	●	●	※	●
1999	Zafira	ECM (Engine Control Module)	※	●	●	●	※
1999	Zafira	ECM (Engine Cooling Module)	※	●	●	※	※
1999	Zafira	IMMO (Immobiliser)	※	●	●	●	※
2000	Agila	ABS (Anti-lock Braking System)	※	●	●	●	※
2000	Agila	ECM (Engine Control Module)	※	●	●	●	●
2000	Agila	IMMO (Immobiliser)	※	●	●	●	※
2000	Agila	PSCM (Power Steering Control Module)	※	●	●	●	※
2000	Agila	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2000	Arena	IMMO (Immobiliser)	※	●	●	●	※
2000	Astra-F	ECM (Engine Control Module)	※	●	●	●	※

2000	Astra-F	IMMO (Immobiliser)	※	●	●	●	※
2000	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2000	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
2000	Astra-G	Cruise Control	●	●	●	●	※
2000	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2000	Astra-G	ESP (Electronic Stability Program)	※	●	●	●	※
2000	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2000	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2000	Astra-G-GMSA	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2000	Astra-G-GMSA	ATW (Anti Theft Warning)	※	●	●	※	●
2000	Astra-G-GMSA	ECM (Engine Control Module)	※	●	●	●	※
2000	Astra-G-GMSA	ECM (Engine Cooling Module)	※	●	●	※	※
2000	Astra-G-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2000	Astra-G-GMSA	PSCM (Power Steering Control Module)	※	●	●	●	※
2000	Corsa-B	ECM (Engine Control Module)	●	●	●	●	●
2000	Corsa-B	IMMO (Immobiliser)	※	●	●	●	※
2000	Corsa-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2000	Corsa-B-GMSA	ECM (Engine Control Module)	※	●	●	●	※
2000	Corsa-B-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2000	Frontera-B	4L30-E	●	●	●	●	※
2000	Frontera-B	ABS	●	●	●	●	※
2000	Frontera-B	AR 25/35	※	●	●	●	※
2000	Frontera-B	ECM (Engine Control Module)	●	●	●	●	●
2000	Frontera-B	IMMO (Immobiliser)	※	●	●	●	※
2000	Movano	IMMO (Immobiliser)	※	●	●	●	※
2000	Omega-B	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2000	Omega-B	AOH (Add On Heater)	※	●	●	●	●
2000	Omega-B	AR 25/35	※	●	●	●	※
2000	Omega-B	ECM (Engine Control Module)	※	●	●	●	※
2000	Omega-B	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2000	Omega-B	IMMO (Immobiliser)	※	●	●	●	※
2000	Tigra	ECM (Engine Control Module)	※	●	●	●	※
2000	Tigra	IMMO (Immobiliser)	※	●	●	●	※
2000	Vectra-B	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
2000	Vectra-B	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2000	Vectra-B	AF 13-II/17/20/22	※	●	●	●	※
2000	Vectra-B	AF 13-II/17/20/22 CAN	※	●	●	●	●
2000	Vectra-B	AOH (Add On Heater)	※	●	●	●	●
2000	Vectra-B	ECM (Engine Control Module)	※	●	●	●	※
2000	Vectra-B	Headlamp Adjustment(Left)	※	●	●	●	※
2000	Vectra-B	Headlamp Adjustment(Right)	※	●	●	●	※
2000	Zafira	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2000	Zafira	AF 13-II/17/20/22	※	●	●	●	※
2000	Zafira	ATW (Anti Theft Warning)	※	●	●	※	●
2000	Zafira	ECM (Engine Control Module)	※	●	●	●	※
2000	Zafira	ECM (Engine Cooling Module)	※	●	●	※	※
2000	Zafira	ESP (Electronic Stability Program)	※	●	●	●	※
2000	Zafira	IMMO (Immobiliser)	※	●	●	●	※
2000	Zafira	PSCM (Power Steering Control Module)	※	●	●	●	※
2001	Agila	ABS (Anti-lock Braking System)	※	●	●	●	※
2001	Agila	ECM (Engine Control Module)	※	●	●	●	●
2001	Agila	IMMO (Immobiliser)	※	●	●	●	※
2001	Agila	PSCM (Power Steering Control Module)	※	●	●	●	※
2001	Agila	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2001	Astra-F	ECM (Engine Control Module)	※	●	●	●	●
2001	Astra-F	IMMO (Immobiliser)	※	●	●	●	※
2001	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2001	Astra-G	CDL (Central Door Lock)	※	●	●	※	●

2001	Astra-G	Cruise Control	●	●	●	●	※
2001	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2001	Astra-G	ESP (Electronic Stability Program)	※	●	●	●	※
2001	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2001	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2001	Astra-G	TU (Telematic unit)	●	●	●	※	※
2001	Astra-G-GMSA	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2001	Astra-G-GMSA	ATW (Anti Theft Warning)	※	●	●	※	●
2001	Astra-G-GMSA	ECM (Engine Control Module)	●	●	●	●	※
2001	Astra-G-GMSA	ECM (Engine Cooling Module)	※	●	●	※	※
2001	Astra-G-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2001	Astra-G-GMSA	PSCM (Power Steering Control Module)	※	●	●	●	※
2001	Campo	IMMO (Immobiliser)	※	●	●	●	※
2001	Corsa-B	ECM (Engine Control Module)	●	●	●	●	※
2001	Corsa-B	IMMO (Immobiliser)	※	●	●	●	※
2001	Corsa-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2001	Corsa-B-GMSA	ECM (Engine Control Module)	※	●	●	●	※
2001	Corsa-B-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2001	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2001	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2001	Corsa-C	ECM (Engine Control Module)	※	●	●	●	●
2001	Frontera-B	ABS	●	●	●	●	※
2001	Frontera-B	AR 25/35	※	●	●	●	※
2001	Frontera-B	ECM (Engine Control Module)	●	●	●	●	●
2001	Frontera-B	IMMO (Immobiliser)	※	●	●	●	※
2001	Movano	IMMO (Immobiliser)	※	●	●	●	※
2001	Omega-B	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2001	Omega-B	AOH (Add On Heater)	※	●	●	●	●
2001	Omega-B	AR 25/35	※	●	●	●	※
2001	Omega-B	ECM (Engine Control Module)	※	●	●	●	※
2001	Omega-B	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2001	Omega-B	IMMO (Immobiliser)	※	●	●	●	※
2001	Speedster-VX220	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
2001	Speedster-VX220	ECM (Engine Control Module)	※	●	●	●	※
2001	Speedster-VX220	IMMO (Immobiliser)	※	●	●	●	※
2001	Vectra-B	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
2001	Vectra-B	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2001	Vectra-B	AF 13-II/17/20/22	※	●	●	●	※
2001	Vectra-B	AOH (Add On Heater)	※	●	●	●	●
2001	Vectra-B	ECM (Engine Control Module)	●	●	●	●	※
2001	Vectra-B	Headlamp Adjustment(Left)	※	●	●	●	※
2001	Vectra-B	Headlamp Adjustment(Right)	※	●	●	●	※
2001	Vivaro	ABS (Anti-lock Braking System)	※	●	●	●	※
2001	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2001	Vivaro	BCM (Body Control Module)	●	※	●	●	●
2001	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2001	Vivaro	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2001	Zafira	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2001	Zafira	AF 13-II/17/20/22 CAN	※	●	●	●	●
2001	Zafira	ATW (Anti Theft Warning)	※	●	●	※	●
2001	Zafira	ECM (Engine Control Module)	●	●	●	●	※
2001	Zafira	ECM (Engine Cooling Module)	※	●	●	※	※
2001	Zafira	ESP (Electronic Stability Program)	※	●	●	●	※
2001	Zafira	IMMO (Immobiliser)	※	●	●	●	※
2001	Zafira	PSCM (Power Steering Control Module)	※	●	●	●	※
2002	Agila	ABS (Anti-lock Braking System)	※	●	●	●	※
2002	Agila	ECM (Engine Control Module)	※	●	●	●	●
2002	Agila	IMMO (Immobiliser)	※	●	●	●	※

2002	Agila	PSCM (Power Steering Control Module)	※	●	●	●	※
2002	Agila	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2002	Astra-F	ECM (Engine Control Module)	※	●	●	●	●
2002	Astra-F	IMMO (Immobiliser)	※	●	●	●	※
2002	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2002	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
2002	Astra-G	Cruise Control	●	●	●	●	※
2002	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2002	Astra-G	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2002	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2002	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2002	Astra-G	TU (Telematic unit)	●	●	●	※	※
2002	Astra-G-GMSA	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2002	Astra-G-GMSA	ATW (Anti Theft Warning)	※	●	●	※	●
2002	Astra-G-GMSA	ECM (Engine Control Module)	●	●	●	●	※
2002	Astra-G-GMSA	ECM (Engine Cooling Module)	※	●	●	※	※
2002	Astra-G-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2002	Astra-G-GMSA	PSCM (Power Steering Control Module)	※	●	●	●	※
2002	Campo	IMMO (Immobiliser)	※	●	●	●	※
2002	Combo	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2002	Combo	BCM (Body Control Module)	※	●	●	●	※
2002	Combo	ECM (Engine Control Module)	※	●	●	●	●
2002	Combo	IMMO (Immobiliser)	※	●	●	●	※
2002	Corsa-B	ECM (Engine Control Module)	●	●	●	●	※
2002	Corsa-B	IMMO (Immobiliser)	※	●	●	●	※
2002	Corsa-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2002	Corsa-B-GMSA	ECM (Engine Control Module)	※	●	●	●	※
2002	Corsa-B-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2002	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2002	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2002	Corsa-C	BCM (Body Control Module)	※	●	●	●	※
2002	Corsa-C	ECM (Engine Control Module)	●	●	●	●	●
2002	Corsa-C-GMSA	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2002	Corsa-C-GMSA	BCM (Body Control Module)	※	●	●	●	※
2002	Corsa-C-GMSA	ECM (Engine Control Module)	※	●	●	●	●
2002	Corsa-C-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2002	Corsa-C-GMSA	PSCM (Power Steering Control Module)	※	●	●	●	※
2002	Corsa-C-GMSA	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2002	Frontera-B	ABS	●	●	●	●	※
2002	Frontera-B	AR 25/35	※	●	●	●	※
2002	Frontera-B	ECM (Engine Control Module)	●	●	●	●	●
2002	Frontera-B	IMMO (Immobiliser)	※	●	●	●	※
2002	Movano	IMMO (Immobiliser)	※	●	●	●	※
2002	Omega-B	5L40-E	※	●	●	●	※
2002	Omega-B	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2002	Omega-B	AOH (Add On Heater)	※	●	●	●	●
2002	Omega-B	AR 25/35	※	●	●	●	※
2002	Omega-B	ECM (Engine Control Module)	※	●	●	●	※
2002	Omega-B	ESP (Electronic Stability Program)	※	●	●	●	※
2002	Omega-B	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2002	Omega-B	IMMO (Immobiliser)	※	●	●	●	※
2002	Speedster-VX220	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
2002	Speedster-VX220	ECM (Engine Control Module)	※	●	●	●	※
2002	Speedster-VX220	IMMO (Immobiliser)	※	●	●	●	※
2002	Vectra-C-Signum	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2002	Vectra-C-Signum	DSM (Driver Seat Module)	●	●	●	●	※
2002	Vectra-C-Signum	Driver information display	●	●	●	●	※
2002	Vectra-C-Signum	ECM (Engine Control Module)	●	●	●	●	●

2002	Vectra-C-Signum	EH (Electrical Horn)	●	●	●	●	●
2002	Vectra-C-Signum	ESM/SH (Electronic Seat Memory/Seat Heating)	●	●	●	●	※
2002	Vectra-C-Signum	PAS (Park pilot)	●	●	●	●	●
2002	Vectra-C-Signum	SRM (Sun Roof Module)	●	●	●	●	※
2002	Vectra-C-Signum	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2002	Vivaro	ABS (Anti-lock Braking System)	※	●	●	●	※
2002	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2002	Vivaro	BCM (Body Control Module)	●	※	●	●	●
2002	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2002	Vivaro	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2002	Zafira	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2002	Zafira	AF 13-II/17/20/22 CAN	※	●	●	●	●
2002	Zafira	ATW (Anti Theft Warning)	※	●	●	※	●
2002	Zafira	ECM (Engine Control Module)	●	●	●	●	●
2002	Zafira	ECM (Engine Cooling Module)	※	●	●	※	※
2002	Zafira	ESP (Electronic Stability Program)	※	●	●	●	※
2002	Zafira	IMMO (Immobiliser)	※	●	●	●	※
2002	Zafira	PSCM (Power Steering Control Module)	※	●	●	●	※
2003	Agila	ABS (Anti-lock Braking System)	※	●	●	●	※
2003	Agila	ECM (Engine Control Module)	※	●	●	●	●
2003	Agila	IMMO (Immobiliser)	※	●	●	●	※
2003	Agila	PSCM (Power Steering Control Module)	※	●	●	●	※
2003	Agila	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2003	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2003	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
2003	Astra-G	Cruise Control	●	●	●	●	※
2003	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2003	Astra-G	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2003	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2003	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2003	Astra-G	TU (Telematic unit)	●	●	●	※	※
2003	Astra-G-GMSA	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2003	Astra-G-GMSA	ATW (Anti Theft Warning)	※	●	●	※	●
2003	Astra-G-GMSA	ECM (Engine Control Module)	※	●	●	●	※
2003	Astra-G-GMSA	ECM (Engine Cooling Module)	※	●	●	※	※
2003	Astra-G-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2003	Astra-G-GMSA	PSCM (Power Steering Control Module)	※	●	●	●	※
2003	Combo	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2003	Combo	AF 13-II/17/20/22	※	●	●	●	※
2003	Combo	AF 13-II/17/20/22 CAN	※	●	●	●	●
2003	Combo	AOH (Add On Heater)	※	●	●	●	●
2003	Combo	BCM (Body Control Module)	※	●	●	●	※
2003	Combo	ECM (Engine Control Module)	※	●	●	●	●
2003	Combo	IMMO (Immobiliser)	※	●	●	●	※
2003	Corsa-B	ECM (Engine Control Module)	●	●	●	●	※
2003	Corsa-B	IMMO (Immobiliser)	※	●	●	●	※
2003	Corsa-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2003	Corsa-B-GMSA	ECM (Engine Control Module)	※	●	●	●	※
2003	Corsa-B-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2003	Corsa-C	AF 13-II/17/20/22	※	●	●	●	※
2003	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2003	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2003	Corsa-C	BCM (Body Control Module)	※	●	●	●	※
2003	Corsa-C	ECM (Engine Control Module)	※	●	●	●	●
2003	Corsa-C-GMSA	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2003	Corsa-C-GMSA	BCM (Body Control Module)	※	●	●	●	※
2003	Corsa-C-GMSA	ECM (Engine Control Module)	※	●	●	●	●
2003	Corsa-C-GMSA	IMMO (Immobiliser)	※	●	●	●	※

2003	Corsa-C-GMSA	PSCM (Power Steering Control Module)	※	●	●	●	※
2003	Corsa-C-GMSA	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2003	Frontera-B	ABS	●	●	●	●	※
2003	Frontera-B	AR 25/35	※	●	●	●	※
2003	Frontera-B	ECM (Engine Control Module)	●	●	●	●	●
2003	Frontera-B	IMMO (Immobiliser)	※	●	●	●	※
2003	Meriva	ECM (Engine Control Module)	●	●	●	●	●
2003	Meriva	ESP (Electronic Stability Program)	※	●	●	●	※
2003	Meriva	Easytronic (MTA)	●	●	●	●	※
2003	Meriva	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2003	Movano	IMMO (Immobiliser)	※	●	●	●	※
2003	Omega-B	5L40-E	※	●	●	●	※
2003	Omega-B	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2003	Omega-B	AOH (Add On Heater)	※	●	●	●	●
2003	Omega-B	AR 25/35	※	●	●	●	※
2003	Omega-B	ECM (Engine Control Module)	※	●	●	●	※
2003	Omega-B	ESP (Electronic Stability Program)	※	●	●	●	※
2003	Omega-B	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2003	Omega-B	IMMO (Immobiliser)	※	●	●	●	※
2003	Speedster-VX220	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
2003	Speedster-VX220	ECM (Engine Control Module)	※	●	●	●	※
2003	Speedster-VX220	IMMO (Immobiliser)	※	●	●	●	※
2003	Vectra-C-Signum	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2003	Vectra-C-Signum	DSM (Driver Seat Module)	●	●	●	●	※
2003	Vectra-C-Signum	Driver information display	●	●	●	●	※
2003	Vectra-C-Signum	ECM (Engine Control Module)	●	●	●	●	●
2003	Vectra-C-Signum	EH (Electrical Horn)	●	●	●	●	●
2003	Vectra-C-Signum	ESM/SH (Electronic Seat Memory/Seat Heating)	●	●	●	●	※
2003	Vectra-C-Signum	PAS (Park pilot)	●	●	●	●	●
2003	Vectra-C-Signum	SRM (Sun Roof Module)	●	●	●	●	※
2003	Vectra-C-Signum	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2003	Vivaro	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2003	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2003	Vivaro	BCM (Body Control Module)	●	※	●	●	●
2003	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2003	Vivaro	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2003	Zafira	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2003	Zafira	AF 13-II/17/20/22 CAN	※	●	●	●	●
2003	Zafira	ATW (Anti Theft Warning)	※	●	●	※	●
2003	Zafira	ECM (Engine Control Module)	●	●	●	●	●
2003	Zafira	ECM (Engine Cooling Module)	※	●	●	※	※
2003	Zafira	ESP (Electronic Stability Program)	※	●	●	●	※
2003	Zafira	Headlamp Adjustment (Left)	※	●	●	●	※
2003	Zafira	Headlamp Adjustment (Right)	※	●	●	●	※
2003	Zafira	IMMO (Immobiliser)	※	●	●	●	※
2003	Zafira	PSCM (Power Steering Control Module)	※	●	●	●	※
2004	Agila	ABS (Anti-lock Braking System)	※	●	●	●	※
2004	Agila	ECM (Engine Control Module)	※	●	●	●	●
2004	Agila	IMMO (Immobiliser)	※	●	●	●	※
2004	Agila	PSCM (Power Steering Control Module)	※	●	●	●	※
2004	Agila	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2004	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2004	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
2004	Astra-G	Cruise Control	●	●	●	●	※
2004	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2004	Astra-G	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2004	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2004	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●

2004	Astra-G	TU (Telematic unit)	●	●	●	※	※
2004	Astra-G-GMSA	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2004	Astra-G-GMSA	ATW (Anti Theft Warning)	※	●	●	※	●
2004	Astra-G-GMSA	ECM (Engine Control Module)	※	●	●	●	※
2004	Astra-G-GMSA	ECM (Engine Cooling Module)	※	●	●	※	※
2004	Astra-G-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2004	Astra-G-GMSA	PSCM (Power Steering Control Module)	※	●	●	●	※
2004	Astra-H	AF17-4	●	●	●	●	●
2004	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2004	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2004	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2004	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2004	Astra-H	ECM (Engine Control Module)	●	●	●	●	●
2004	Astra-H	EHHT (Electrohydraulic HardTop)	●	●	●	●	●
2004	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2004	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2004	Astra-H	IC (Instrument Cluster)	●	●	●	●	●
2004	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2004	Astra-H	IMMO (Immobiliser)	●	●	●	●	●
2004	Astra-H	PAS (Park pilot)	●	●	●	●	●
2004	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2004	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2004	Astra-H	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	※
2004	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2004	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2004	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●
2004	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2004	Combo	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2004	Combo	AF 13-II/17/20/22	※	●	●	●	※
2004	Combo	AF 13-II/17/20/22 CAN	※	●	●	●	●
2004	Combo	AOH (Add On Heater)	※	●	●	●	●
2004	Combo	BCM (Body Control Module)	※	●	●	●	※
2004	Combo	ECM (Engine Control Module)	●	●	●	●	●
2004	Combo	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2004	Combo	IMMO (Immobiliser)	※	●	●	●	※
2004	Corsa-B-GMSA	ECM (Engine Control Module)	※	●	●	●	※
2004	Corsa-B-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2004	Corsa-C	AF 13-II/17/20/22	※	●	●	●	※
2004	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2004	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2004	Corsa-C	ECM (Engine Control Module)	●	●	●	●	●
2004	Corsa-C	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2004	Corsa-C-GMSA	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2004	Corsa-C-GMSA	BCM (Body Control Module)	※	●	●	●	※
2004	Corsa-C-GMSA	ECM (Engine Control Module)	※	●	●	●	●
2004	Corsa-C-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2004	Corsa-C-GMSA	PSCM (Power Steering Control Module)	※	●	●	●	※
2004	Corsa-C-GMSA	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2004	Meriva	AOH (Add On Heater)	※	●	●	●	●
2004	Meriva	ECM (Engine Control Module)	●	●	●	●	●
2004	Meriva	ESP (Electronic Stability Program)	※	●	●	●	※
2004	Meriva	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2004	Movano	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2004	Movano	ECM (Engine Control Module)	●	●	●	●	※
2004	Movano	IMMO (Immobiliser)	※	●	●	●	※
2004	Speedster-VX220	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
2004	Speedster-VX220	ECM (Engine Control Module)	※	●	●	●	※
2004	Speedster-VX220	IMMO (Immobiliser)	※	●	●	●	※

2004	Vauxhall-Monaro	ABS/ETC	●	●	●	●	※
2004	Vauxhall-Monaro	Audio system	●	●	●	●	※
2004	Vauxhall-Monaro	BCM (Body Control Module)	●	●	●	●	※
2004	Vauxhall-Monaro	ECM (Engine Control Module)	●	●	●	●	※
2004	Vauxhall-Monaro	GEN III automatic transmission	●	●	●	●	※
2004	Vauxhall-Monaro	IC (Instrument Cluster)	●	●	●	●	※
2004	Vauxhall-Monaro	OCC (Occupant climate control)	●	●	●	●	※
2004	Vauxhall-Monaro	PIM (Powertrain interface module)	●	●	●	●	●
2004	Vauxhall-Monaro	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	※
2004	Vectra-C-Signum	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2004	Vectra-C-Signum	CVTronic	●	●	●	※	●
2004	Vectra-C-Signum	DSM (Driver Seat Module)	●	●	●	●	※
2004	Vectra-C-Signum	Driver information display	●	●	●	●	※
2004	Vectra-C-Signum	ECM (Engine Control Module)	●	●	●	●	●
2004	Vectra-C-Signum	EH (Electrical Horn)	●	●	●	●	●
2004	Vectra-C-Signum	ESM/SH (Electronic Seat Memory/Seat Heating)	●	●	●	●	※
2004	Vectra-C-Signum	PAS (Park pilot)	●	●	●	●	●
2004	Vectra-C-Signum	SRM (Sun Roof Module)	●	●	●	●	※
2004	Vectra-C-Signum	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2004	Vivaro	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2004	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2004	Vivaro	BCM (Body Control Module)	●	※	●	●	●
2004	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2004	Vivaro	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2004	Zafira	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2004	Zafira	AF 13-II/17/20/22 CAN	※	●	●	●	●
2004	Zafira	ATW (Anti Theft Warning)	※	●	●	※	●
2004	Zafira	ECM (Engine Control Module)	●	●	●	●	●
2004	Zafira	ECM (Engine Cooling Module)	※	●	●	※	※
2004	Zafira	ESP (Electronic Stability Program)	※	●	●	●	※
2004	Zafira	Headlamp Adjustment(Left)	※	●	●	●	※
2004	Zafira	Headlamp Adjustment(Right)	※	●	●	●	※
2004	Zafira	IMMO (Immobiliser)	※	●	●	●	※
2004	Zafira	PSCM (Power Steering Control Module)	※	●	●	●	※
2005	Agila	ABS (Anti-lock Braking System)	※	●	●	●	※
2005	Agila	ECM (Engine Control Module)	●	●	●	●	●
2005	Agila	IMMO (Immobiliser)	※	●	●	●	※
2005	Agila	PSCM (Power Steering Control Module)	※	●	●	●	※
2005	Agila	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2005	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2005	Astra-G	Cruise Control	●	●	●	●	※
2005	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2005	Astra-G	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2005	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2005	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2005	Astra-G	TU (Telematic unit)	●	●	●	※	※
2005	Astra-G-GMSA	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2005	Astra-G-GMSA	ATW (Anti Theft Warning)	※	●	●	※	●
2005	Astra-G-GMSA	ECM (Engine Control Module)	※	●	●	●	※
2005	Astra-G-GMSA	ECM (Engine Cooling Module)	※	●	●	※	※
2005	Astra-G-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2005	Astra-G-GMSA	PSCM (Power Steering Control Module)	※	●	●	●	※
2005	Astra-H	AF17-4	●	●	●	●	●
2005	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2005	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2005	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2005	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2005	Astra-H	ECM (Engine Control Module)	●	●	●	●	●

2005	Astra-H	EHHT (Electrohydraulic HardTop)	●	●	●	●	●
2005	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2005	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2005	Astra-H	IC (Instrument Cluster)	●	●	●	●	●
2005	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2005	Astra-H	IMMO (Immobiliser)	●	●	●	●	●
2005	Astra-H	PAS (Park pilot)	●	●	●	●	●
2005	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2005	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2005	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2005	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2005	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●
2005	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2005	Combo	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2005	Combo	AF 13-II/17/20/22	※	●	●	●	※
2005	Combo	AF 13-II/17/20/22 CAN	※	●	●	●	●
2005	Combo	AOH (Add On Heater)	※	●	●	●	●
2005	Combo	BCM (Body Control Module)	※	●	●	●	※
2005	Combo	DAB (Digital Audio Broadcast)	●	●	●	※	※
2005	Combo	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2005	Combo	ECM (Engine Control Module)	●	●	●	●	●
2005	Combo	EHU (Entertainment Head Unit)	●	●	●	※	※
2005	Combo	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2005	Combo	IMMO (Immobiliser)	※	●	●	●	※
2005	Corsa-B-GMSA	ECM (Engine Control Module)	※	●	●	●	※
2005	Corsa-B-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2005	Corsa-C	AF 13-II/17/20/22	※	●	●	●	※
2005	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2005	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2005	Corsa-C	DAB (Digital Audio Broadcast)	●	●	●	※	※
2005	Corsa-C	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2005	Corsa-C	ECM (Engine Control Module)	●	●	●	●	●
2005	Corsa-C	EHU (Entertainment Head Unit)	●	●	●	※	※
2005	Corsa-C	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2005	Corsa-C-GMSA	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2005	Corsa-C-GMSA	BCM (Body Control Module)	※	●	●	●	※
2005	Corsa-C-GMSA	ECM (Engine Control Module)	※	●	●	●	●
2005	Corsa-C-GMSA	IMMO (Immobiliser)	※	●	●	●	※
2005	Corsa-C-GMSA	PSCM (Power Steering Control Module)	※	●	●	●	※
2005	Corsa-C-GMSA	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2005	Meriva	AOH (Add On Heater)	※	●	●	●	●
2005	Meriva	DAB (Digital Audio Broadcast)	●	●	●	※	※
2005	Meriva	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2005	Meriva	ECM (Engine Control Module)	●	●	●	●	●
2005	Meriva	EHU (Entertainment Head Unit)	●	●	●	※	※
2005	Meriva	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2005	Meriva	IMMO (Immobiliser)	※	●	●	●	※
2005	Movano	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2005	Movano	BCM (Body Control Module)	※	●	●	●	※
2005	Movano	ECM (Engine Control Module)	●	●	●	●	※
2005	Speedster-VX220	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
2005	Speedster-VX220	ECM (Engine Control Module)	※	●	●	●	※
2005	Speedster-VX220	IMMO (Immobiliser)	※	●	●	●	※
2005	Tigra-B	ABS8/ESP8 (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2005	Tigra-B	BCM (Body Control Module)	※	●	●	●	※
2005	Tigra-B	ECM (Engine Control Module)	※	●	●	●	●
2005	Tigra-B	Easytronic (MTA)	●	●	●	●	※

2005	Tigra-B	IMMO (Immobiliser)	※	●	●	●	※
2005	Tigra-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2005	Tigra-B	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2005	Vauxhall-Monaro	ABS/ETC	●	●	●	●	※
2005	Vauxhall-Monaro	Audio system	●	●	●	●	※
2005	Vauxhall-Monaro	Auxiliary gauges	●	●	●	●	※
2005	Vauxhall-Monaro	BCM (Body Control Module)	●	●	●	●	※
2005	Vauxhall-Monaro	ECM (Engine Control Module)	●	●	●	●	●
2005	Vauxhall-Monaro	GEN III automatic transmission	●	●	●	●	※
2005	Vauxhall-Monaro	Instrument	●	●	●	●	※
2005	Vauxhall-Monaro	OCC (Occupant climate control)	●	●	●	●	※
2005	Vauxhall-Monaro	PIM (Powertrain interface module)	●	●	●	●	※
2005	Vauxhall-Monaro	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	※
2005	Vectra-C-Signum	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2005	Vectra-C-Signum	CVTronic	●	●	●	※	●
2005	Vectra-C-Signum	DAB (Digital Audio Broadcast)	●	●	●	※	※
2005	Vectra-C-Signum	DSM (Driver Seat Module)	●	●	●	●	※
2005	Vectra-C-Signum	Driver information display	●	●	●	●	※
2005	Vectra-C-Signum	ECM (Engine Control Module)	●	●	●	●	●
2005	Vectra-C-Signum	EH (Electrical Horn)	●	●	●	●	●
2005	Vectra-C-Signum	ESM/SH (Electronic Seat Memory/Seat Heating)	●	●	●	●	※
2005	Vectra-C-Signum	PAS (Park pilot)	●	●	●	●	●
2005	Vectra-C-Signum	SRM (Sun Roof Module)	●	●	●	●	※
2005	Vectra-C-Signum	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2005	Vivaro	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2005	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2005	Vivaro	BCM (Body Control Module)	●	※	●	●	●
2005	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2005	Vivaro	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2005	Zafira	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2005	Zafira	AF 13-II/17/20/22 CAN	※	●	●	●	●
2005	Zafira	ATW (Anti Theft Warning)	※	●	●	※	●
2005	Zafira	ECM (Engine Control Module)	●	●	●	●	●
2005	Zafira	ECM (Engine Cooling Module)	※	●	●	※	※
2005	Zafira	ESP (Electronic Stability Program)	※	●	●	●	※
2005	Zafira	Headlamp Adjustment(Left)	※	●	●	●	※
2005	Zafira	Headlamp Adjustment(Right)	※	●	●	●	※
2005	Zafira	IMMO (Immobiliser)	※	●	●	●	※
2005	Zafira	PSCM (Power Steering Control Module)	※	●	●	●	※
2005	Zafira-B	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2005	Zafira-B	ATW (Anti Theft Warning System)	●	●	●	●	●
2005	Zafira-B	CDL (Central Door Lock)	●	●	●	●	●
2005	Zafira-B	DAB (Digital Audio Broadcast)	●	●	●	※	※
2005	Zafira-B	ECM (Engine Control Module)	●	●	●	●	●
2005	Zafira-B	EHS (Electrical Heater System)	●	●	●	●	※
2005	Zafira-B	EPS (Electric Power Steering)	●	●	●	●	※
2005	Zafira-B	IC (Instrument Cluster)	●	●	●	●	●
2005	Zafira-B	IL (Interior Lighting)	●	●	●	●	●
2005	Zafira-B	IMMO (Immobiliser)	●	●	●	●	●
2005	Zafira-B	PAS (Park pilot)	●	●	●	●	●
2005	Zafira-B	PEPS (Open&Start)	●	●	●	●	※
2005	Zafira-B	SLM (Shift Lever Module)	●	●	●	●	●
2005	Zafira-B	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2005	Zafira-B	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2005	Zafira-B	UHP (Mobile Phone Portal)	●	●	●	※	※
2005	Zafira-B	W&W (Wipers/Washer)	●	●	●	●	●
2005	Zafira-B	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2006	Agila	ABS (Anti-lock Braking System)	※	●	●	●	※

2006	Agila	ECM (Engine Control Module)	●	●	●	●	●
2006	Agila	IMMO (Immobiliser)	※	●	●	●	※
2006	Agila	PSCM (Power Steering Control Module)	※	●	●	●	※
2006	Agila	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2006	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2006	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
2006	Astra-G	Cruise Control	●	●	●	●	※
2006	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2006	Astra-G	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2006	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2006	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2006	Astra-G	TU (Telematic unit)	●	●	●	※	※
2006	Astra-H	AF 40-6	●	●	●	●	●
2006	Astra-H	AF17-4	●	●	●	●	●
2006	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2006	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2006	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2006	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2006	Astra-H	ECM (Engine Control Module)	●	●	●	●	●
2006	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2006	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2006	Astra-H	IC (Instrument Cluster)	●	●	●	●	●
2006	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2006	Astra-H	IMMO (Immobiliser)	●	●	●	●	●
2006	Astra-H	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2006	Astra-H	PAS (Park pilot)	●	●	●	●	●
2006	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2006	Astra-H	SAC (Automatic Climate Control)	●	●	●	●	●
2006	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2006	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2006	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2006	Astra-H	UHP (Mobile Phone Portal)	●	●	●	※	※
2006	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●
2006	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2006	Combo	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2006	Combo	AF 13-II/17/20/22	※	●	●	●	※
2006	Combo	AF 13-II/17/20/22 CAN	※	●	●	●	●
2006	Combo	AOH (Add On Heater)	※	●	●	●	●
2006	Combo	BCM (Body Control Module)	※	●	●	●	※
2006	Combo	DAB (Digital Audio Broadcast)	●	●	●	※	※
2006	Combo	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2006	Combo	ECM (Engine Control Module)	●	●	●	●	●
2006	Combo	EHU (Entertainment Head Unit)	●	●	●	※	※
2006	Combo	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2006	Combo	IMMO (Immobiliser)	※	●	●	●	※
2006	Combo	UHP (Mobile Phone Portal)	●	●	●	※	※
2006	Corsa-C	AF 13-II/17/20/22	※	●	●	●	※
2006	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2006	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2006	Corsa-C	DAB (Digital Audio Broadcast)	●	●	●	※	※
2006	Corsa-C	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2006	Corsa-C	ECM (Engine Control Module)	●	●	●	●	●
2006	Corsa-C	EHU (Entertainment Head Unit)	●	●	●	※	※
2006	Corsa-C	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2006	Corsa-C	UHP (Mobile Phone Portal)	●	●	●	※	※
2006	Meriva	AFL (Adaptive Forward Lighting)	●	●	●	※	※
2006	Meriva	AOH (Add On Heater)	※	●	●	●	●
2006	Meriva	DAB (Digital Audio Broadcast)	●	●	●	※	※

2006	Meriva	DIS (Info Display TID, BID, GID, CID)	●	●	●	※	※
2006	Meriva	ECM (Engine Control Module)	●	●	●	●	●
2006	Meriva	EHS (Electrical Heater System)	●	●	●	●	●
2006	Meriva	EHU (Entertainment Head Unit)	●	●	●	※	※
2006	Meriva	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2006	Meriva	UHP (Mobile Phone Portal)	●	●	●	※	※
2006	Movano	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2006	Movano	BCM (Body Control Module)	※	●	●	●	※
2006	Movano	G9U 750 (2.5l)	●	●	●	●	※
2006	Speedster-VX220	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
2006	Speedster-VX220	ECM (Engine Control Module)	※	●	●	●	※
2006	Speedster-VX220	IMMO (Immobiliser)	※	●	●	●	※
2006	Tigra-B	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2006	Tigra-B	BCM (Body Control Module)	※	●	●	●	※
2006	Tigra-B	ECM (Engine Control Module)	※	●	●	●	●
2006	Tigra-B	Easytronic (MTA)	●	●	●	●	※
2006	Tigra-B	IC (Instrument Cluster)	※	●	●	※	●
2006	Tigra-B	IMMO (Immobiliser)	※	●	●	●	※
2006	Tigra-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2006	Tigra-B	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2006	Vauxhall-Monaro	ABS/ETC	●	●	●	●	※
2006	Vauxhall-Monaro	Audio system	●	●	●	●	※
2006	Vauxhall-Monaro	Auxiliary gauges	●	●	●	●	※
2006	Vauxhall-Monaro	Body Control Module	●	●	●	●	※
2006	Vauxhall-Monaro	ECM (Engine Control Module)	●	●	●	●	●
2006	Vauxhall-Monaro	GEN III automatic transmission	●	●	●	●	※
2006	Vauxhall-Monaro	Instrument	●	●	●	●	※
2006	Vauxhall-Monaro	OCC (Occupant climate control)	●	●	●	●	※
2006	Vauxhall-Monaro	PIM (Powertrain interface module)	●	●	●	●	※
2006	Vauxhall-Monaro	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	※
2006	Vectra-C-Signum	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2006	Vectra-C-Signum	CVTronic	●	●	●	※	●
2006	Vectra-C-Signum	DAB (Digital Audio Broadcast)	●	●	●	※	※
2006	Vectra-C-Signum	DSM (Driver Seat Module)	●	●	●	●	※
2006	Vectra-C-Signum	Driver information display	●	●	●	●	※
2006	Vectra-C-Signum	ECM (Engine Control Module)	●	●	●	●	●
2006	Vectra-C-Signum	EH (Electrical Horn)	●	●	●	●	●
2006	Vectra-C-Signum	EHS (Electrical Heater System)	●	●	●	●	●
2006	Vectra-C-Signum	ESM/SH (Electronic Seat Memory/Seat Heating)	●	●	●	●	※
2006	Vectra-C-Signum	IL (Interior Lighting)	●	●	●	●	●
2006	Vectra-C-Signum	MTA (Easytronic)	●	●	●	●	●
2006	Vectra-C-Signum	PAS (Park pilot)	●	●	●	●	●
2006	Vectra-C-Signum	SAC (Automatic Climate Control)	●	●	●	●	●
2006	Vectra-C-Signum	SRM (Sun Roof Module)	●	●	●	●	※
2006	Vectra-C-Signum	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2006	Vectra-C-Signum	UHP (Mobile Phone Portal)	●	●	●	※	※
2006	Vivaro	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2006	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2006	Vivaro	BCM (Body Control Module)	●	※	●	●	●
2006	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2006	Vivaro	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2006	Zafira-B	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2006	Zafira-B	ATW (Anti Theft Warning System)	●	●	●	●	●
2006	Zafira-B	CDL (Central Door Lock)	●	●	●	●	●
2006	Zafira-B	DAB (Digital Audio Broadcast)	●	●	●	※	※
2006	Zafira-B	ECM (Engine Control Module)	●	●	●	●	●
2006	Zafira-B	EHS (Electrical Heater System)	●	●	●	●	※

2006	Zafira-B	EPS (Electric Power Steering)	●	●	●	●	※
2006	Zafira-B	IC (Instrument Cluster)	●	●	●	●	●
2006	Zafira-B	IL (Interior Lighting)	●	●	●	●	●
2006	Zafira-B	IMMO (Immobiliser)	●	●	●	●	●
2006	Zafira-B	IPC (Instrument Control Unit)	●	●	●	●	●
2006	Zafira-B	PAS (Park pilot)	●	●	●	●	●
2006	Zafira-B	PEPS (Open&Start)	●	●	●	●	※
2006	Zafira-B	SAC (Automatic Climate Control)	●	●	●	●	●
2006	Zafira-B	SLM (Shift Lever Module)	●	●	●	●	●
2006	Zafira-B	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2006	Zafira-B	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2006	Zafira-B	UHP (Mobile Phone Portal)	●	●	●	※	※
2006	Zafira-B	W&W (Wipers/Washer)	●	●	●	●	●
2006	Zafira-B	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2007	Agila	ABS (Anti-lock Braking System)	※	●	●	●	※
2007	Agila	ECM (Engine Control Module)	●	●	●	●	●
2007	Agila	IMMO (Immobiliser)	※	●	●	●	※
2007	Agila	PSCM (Power Steering Control Module)	※	●	●	●	※
2007	Agila	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2007	Antara-CaptivaShort-Body	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2007	Antara-CaptivaShort-Body	ABS/TC/ESP (Vehicle Dynamic System)	●	●	●	●	●
2007	Antara-CaptivaShort-Body	AHL (Automatic Headlamp Levelling)	●	●	●	●	●
2007	Antara-CaptivaShort-Body	ATW (Anti Theft Warning System)	●	●	●	●	●
2007	Antara-CaptivaShort-Body	BCM (Body Control Module)	●	●	●	●	●
2007	Antara-CaptivaShort-Body	CDL (Central Door Lock)	●	●	●	●	●
2007	Antara-CaptivaShort-Body	DIS (Info Display TID, BID, GID, CID)	●	●	●	※	※
2007	Antara-CaptivaShort-Body	ECC (Electronic Climate Control)	●	●	●	※	●
2007	Antara-CaptivaShort-Body	ECM (Engine Control Module)	●	●	●	●	●
2007	Antara-CaptivaShort-Body	HVAC (Heating Ventilation Air-conditioning and Cooling)	※	●	●	●	※
2007	Antara-CaptivaShort-Body	IL (Interior Lighting)	※	●	●	●	※
2007	Antara-CaptivaShort-Body	IMMO (Immobiliser)	●	●	●	●	※
2007	Antara-CaptivaShort-Body	IPC (Instrument Control Unit)	●	●	●	●	●
2007	Antara-CaptivaShort-Body	PAS (Park pilot)	●	●	●	●	●
2007	Antara-CaptivaShort-Body	SLM (Shift Lever Module)	●	●	●	●	※
2007	Antara-CaptivaShort-Body	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2007	Antara-CaptivaShort-Body	TCCM (Transfer Case Control Module)	●	●	●	●	※
2007	Antara-CaptivaShort-Body	UHP (Mobile Phone Portal)	●	●	●	※	※
2007	Antara-CaptivaShort-Body	W&W (Wipers/Washer)	※	●	●	●	※
2007	Antara-CaptivaShort-Body	XL/TIS (Exterior Lighting/Turn Indicator System)	※	●	●	●	※
2007	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2007	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
2007	Astra-G	Cruise Control	●	●	●	●	※
2007	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2007	Astra-G	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2007	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2007	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2007	Astra-G	TU (Telematic unit)	●	●	●	※	※
2007	Astra-H	AF 40-6	●	●	●	●	●
2007	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2007	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2007	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2007	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2007	Astra-H	ECM (Engine Control Module)	●	●	●	●	●
2007	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2007	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2007	Astra-H	IC (Instrument Cluster)	●	●	●	●	●
2007	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2007	Astra-H	IMMO (Immobiliser)	●	●	●	●	●

2007	Astra-H	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2007	Astra-H	PAS (Park pilot)	●	●	●	●	●
2007	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2007	Astra-H	SAC (Automatic Climate Control)	●	●	●	●	●
2007	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2007	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2007	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2007	Astra-H	UHP (Mobile Phone Portal)	●	●	●	※	※
2007	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●
2007	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2007	CaptivaLong-Body	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2007	CaptivaLong-Body	ABS/TC/ESP (Vehicle Dynamic System)	●	●	●	●	●
2007	CaptivaLong-Body	BCM (Body Control Module)	●	●	●	●	●
2007	CaptivaLong-Body	ECC (Electronic Climate Control)	●	●	●	※	●
2007	CaptivaLong-Body	ECM (Engine Control Module)	●	●	●	●	●
2007	CaptivaLong-Body	IMMO (Immobiliser)	●	●	●	●	※
2007	CaptivaLong-Body	IPC (Instrument Control Unit)	●	●	●	●	●
2007	CaptivaLong-Body	SDM (Airbag)	●	●	●	※	※
2007	CaptivaLong-Body	TCCM (Transfer Case Control Module)	●	●	●	●	※
2007	Combo	ABS-5.3/5.4(+TC) (Anti-lock Braking System)	※	●	●	●	※
2007	Combo	AF 13-II/17/20/22 CAN	※	●	●	●	●
2007	Combo	AOH (Add On Heater)	※	●	●	●	●
2007	Combo	BCM (Body Control Module)	※	●	●	●	※
2007	Combo	DAB (Digital Audio Broadcast)	●	●	●	※	※
2007	Combo	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2007	Combo	ECM (Engine Control Module)	●	●	●	●	●
2007	Combo	EHU (Entertainment Head Unit)	●	●	●	※	※
2007	Combo	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2007	Combo	IMMO (Immobiliser)	※	●	●	●	※
2007	Combo	UHP (Mobile Phone Portal)	●	●	●	※	※
2007	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2007	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2007	Corsa-C	DAB (Digital Audio Broadcast)	●	●	●	※	※
2007	Corsa-C	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2007	Corsa-C	ECM (Engine Control Module)	●	●	●	●	●
2007	Corsa-C	EHU (Entertainment Head Unit)	●	●	●	※	※
2007	Corsa-C	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2007	Corsa-C	UHP (Mobile Phone Portal)	●	●	●	※	※
2007	Corsa-D	AF 13-4	●	●	●	●	●
2007	Corsa-D	AFL (Adaptive Forward Lighting)	●	●	●	●	●
2007	Corsa-D	DIS (Info Display TID,BID,GID,CID)	●	●	●	●	※
2007	Corsa-D	ECC (Electronic Climate Control)	●	●	●	※	※
2007	Corsa-D	ECM (Engine Control Module)	●	●	●	●	●
2007	Corsa-D	EHS (Electrical Heater System)	●	●	●	●	●
2007	Corsa-D	PAS (Park pilot)	●	●	●	●	●
2007	Corsa-D	TIM (Trailer Interface Module)	●	●	●	●	●
2007	Corsa-D	UHP (Mobile Phone Portal)	●	●	●	※	※
2007	Meriva	AFL (Adaptive Forward Lighting)	●	●	●	※	※
2007	Meriva	AOH (Add On Heater)	※	●	●	●	●
2007	Meriva	DAB (Digital Audio Broadcast)	●	●	●	※	※
2007	Meriva	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2007	Meriva	ECM (Engine Control Module)	●	●	●	●	●
2007	Meriva	EHS (Electrical Heater System)	●	●	●	●	●
2007	Meriva	EHU (Entertainment Head Unit)	●	●	●	※	※
2007	Meriva	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2007	Meriva	UHP (Mobile Phone Portal)	●	●	●	※	※
2007	Movano	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2007	Movano	BCM (Body Control Module)	※	●	●	●	※

2007	Movano	ECM (Engine Control Module)	●	●	●	●	※
2007	Movano	MTA (Tecshift)	●	●	●	●	●
2007	Movano	PP (Park Pilot)	※	●	●	●	※
2007	Movano	PS (Pneumatic Suspension)	●	●	●	●	●
2007	Speedster-VX220	ABS 430 (Anti-lock Braking System)	※	●	●	●	※
2007	Speedster-VX220	ECM (Engine Control Module)	※	●	●	●	※
2007	Speedster-VX220	IMMO (Immobiliser)	※	●	●	●	※
2007	Tigra-B	ABS8/ESP8 (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2007	Tigra-B	BCM (Body Control Module)	※	●	●	●	※
2007	Tigra-B	ECM (Engine Control Module)	※	●	●	●	●
2007	Tigra-B	EHHT (Electrohydraulic HardTop)	●	●	●	●	●
2007	Tigra-B	Easytronic (MTA)	●	●	●	●	※
2007	Tigra-B	IC (Instrument Cluster)	※	●	●	※	●
2007	Tigra-B	IMMO (Immobiliser)	※	●	●	●	※
2007	Tigra-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2007	Tigra-B	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2007	Vauxhall-VXR8	AHL (Automatic Headlamp Levelling)	●	●	●	●	●
2007	Vauxhall-VXR8	AT (Automatic Transmission)	●	●	●	●	●
2007	Vauxhall-VXR8	Audio system	●	●	●	●	※
2007	Vauxhall-VXR8	BCM (Body Control Module)	●	●	●	●	●
2007	Vauxhall-VXR8	Driver information display	●	●	●	●	※
2007	Vauxhall-VXR8	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2007	Vauxhall-VXR8	ESC (Electronic Suspension Control)	●	●	●	●	●
2007	Vauxhall-VXR8	IC (Instrument Cluster)	●	●	●	●	●
2007	Vauxhall-VXR8	IMMO (Immobiliser)	●	●	●	●	※
2007	Vauxhall-VXR8	MSM (Memory Seat And Mirrors)	●	●	●	●	●
2007	Vauxhall-VXR8	PA (Park Assist)	●	●	●	●	●
2007	Vauxhall-VXR8	RFA (Multipurpose Receiver Module)	●	●	●	●	※
2007	Vauxhall-VXR8	SDM (Sensing And Diagnostic Module)	●	●	●	●	※
2007	Vauxhall-VXR8	Telematics	●	●	●	●	※
2007	Vauxhall-VXR8	V8 GEN IV	●	●	●	●	●
2007	Vectra-C-Signum	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2007	Vectra-C-Signum	CVTronic	●	●	●	※	●
2007	Vectra-C-Signum	DAB (Digital Audio Broadcast)	●	●	●	※	※
2007	Vectra-C-Signum	DSM (Driver Seat Module)	●	●	●	●	※
2007	Vectra-C-Signum	Driver information display	●	●	●	●	※
2007	Vectra-C-Signum	ECM (Engine Control Module)	●	●	●	●	●
2007	Vectra-C-Signum	EH (Electrical Horn)	●	●	●	●	●
2007	Vectra-C-Signum	EHS (Electrical Heater System)	●	●	●	●	●
2007	Vectra-C-Signum	ESM/SH (Electronic Seat Memory/Seat Heating)	●	●	●	●	※
2007	Vectra-C-Signum	IL (Interior Lighting)	●	●	●	●	●
2007	Vectra-C-Signum	MTA (Easytronic)	●	●	●	●	●
2007	Vectra-C-Signum	PAS (Park pilot)	●	●	●	●	●
2007	Vectra-C-Signum	SAC (Automatic Climate Control)	●	●	●	●	●
2007	Vectra-C-Signum	SRM (Sun Roof Module)	●	●	●	●	※
2007	Vectra-C-Signum	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2007	Vectra-C-Signum	UHP (Mobile Phone Portal)	●	●	●	※	※
2007	Vivaro	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2007	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2007	Vivaro	BCM (Body Control Module)	●	※	●	●	●
2007	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2007	Vivaro	MTA (Tecshift)	●	●	●	●	●
2007	Vivaro	PP (Park Pilot)	※	●	●	●	※
2007	Vivaro	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2007	Zafira-B	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2007	Zafira-B	ATW (Anti Theft Warning System)	●	●	●	●	●
2007	Zafira-B	CDL (Central Door Lock)	●	●	●	●	●

2007	Zafira-B	DAB (Digital Audio Broadcast)	●	●	●	※	※
2007	Zafira-B	ECM (Engine Control Module)	●	●	●	●	●
2007	Zafira-B	EHS (Electrical Heater System)	●	●	●	●	※
2007	Zafira-B	EPS (Electric Power Steering)	●	●	●	●	※
2007	Zafira-B	IC (Instrument Cluster)	●	●	●	●	●
2007	Zafira-B	IL (Interior Lighting)	●	●	●	●	●
2007	Zafira-B	IMMO (Immobiliser)	●	●	●	●	●
2007	Zafira-B	PAS (Park pilot)	●	●	●	●	●
2007	Zafira-B	PEPS (Open&Start)	●	●	●	●	※
2007	Zafira-B	SAC (Automatic Climate Control)	●	●	●	●	●
2007	Zafira-B	SLM (Shift Lever Module)	●	●	●	●	●
2007	Zafira-B	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2007	Zafira-B	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2007	Zafira-B	UHP (Mobile Phone Portal)	●	●	●	※	※
2007	Zafira-B	W&W (Wipers/Washer)	●	●	●	●	●
2007	Zafira-B	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2008	Agila-B	BCM (Body Control Module)	※	●	●	●	●
2008	Agila-B	ECM (Engine Control Module)	●	●	●	●	●
2008	Agila-B	IMMO (Immobiliser)	●	●	●	●	※
2008	Agila-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2008	Agila-B	TCM (Transmission Control Module)	●	●	●	●	※
2008	Antara-CaptivaShort-Body	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2008	Antara-CaptivaShort-Body	ABS/TC/ESP (Vehicle Dynamic System)	●	●	●	●	●
2008	Antara-CaptivaShort-Body	AHL (Automatic Headlamp Levelling)	●	●	●	●	●
2008	Antara-CaptivaShort-Body	ATW (Anti Theft Warning System)	●	●	●	●	●
2008	Antara-CaptivaShort-Body	BCM (Body Control Module)	●	●	●	●	●
2008	Antara-CaptivaShort-Body	CDL (Central Door Lock)	●	●	●	●	●
2008	Antara-CaptivaShort-Body	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2008	Antara-CaptivaShort-Body	ECC (Electronic Climate Control)	●	●	●	※	●
2008	Antara-CaptivaShort-Body	ECM (Engine Control Module)	●	●	●	●	●
2008	Antara-CaptivaShort-Body	HVAC (Heating Ventilation Air-conditioning and Cooling)	※	●	●	●	※
2008	Antara-CaptivaShort-Body	IL (Interior Lighting)	※	●	●	●	※
2008	Antara-CaptivaShort-Body	IMMO (Immobiliser)	●	●	●	●	※
2008	Antara-CaptivaShort-Body	IPC (Instrument Control Unit)	●	●	●	●	●
2008	Antara-CaptivaShort-Body	PAS (Park pilot)	●	●	●	●	●
2008	Antara-CaptivaShort-Body	SLM (Shift Lever Module)	●	●	●	●	※
2008	Antara-CaptivaShort-Body	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2008	Antara-CaptivaShort-Body	TCCM (Transfer Case Control Module)	●	●	●	●	※
2008	Antara-CaptivaShort-Body	UHP (Mobile Phone Portal)	●	●	●	※	※
2008	Antara-CaptivaShort-Body	W&W (Wipers/Washer)	※	●	●	●	※
2008	Antara-CaptivaShort-Body	XL/TIS (Exterior Lighting/Turn Indicator System)	※	●	●	●	※
2008	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2008	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
2008	Astra-G	Cruise Control	●	●	●	●	※
2008	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2008	Astra-G	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2008	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2008	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2008	Astra-G	TU (Telematic unit)	●	●	●	※	※
2008	Astra-H	AF 40-6	●	●	●	●	●
2008	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2008	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2008	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2008	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2008	Astra-H	ECM (Engine Control Module)	●	●	●	●	●
2008	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2008	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2008	Astra-H	IC (Instrument Cluster)	●	●	●	●	●

2008	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2008	Astra-H	IMMO (Immobiliser)	●	●	●	●	●
2008	Astra-H	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2008	Astra-H	PAS (Park pilot)	●	●	●	●	●
2008	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2008	Astra-H	SAC (Automatic Climate Control)	●	●	●	●	●
2008	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2008	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2008	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2008	Astra-H	UHP (Mobile Phone Portal)	●	●	●	※	※
2008	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●
2008	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2008	CaptivaLong-Body	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2008	CaptivaLong-Body	ABS/TC/ESP (Vehicle Dynamic System)	●	●	●	●	●
2008	CaptivaLong-Body	BCM (Body Control Module)	●	●	●	●	●
2008	CaptivaLong-Body	ECC (Electronic Climate Control)	●	●	●	※	●
2008	CaptivaLong-Body	ECM (Engine Control Module)	●	●	●	●	●
2008	CaptivaLong-Body	IMMO (Immobiliser)	●	●	●	●	※
2008	CaptivaLong-Body	IPC (Instrument Control Unit)	●	●	●	●	●
2008	CaptivaLong-Body	SDM (Airbag)	●	●	●	※	※
2008	CaptivaLong-Body	TCCM (Transfer Case Control Module)	●	●	●	●	※
2008	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2008	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2008	Corsa-C	DAB (Digital Audio Broadcast)	●	●	●	※	※
2008	Corsa-C	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2008	Corsa-C	ECM (Engine Control Module)	●	●	●	●	●
2008	Corsa-C	EHU (Entertainment Head Unit)	●	●	●	※	※
2008	Corsa-C	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2008	Corsa-C	UHP (Mobile Phone Portal)	●	●	●	※	※
2008	Corsa-D	AF 13-4	●	●	●	●	●
2008	Corsa-D	AFL (Adaptive Forward Lighting)	●	●	●	●	●
2008	Corsa-D	DIS (Info Display TID,BID,GID,CID)	●	●	●	●	※
2008	Corsa-D	ECC (Electronic Climate Control)	●	●	●	※	※
2008	Corsa-D	ECM (Engine Control Module)	●	●	●	●	●
2008	Corsa-D	EHS (Electrical Heater System)	●	●	●	●	●
2008	Corsa-D	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2008	Corsa-D	PAS (Park pilot)	●	●	●	●	●
2008	Corsa-D	TIM (Trailer Interface Module)	●	●	●	●	●
2008	Corsa-D	UHP (Mobile Phone Portal)	●	●	●	※	※
2008	Meriva	AFL (Adaptive Forward Lighting)	●	●	●	※	※
2008	Meriva	AOH (Add On Heater)	※	●	●	●	●
2008	Meriva	DAB (Digital Audio Broadcast)	●	●	●	※	※
2008	Meriva	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2008	Meriva	ECM (Engine Control Module)	●	●	●	●	●
2008	Meriva	EHS (Electrical Heater System)	●	●	●	●	●
2008	Meriva	EHU (Entertainment Head Unit)	●	●	●	※	※
2008	Meriva	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2008	Meriva	UHP (Mobile Phone Portal)	●	●	●	※	※
2008	Movano	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2008	Movano	BCM (Body Control Module)	※	●	●	●	※
2008	Movano	ECM (Engine Control Module)	●	●	●	●	※
2008	Movano	MTA (Tecshift)	●	●	●	●	●
2008	Movano	PP (Park Pilot)	※	●	●	●	※
2008	Movano	PS (Pneumatic Suspension)	●	●	●	●	●
2008	Tigra-B	ABS8/ESP8 (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2008	Tigra-B	BCM (Body Control Module)	※	●	●	●	※
2008	Tigra-B	ECM (Engine Control Module)	※	●	●	●	●

2008	Tigra-B	EHHT (Electrohydraulic HardTop)	●	●	●	●	●
2008	Tigra-B	Easytronic (MTA)	●	●	●	●	※
2008	Tigra-B	IC (Instrument Cluster)	※	●	●	※	●
2008	Tigra-B	IMMO (Immobiliser)	※	●	●	●	※
2008	Tigra-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2008	Tigra-B	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2008	Vauxhall-VXR8	AHL (Automatic Headlamp Levelling)	●	●	●	●	●
2008	Vauxhall-VXR8	AT (Automatic Transmission)	●	●	●	●	●
2008	Vauxhall-VXR8	Audio system	●	●	●	●	※
2008	Vauxhall-VXR8	BCM (Body Control Module)	●	●	●	●	●
2008	Vauxhall-VXR8	Driver information display	●	●	●	●	※
2008	Vauxhall-VXR8	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2008	Vauxhall-VXR8	ECM (Engine Control Module)	●	●	●	●	●
2008	Vauxhall-VXR8	ESC (Electronic Suspension Control)	●	●	●	●	●
2008	Vauxhall-VXR8	IC (Instrument Cluster)	●	●	●	●	●
2008	Vauxhall-VXR8	IMMO (Immobiliser)	●	●	●	●	※
2008	Vauxhall-VXR8	MSM (Memory Seat And Mirrors)	●	●	●	●	●
2008	Vauxhall-VXR8	PA (Park Assist)	●	●	●	●	●
2008	Vauxhall-VXR8	RFA (Multipurpose Receiver Module)	●	●	●	●	※
2008	Vauxhall-VXR8	SDM (Sensing And Diagnostic Module)	●	●	●	●	※
2008	Vauxhall-VXR8	Telematics	●	●	●	●	※
2008	Vectra-C-Signum	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2008	Vectra-C-Signum	CVTronic	●	●	●	※	●
2008	Vectra-C-Signum	DAB (Digital Audio Broadcast)	●	●	●	※	※
2008	Vectra-C-Signum	DSM (Driver Seat Module)	●	●	●	●	※
2008	Vectra-C-Signum	Driver information display	●	●	●	●	※
2008	Vectra-C-Signum	ECM (Engine Control Module)	●	●	●	●	●
2008	Vectra-C-Signum	EH (Electrical Horn)	●	●	●	●	●
2008	Vectra-C-Signum	EHS (Electrical Heater System)	●	●	●	●	●
2008	Vectra-C-Signum	ESM/SH (Electronic Seat Memory/Seat Heating)	●	●	●	●	※
2008	Vectra-C-Signum	IL (Interior Lighting)	●	●	●	●	●
2008	Vectra-C-Signum	MTA (Easytronic)	●	●	●	●	●
2008	Vectra-C-Signum	PAS (Park pilot)	●	●	●	●	●
2008	Vectra-C-Signum	SAC (Automatic Climate Control)	●	●	●	●	●
2008	Vectra-C-Signum	SRM (Sun Roof Module)	●	●	●	●	※
2008	Vectra-C-Signum	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2008	Vectra-C-Signum	UHP (Mobile Phone Portal)	●	●	●	※	※
2008	Vivaro	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2008	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2008	Vivaro	BCM (Body Control Module)	●	※	●	●	●
2008	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2008	Vivaro	MTA (Tecshift)	●	●	●	●	●
2008	Vivaro	PP (Park Pilot)	※	●	●	●	※
2008	Vivaro	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2008	Zafira-B	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2008	Zafira-B	ATW (Anti Theft Warning System)	●	●	●	●	●
2008	Zafira-B	CDL (Central Door Lock)	●	●	●	●	●
2008	Zafira-B	DAB (Digital Audio Broadcast)	●	●	●	※	※
2008	Zafira-B	ECM (Engine Control Module)	●	●	●	●	●
2008	Zafira-B	EHS (Electrical Heater System)	●	●	●	●	※
2008	Zafira-B	EPS (Electric Power Steering)	●	●	●	●	※
2008	Zafira-B	IC (Instrument Cluster)	●	●	●	●	●
2008	Zafira-B	IL (Interior Lighting)	●	●	●	●	●
2008	Zafira-B	IMMO (Immobiliser)	●	●	●	●	●
2008	Zafira-B	PEPS (Open&Start)	●	●	●	●	※
2008	Zafira-B	SAC (Automatic Climate Control)	●	●	●	●	●
2008	Zafira-B	SLM (Shift Lever Module)	●	●	●	●	●
2008	Zafira-B	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※

2008	Zafira-B	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2008	Zafira-B	UHP (Mobile Phone Portal)	●	●	●	※	※
2008	Zafira-B	W&W (Wipers/Washer)	●	●	●	●	●
2008	Zafira-B	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2009	Agila-B	BCM (Body Control Module)	※	●	●	●	●
2009	Agila-B	ECM (Engine Control Module)	●	●	●	●	●
2009	Agila-B	IMMO (Immobiliser)	●	●	●	●	※
2009	Agila-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2009	Agila-B	TCM (Transmission Control Module)	●	●	●	●	※
2009	Antara-CaptivaShort-Body	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2009	Antara-CaptivaShort-Body	ABS/TC/ESP (Vehicle Dynamic System)	●	●	●	●	●
2009	Antara-CaptivaShort-Body	AHL (Automatic Headlamp Levelling)	●	●	●	●	●
2009	Antara-CaptivaShort-Body	ATW (Anti Theft Warning System)	●	●	●	●	●
2009	Antara-CaptivaShort-Body	BCM (Body Control Module)	●	●	●	●	●
2009	Antara-CaptivaShort-Body	CDL (Central Door Lock)	●	●	●	●	●
2009	Antara-CaptivaShort-Body	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2009	Antara-CaptivaShort-Body	ECC (Electronic Climate Control)	●	●	●	※	●
2009	Antara-CaptivaShort-Body	ECM (Engine Control Module)	●	●	●	●	●
2009	Antara-CaptivaShort-Body	HVAC (Heating Ventilation Air-conditioning and Cooling)	※	●	●	●	※
2009	Antara-CaptivaShort-Body	IL (Interior Lighting)	※	●	●	●	※
2009	Antara-CaptivaShort-Body	IMMO (Immobiliser)	●	●	●	●	※
2009	Antara-CaptivaShort-Body	IPC (Instrument Control Unit)	●	●	●	●	●
2009	Antara-CaptivaShort-Body	PAS (Park pilot)	●	●	●	●	●
2009	Antara-CaptivaShort-Body	SLM (Shift Lever Module)	●	●	●	●	※
2009	Antara-CaptivaShort-Body	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2009	Antara-CaptivaShort-Body	TCCM (Transfer Case Control Module)	●	●	●	●	※
2009	Antara-CaptivaShort-Body	UHP (Mobile Phone Portal)	●	●	●	※	※
2009	Antara-CaptivaShort-Body	W&W (Wipers/Washer)	※	●	●	●	※
2009	Antara-CaptivaShort-Body	XL/TIS (Exterior Lighting/Turn Indicator System)	※	●	●	●	※
2009	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2009	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
2009	Astra-G	Cruise Control	●	●	●	●	※
2009	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2009	Astra-G	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2009	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2009	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2009	Astra-G	TU (Telematic unit)	●	●	●	※	※
2009	Astra-H	AF 40-6	●	●	●	●	●
2009	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2009	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2009	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2009	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2009	Astra-H	ECM (Engine Control Module)	●	●	●	●	●
2009	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2009	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2009	Astra-H	IC (Instrument Cluster)	●	●	●	●	●
2009	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2009	Astra-H	IMMO (Immobiliser)	●	●	●	●	●
2009	Astra-H	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2009	Astra-H	PAS (Park pilot)	●	●	●	●	●
2009	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2009	Astra-H	SAC (Automatic Climate Control)	●	●	●	●	●
2009	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2009	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2009	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2009	Astra-H	UHP (Mobile Phone Portal)	●	●	●	※	※
2009	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●
2009	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●

2009	CaptivaLong-Body	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2009	CaptivaLong-Body	ABS/TC/ESP (Vehicle Dynamic System)	●	●	●	●	●
2009	CaptivaLong-Body	BCM (Body Control Module)	●	●	●	●	●
2009	CaptivaLong-Body	ECC (Electronic Climate Control)	●	●	●	※	●
2009	CaptivaLong-Body	ECM (Engine Control Module)	●	●	●	●	●
2009	CaptivaLong-Body	IMMO (Immobiliser)	●	●	●	●	※
2009	CaptivaLong-Body	IPC (Instrument Control Unit)	●	●	●	●	●
2009	CaptivaLong-Body	SDM (Airbag)	●	●	●	※	※
2009	CaptivaLong-Body	TCCM (Transfer Case Control Module)	●	●	●	●	※
2009	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2009	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2009	Corsa-C	DAB (Digital Audio Broadcast)	●	●	●	※	※
2009	Corsa-C	DIS (Info Display TID,BID,GID,CID)	●	●	●	※	※
2009	Corsa-C	ECM (Engine Control Module)	●	●	●	●	●
2009	Corsa-C	EHU (Entertainment Head Unit)	●	●	●	※	※
2009	Corsa-C	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2009	Corsa-C	UHP (Mobile Phone Portal)	●	●	●	※	※
2009	Corsa-D	AF 13-4	●	●	●	●	●
2009	Corsa-D	AFL (Adaptive Forward Lighting)	●	●	●	●	●
2009	Corsa-D	DIS (Info Display TID,BID,GID,CID)	●	●	●	●	※
2009	Corsa-D	ECC (Electronic Climate Control)	●	●	●	※	※
2009	Corsa-D	ECM (Engine Control Module)	●	●	●	●	●
2009	Corsa-D	EHS (Electrical Heater System)	●	●	●	●	●
2009	Corsa-D	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2009	Corsa-D	PAS (Park pilot)	●	●	●	●	●
2009	Corsa-D	TIM (Trailer Interface Module)	●	●	●	●	●
2009	Corsa-D	UHP (Mobile Phone Portal)	●	●	●	※	※
2009	Insignia	BCM (Body Control Module)	●	●	●	●	●
2009	Insignia	CACM (Chime Alarm Control Module)	●	●	●	※	●
2009	Insignia	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2009	Insignia	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2009	Insignia	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2009	Insignia	ECM (Engine Control Module)	●	●	●	●	●
2009	Insignia	FICM (Fuel Injector Control Module)	●	※	※	●	●
2009	Insignia	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2009	Insignia	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2009	Insignia	HCM (Headlamp Control Module)	●	●	●	●	●
2009	Insignia	IC (Instrument Cluster)	●	●	●	●	●
2009	Insignia	LCM (Liftgate Control Module)	●	●	●	●	※
2009	Insignia	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2009	Insignia	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2009	Insignia	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2009	Insignia	PACM (Parking Assist Control Module)	●	●	●	●	●
2009	Insignia	PBCM (Parking Brake Control Module)	●	●	●	●	●
2009	Insignia	PSCM (Power Steering Control Module)	●	●	●	●	●
2009	Insignia	RADIO (Radio)	●	●	●	●	●
2009	Insignia	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2009	Insignia	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2009	Insignia	SCM (Suspension Control Module)	●	●	●	●	●
2009	Insignia	SMCM (Seat Memory Control Module)	●	●	●	●	●
2009	Insignia	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2009	Insignia	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2009	Insignia	TCM (Transmission Control Module)	●	●	●	●	●
2009	Insignia	TICM (Trailer Interface Control Module)	●	●	●	●	●
2009	Insignia	VDCCM (Vehicle Direction Camera Control Module)	●	●	●	●	●
2009	Meriva	AFL (Adaptive Forward Lighting)	●	●	●	※	※
2009	Meriva	AOH (Add On Heater)	※	●	●	●	●

2009	Meriva	DAB (Digital Audio Broadcast)	●	●	●	※	※
2009	Meriva	DIS (Info Display TID, BID, GID, CID)	●	●	●	※	※
2009	Meriva	ECM (Engine Control Module)	●	●	●	●	●
2009	Meriva	EHS (Electrical Heater System)	●	●	●	●	●
2009	Meriva	EHU (Entertainment Head Unit)	●	●	●	※	※
2009	Meriva	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2009	Meriva	UHP (Mobile Phone Portal)	●	●	●	※	※
2009	Movano	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2009	Movano	BCM (Body Control Module)	※	●	●	●	※
2009	Movano	ECM (Engine Control Module)	●	●	●	●	※
2009	Movano	MTA (Tecshift)	●	●	●	●	●
2009	Movano	PP (Park Pilot)	※	●	●	●	※
2009	Movano	PS (Pneumatic Suspension)	●	●	●	●	●
2009	Tigra-B	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2009	Tigra-B	BCM (Body Control Module)	※	●	●	●	※
2009	Tigra-B	ECM (Engine Control Module)	※	●	●	●	●
2009	Tigra-B	EHHT (Electrohydraulic HardTop)	●	●	●	●	●
2009	Tigra-B	Easytronic (MTA)	●	●	●	●	※
2009	Tigra-B	IC (Instrument Cluster)	※	●	●	※	●
2009	Tigra-B	IMMO (Immobiliser)	※	●	●	●	※
2009	Tigra-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2009	Tigra-B	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2009	Vauxhall-VXR8	AHL (Automatic Headlamp Levelling)	●	●	●	●	●
2009	Vauxhall-VXR8	AT (Automatic Transmission)	●	●	●	●	●
2009	Vauxhall-VXR8	Audio system	●	●	●	●	※
2009	Vauxhall-VXR8	BCM (Body Control Module)	●	●	●	●	●
2009	Vauxhall-VXR8	Driver information display	●	●	●	●	※
2009	Vauxhall-VXR8	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2009	Vauxhall-VXR8	ECM (Engine Control Module)	●	●	●	●	●
2009	Vauxhall-VXR8	ESC (Electronic Suspension Control)	●	●	●	●	●
2009	Vauxhall-VXR8	IC (Instrument Cluster)	●	●	●	●	●
2009	Vauxhall-VXR8	IMMO (Immobiliser)	●	●	●	●	※
2009	Vauxhall-VXR8	MSM (Memory Seat And Mirrors)	●	●	●	●	●
2009	Vauxhall-VXR8	PA (Park Assist)	●	●	●	●	●
2009	Vauxhall-VXR8	RFA (Multipurpose Receiver Module)	●	●	●	●	※
2009	Vauxhall-VXR8	SDM (Sensing And Diagnostic Module)	●	●	●	●	※
2009	Vauxhall-VXR8	Telematics	●	●	●	●	※
2009	Vivaro	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2009	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2009	Vivaro	BCM (Body Control Module)	●	※	●	●	●
2009	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2009	Vivaro	MTA (Tecshift)	●	●	●	●	●
2009	Vivaro	PP (Park Pilot)	※	●	●	●	※
2009	Vivaro	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2009	Zafira-B	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2009	Zafira-B	ATW (Anti Theft Warning System)	●	●	●	●	●
2009	Zafira-B	CDL (Central Door Lock)	●	●	●	●	●
2009	Zafira-B	DAB (Digital Audio Broadcast)	●	●	●	※	※
2009	Zafira-B	ECM (Engine Control Module)	●	●	●	●	●
2009	Zafira-B	EHS (Electrical Heater System)	●	●	●	●	※
2009	Zafira-B	EPS (Electric Power Steering)	●	●	●	●	※
2009	Zafira-B	IC (Instrument Cluster)	●	●	●	●	●
2009	Zafira-B	IL (Interior Lighting)	●	●	●	●	●
2009	Zafira-B	IMMO (Immobiliser)	●	●	●	●	●
2009	Zafira-B	PEPS (Open&Start)	●	●	●	●	※
2009	Zafira-B	SAC (Automatic Climate Control)	●	●	●	●	●
2009	Zafira-B	SLM (Shift Lever Module)	●	●	●	●	●

2009	Zafira-B	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2009	Zafira-B	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2009	Zafira-B	UHP (Mobile Phone Portal)	●	●	●	※	※
2009	Zafira-B	W&W (Wipers/Washer)	●	●	●	●	●
2009	Zafira-B	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2010	Agila-B	BCM (Body Control Module)	※	●	●	●	●
2010	Agila-B	ECM (Engine Control Module)	●	●	●	●	●
2010	Agila-B	IMMO (Immobiliser)	●	●	●	●	※
2010	Agila-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2010	Agila-B	TCM (Transmission Control Module)	●	●	●	●	※
2010	Antara-CaptivaShort-Body	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2010	Antara-CaptivaShort-Body	ABS/TC/ESP (Vehicle Dynamic System)	●	●	●	●	●
2010	Antara-CaptivaShort-Body	AHL (Automatic Headlamp Levelling)	●	●	●	●	●
2010	Antara-CaptivaShort-Body	ATW (Anti Theft Warning System)	●	●	●	●	●
2010	Antara-CaptivaShort-Body	BCM (Body Control Module)	●	●	●	●	●
2010	Antara-CaptivaShort-Body	CDL (Central Door Lock)	●	●	●	●	●
2010	Antara-CaptivaShort-Body	DIS (Info Display TID, BID, GID, CID)	●	●	●	※	※
2010	Antara-CaptivaShort-Body	ECC (Electronic Climate Control)	●	●	●	※	●
2010	Antara-CaptivaShort-Body	ECM (Engine Control Module)	●	●	●	●	●
2010	Antara-CaptivaShort-Body	HVAC (Heating Ventilation Air-conditioning and Cooling)	※	●	●	●	※
2010	Antara-CaptivaShort-Body	IL (Interior Lighting)	※	●	●	●	※
2010	Antara-CaptivaShort-Body	IMMO (Immobiliser)	●	●	●	●	※
2010	Antara-CaptivaShort-Body	IPC (Instrument Control Unit)	●	●	●	●	●
2010	Antara-CaptivaShort-Body	PAS (Park pilot)	●	●	●	●	●
2010	Antara-CaptivaShort-Body	SLM (Shift Lever Module)	●	●	●	●	※
2010	Antara-CaptivaShort-Body	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2010	Antara-CaptivaShort-Body	TCCM (Transfer Case Control Module)	●	●	●	●	※
2010	Antara-CaptivaShort-Body	UHP (Mobile Phone Portal)	●	●	●	※	※
2010	Antara-CaptivaShort-Body	W&W (Wipers/Washer)	※	●	●	●	※
2010	Antara-CaptivaShort-Body	XL/TIS (Exterior Lighting/Turn Indicator System)	※	●	●	●	※
2010	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2010	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
2010	Astra-G	Cruise Control	●	●	●	●	※
2010	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2010	Astra-G	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2010	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2010	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2010	Astra-G	TU (Telematic unit)	●	●	●	※	※
2010	Astra-H	AF 40-6	●	●	●	●	●
2010	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2010	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2010	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2010	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2010	Astra-H	ECM (Engine Control Module)	●	●	●	●	●
2010	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2010	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2010	Astra-H	IC (Instrument Cluster)	●	●	●	●	●
2010	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2010	Astra-H	IMMO (Immobiliser)	●	●	●	●	●
2010	Astra-H	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2010	Astra-H	PAS (Park pilot)	●	●	●	●	●
2010	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2010	Astra-H	SAC (Automatic Climate Control)	●	●	●	●	●
2010	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2010	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2010	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2010	Astra-H	UHP (Mobile Phone Portal)	●	●	●	※	※
2010	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●

2010	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2010	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2010	Astra-J	CACM (Chime Alarm Control Module)	●	●	●	※	●
2010	Astra-J	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2010	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2010	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2010	Astra-J	FICM (Fuel Injector Control Module)	●	※	※	●	●
2010	Astra-J	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2010	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2010	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2010	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2010	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2010	Astra-J	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2010	Astra-J	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2010	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2010	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2010	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	※
2010	Astra-J	RADIO (Radio)	●	●	●	●	●
2010	Astra-J	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2010	Astra-J	SCM (Suspension Control Module)	●	●	●	●	●
2010	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2010	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2010	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●
2010	Astra-J	TICM (Trailer Interface Control Module)	●	●	●	●	●
2010	Astra-J	VDCCM (Vehicle Direction Camera Control Module)	●	●	●	●	●
2010	CaptivaLong-Body	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2010	CaptivaLong-Body	ABS/TC/ESP (Vehicle Dynamic System)	●	●	●	●	●
2010	CaptivaLong-Body	BCM (Body Control Module)	●	●	●	●	●
2010	CaptivaLong-Body	ECC (Electronic Climate Control)	●	●	●	※	●
2010	CaptivaLong-Body	ECM (Engine Control Module)	●	●	●	●	●
2010	CaptivaLong-Body	IMMO (Immobiliser)	●	●	●	●	※
2010	CaptivaLong-Body	IPC (Instrument Control Unit)	●	●	●	●	●
2010	CaptivaLong-Body	SDM (Airbag)	●	●	●	※	※
2010	CaptivaLong-Body	TCCM (Transfer Case Control Module)	●	●	●	●	※
2010	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2010	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2010	Corsa-C	DAB (Digital Audio Broadcast)	●	●	●	※	※
2010	Corsa-C	DIS (Info Display TID, BID, GID, CID)	●	●	●	※	※
2010	Corsa-C	ECM (Engine Control Module)	●	●	●	●	●
2010	Corsa-C	EHU (Entertainment Head Unit)	●	●	●	※	※
2010	Corsa-C	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2010	Corsa-C	UHP (Mobile Phone Portal)	●	●	●	※	※
2010	Corsa-D	AF 13-4	●	●	●	●	●
2010	Corsa-D	AFL (Adaptive Forward Lighting)	●	●	●	●	●
2010	Corsa-D	DIS (Info Display TID, BID, GID, CID)	●	●	●	●	※
2010	Corsa-D	ECC (Electronic Climate Control)	●	●	●	※	※
2010	Corsa-D	ECM (Engine Control Module)	●	●	●	●	●
2010	Corsa-D	EHS (Electrical Heater System)	●	●	●	●	●
2010	Corsa-D	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2010	Corsa-D	MTA (Easytronic)	●	●	●	●	●
2010	Corsa-D	PAS (Park pilot)	●	●	●	●	●
2010	Corsa-D	TIM (Trailer Interface Module)	●	●	●	●	●
2010	Corsa-D	UHP (Mobile Phone Portal)	●	●	●	※	※
2010	Insignia	BCM (Body Control Module)	●	●	●	●	●
2010	Insignia	CACM (Chime Alarm Control Module)	●	●	●	※	●
2010	Insignia	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2010	Insignia	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※

2010	Insignia	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2010	Insignia	ECM (Engine Control Module)	●	●	●	●	●
2010	Insignia	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2010	Insignia	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2010	Insignia	HCM (Headlamp Control Module)	●	●	●	●	●
2010	Insignia	IC (Instrument Cluster)	●	●	●	●	●
2010	Insignia	LCM (Liftgate Control Module)	●	●	●	●	※
2010	Insignia	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2010	Insignia	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2010	Insignia	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2010	Insignia	PACM (Parking Assist Control Module)	●	●	●	●	●
2010	Insignia	PBCM (Parking Brake Control Module)	●	●	●	●	●
2010	Insignia	PSCM (Power Steering Control Module)	●	●	●	●	●
2010	Insignia	RADIO (Radio)	●	●	●	●	●
2010	Insignia	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2010	Insignia	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2010	Insignia	SCM (Suspension Control Module)	●	●	●	●	●
2010	Insignia	SMCM (Seat Memory Control Module)	●	●	●	●	●
2010	Insignia	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2010	Insignia	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2010	Insignia	TCM (Transmission Control Module)	●	●	●	●	●
2010	Insignia	TICM (Trailer Interface Control Module)	●	●	●	●	●
2010	Insignia	VDCCM (Vehicle Direction Camera Control Module)	●	●	●	●	●
2010	Meriva	AFL (Adaptive Forward Lighting)	●	●	●	※	※
2010	Meriva	AOH (Add On Heater)	※	●	●	●	●
2010	Meriva	DAB (Digital Audio Broadcast)	●	●	●	※	※
2010	Meriva	DIS (Info Display TID, BID, GID, CID)	●	●	●	※	※
2010	Meriva	ECM (Engine Control Module)	●	●	●	●	●
2010	Meriva	EHS (Electrical Heater System)	●	●	●	●	●
2010	Meriva	EHU (Entertainment Head Unit)	●	●	●	※	※
2010	Meriva	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2010	Meriva	UHP (Mobile Phone Portal)	●	●	●	※	※
2010	Meriva-B	DRCM (Digital Radio Control Module)	●	●	●	※	※
2010	Meriva-B	ECM (Engine Control Module)	●	●	●	●	●
2010	Meriva-B	EPS (Electric Power Steering)	●	●	●	●	●
2010	Meriva-B	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2010	Meriva-B	HLCM (Headlamp Control Module)	●	●	●	●	●
2010	Meriva-B	IC (Instrument Cluster)	●	●	●	●	●
2010	Meriva-B	MPIM (Multimedia player interface module)	●	●	●	※	※
2010	Meriva-B	MTCM (Mobile Telephone Control Module)	●	●	●	※	※
2010	Meriva-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2010	Meriva-B	PBCM (Parking Brake Control Module)	●	●	●	●	●
2010	Meriva-B	R&C (Radio / Chime Alarm Control Module)	●	●	●	●	※
2010	Meriva-B	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2010	Meriva-B	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	●
2010	Meriva-B	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2010	Meriva-B	TICM (Trailer Interface Control Module)	●	●	●	●	●
2010	Movano	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2010	Movano	BCM (Body Control Module)	※	●	●	●	※
2010	Movano	ECM (Engine Control Module)	●	●	●	●	※
2010	Movano	MTA (Tecshift)	●	●	●	●	●
2010	Movano	PP (Park Pilot)	※	●	●	●	※
2010	Movano	PS (Pneumatic Suspension)	●	●	●	●	●
2010	Movano-B	CIM (CAN Interface Module)	●	●	●	●	※
2010	Movano-B	ECM (Engine Control Module)	●	●	●	●	●
2010	Movano-B	HLCM (Headlamp Control Module)	●	●	●	●	※

2010	Movano-B	RHACCM (Remote Heater and Air Conditioning Control Module 2)	※	●	●	●	※
2010	Movano-B	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	※
2010	Movano-B	Radio	●	●	●	※	※
2010	Movano-B	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	※
2010	Vivaro	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	※	●	●	●	※
2010	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2010	Vivaro	BCM (Body Control Module)	●	※	●	●	●
2010	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2010	Vivaro	MTA (Tecshift)	●	●	●	●	●
2010	Vivaro	PP (Park Pilot)	※	●	●	●	※
2010	Vivaro	SRS (Supplemental Inflatable Restraint System)	※	●	●	●	※
2010	Zafira-B	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2010	Zafira-B	ATW (Anti Theft Warning System)	●	●	●	●	●
2010	Zafira-B	CDL (Central Door Lock)	●	●	●	●	●
2010	Zafira-B	DAB (Digital Audio Broadcast)	●	●	●	※	※
2010	Zafira-B	ECM (Engine Control Module)	●	●	●	●	●
2010	Zafira-B	EHS (Electrical Heater System)	●	●	●	●	※
2010	Zafira-B	EPS (Electric Power Steering)	●	●	●	●	※
2010	Zafira-B	IC (Instrument Cluster)	●	●	●	●	●
2010	Zafira-B	IL (Interior Lighting)	●	●	●	●	●
2010	Zafira-B	IMMO (Immobiliser)	●	●	●	●	●
2010	Zafira-B	PEPS (Open&Start)	●	●	●	●	※
2010	Zafira-B	SAC (Automatic Climate Control)	●	●	●	●	●
2010	Zafira-B	SLM (Shift Lever Module)	●	●	●	●	●
2010	Zafira-B	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2010	Zafira-B	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2010	Zafira-B	UHP (Mobile Phone Portal)	●	●	●	※	※
2010	Zafira-B	W&W (Wipers/Washer)	●	●	●	●	●
2010	Zafira-B	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2011	Agila-B	BCM (Body Control Module)	※	●	●	●	●
2011	Agila-B	ECM (Engine Control Module)	●	●	●	●	●
2011	Agila-B	IMMO (Immobiliser)	●	●	●	●	※
2011	Agila-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2011	Agila-B	S&S (Stop/Start System)	●	●	●	●	※
2011	Agila-B	TCM (Transmission Control Module)	●	●	●	●	※
2011	Antara	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2011	Antara	BCM (Body Control Module)	●	●	●	●	●
2011	Antara	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2011	Antara	ECM (Engine Control Module)	●	●	●	●	●
2011	Antara	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2011	Antara	HCM (Headlamp Control Module)	●	●	●	●	●
2011	Antara	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	※	●
2011	Antara	IC (Instrument Cluster)	●	●	●	●	●
2011	Antara	IDM (Info Display Module)	●	●	●	●	●
2011	Antara	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2011	Antara	PACM (Parking Assist Control Module)	●	●	●	※	●
2011	Antara	PBCM (Parking Brake Control Module)	●	●	●	●	●
2011	Antara	RADIO (Radio)	●	●	●	●	●
2011	Antara	RCDLR (Remote Control Door Lock Receiver)	●	●	●	●	●
2011	Antara	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2011	Antara	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2011	Antara	TCM (Transmission Control Module)	●	●	●	●	●
2011	Antara	TDM (Theft Deterrent Module)	●	●	●	●	※
2011	Antara	VPSCM (Variable Power Steering Control Module)	※	●	●	※	●
2011	Antara-CaptivaShort-Body	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2011	Antara-CaptivaShort-Body	ABS/TC/ESP (Vehicle Dynamic System)	●	●	●	●	●

2011	Antara-CaptivaShort-Body	AHL (Automatic Headlamp Levelling)	●	●	●	●	●
2011	Antara-CaptivaShort-Body	BCM (Body Control Module)	●	●	●	●	●
2011	Antara-CaptivaShort-Body	ECC (Electronic Climate Control)	●	●	●	※	●
2011	Antara-CaptivaShort-Body	ECM (Engine Control Module)	●	●	●	●	●
2011	Antara-CaptivaShort-Body	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2011	Antara-CaptivaShort-Body	IMMO (Immobiliser)	●	●	●	●	※
2011	Antara-CaptivaShort-Body	IPC (Instrument Control Unit)	●	●	●	●	●
2011	Antara-CaptivaShort-Body	PAS (Park pilot)	●	●	●	●	●
2011	Antara-CaptivaShort-Body	PBCM (Parking Brake Control Module)	●	●	●	●	●
2011	Antara-CaptivaShort-Body	RFA (Multipurpose Receiver Module)	●	●	●	●	※
2011	Antara-CaptivaShort-Body	TCCM (Transfer Case Control Module)	●	●	●	●	※
2011	Astra-G	AOH (Add On Heater)	※	●	●	●	●
2011	Astra-G	CDL (Central Door Lock)	※	●	●	※	●
2011	Astra-G	Cruise Control	●	●	●	●	※
2011	Astra-G	ECM (Engine Control Module)	●	●	●	●	●
2011	Astra-G	HLD (HeadLamp Levelling Device)	※	●	●	●	●
2011	Astra-G	Info Display CART/CCRT	●	●	●	●	※
2011	Astra-G	PSCM (Power Steering Control Module)	※	●	●	●	●
2011	Astra-G	TU (Telematic unit)	●	●	●	※	※
2011	Astra-H	AF 40-6	●	●	●	●	●
2011	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2011	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2011	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2011	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2011	Astra-H	ECM (Engine Control Module)	●	●	●	●	●
2011	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2011	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2011	Astra-H	IC (Instrument Cluster)	●	●	●	●	●
2011	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2011	Astra-H	IMMO (Immobiliser)	●	●	●	●	●
2011	Astra-H	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2011	Astra-H	PAS (Park pilot)	●	●	●	●	●
2011	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2011	Astra-H	SAC (Automatic Climate Control)	●	●	●	●	●
2011	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2011	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2011	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2011	Astra-H	UHP (Mobile Phone Portal)	●	●	●	※	※
2011	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●
2011	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2011	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2011	Astra-J	CACM (Chime Alarm Control Module)	●	●	●	※	●
2011	Astra-J	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2011	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2011	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2011	Astra-J	FICM (Fuel Injector Control Module)	●	※	※	●	●
2011	Astra-J	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2011	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2011	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2011	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2011	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2011	Astra-J	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2011	Astra-J	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2011	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2011	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2011	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	※
2011	Astra-J	RADIO (Radio)	●	●	●	●	●
2011	Astra-J	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●

2011	Astra-J	SCM (Suspension Control Module)	●	●	●	●	●
2011	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2011	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2011	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●
2011	Astra-J	TICM (Trailer Interface Control Module)	●	●	●	●	●
2011	Astra-J	VDCCM (Vehicle Direction Camera Control Module)	●	●	●	●	●
2011	CaptivaLong-Body	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2011	CaptivaLong-Body	ABS/TC/ESP (Vehicle Dynamic System)	●	●	●	●	●
2011	CaptivaLong-Body	AT (Automatic Transmission)	●	●	●	●	●
2011	CaptivaLong-Body	BCM (Body Control Module)	●	●	●	●	●
2011	CaptivaLong-Body	ECC (Electronic Climate Control)	●	●	●	※	●
2011	CaptivaLong-Body	ECM (Engine Control Module)	●	●	●	●	●
2011	CaptivaLong-Body	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2011	CaptivaLong-Body	IMMO (Immobiliser)	●	●	●	●	※
2011	CaptivaLong-Body	IPC (Instrument Control Unit)	●	●	●	●	●
2011	CaptivaLong-Body	PAS (Park pilot)	●	●	●	●	●
2011	CaptivaLong-Body	RFA (Multipurpose Receiver Module)	●	●	●	●	※
2011	CaptivaLong-Body	TCCM (Transfer Case Control Module)	●	●	●	●	※
2011	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2011	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2011	Corsa-C	DAB (Digital Audio Broadcast)	●	●	●	※	※
2011	Corsa-C	DIS (Info Display TID, BID, GID, CID)	●	●	●	※	※
2011	Corsa-C	ECM (Engine Control Module)	●	●	●	●	●
2011	Corsa-C	EHU (Entertainment Head Unit)	●	●	●	※	※
2011	Corsa-C	HLD (HeadLamp Levelling Device)	●	●	●	●	●
2011	Corsa-C	UHP (Mobile Phone Portal)	●	●	●	※	※
2011	Corsa-D	AF 13-4	●	●	●	●	●
2011	Corsa-D	AFL (Adaptive Forward Lighting)	●	●	●	●	●
2011	Corsa-D	DIS (Info Display TID, BID, GID, CID)	●	●	●	●	※
2011	Corsa-D	ECC (Electronic Climate Control)	●	●	●	※	※
2011	Corsa-D	ECM (Engine Control Module)	●	●	●	●	●
2011	Corsa-D	EHS (Electrical Heater System)	●	●	●	●	●
2011	Corsa-D	FICM (Fuel Injector Control Module)	●	●	●	●	●
2011	Corsa-D	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2011	Corsa-D	PAS (Park pilot)	●	●	●	●	●
2011	Corsa-D	S&S (Stop/Start System)	●	●	●	※	※
2011	Corsa-D	TIM (Trailer Interface Module)	●	●	●	●	●
2011	Corsa-D	UHP (Mobile Phone Portal)	●	●	●	※	※
2011	Insignia	BCM (Body Control Module)	●	●	●	●	●
2011	Insignia	CACM (Chime Alarm Control Module)	●	●	●	※	●
2011	Insignia	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2011	Insignia	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2011	Insignia	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2011	Insignia	ECM (Engine Control Module)	●	●	●	●	●
2011	Insignia	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2011	Insignia	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2011	Insignia	HCM (Headlamp Control Module)	●	●	●	●	●
2011	Insignia	IC (Instrument Cluster)	●	●	●	●	●
2011	Insignia	LCM (Liftgate Control Module)	●	●	●	●	※
2011	Insignia	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2011	Insignia	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2011	Insignia	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2011	Insignia	PACM (Parking Assist Control Module)	●	●	●	●	●
2011	Insignia	PBCM (Parking Brake Control Module)	●	●	●	●	●
2011	Insignia	PSCM (Power Steering Control Module)	●	●	●	●	●
2011	Insignia	RADIO (Radio)	●	●	●	●	●
2011	Insignia	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●

2011	Insignia	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2011	Insignia	SCM (Suspension Control Module)	●	●	●	●	●
2011	Insignia	SMCM (Seat Memory Control Module)	●	●	●	●	●
2011	Insignia	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2011	Insignia	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2011	Insignia	TCM (Transmission Control Module)	●	●	●	●	●
2011	Insignia	TICM (Trailer Interface Control Module)	●	●	●	●	●
2011	Insignia	VDCCM (Vehicle Direction Camera Control Module)	●	●	●	●	●
2011	Meriva-B	DRCM (Digital Radio Control Module)	●	●	●	※	※
2011	Meriva-B	ECM (Engine Control Module)	●	●	●	●	●
2011	Meriva-B	EPS (Electric Power Steering)	●	●	●	●	●
2011	Meriva-B	FICM (Fuel Injector Control Module)	●	●	●	●	●
2011	Meriva-B	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2011	Meriva-B	HLCM (Headlamp Control Module)	●	●	●	●	●
2011	Meriva-B	IC (Instrument Cluster)	●	●	●	●	●
2011	Meriva-B	MPIM (Multimedia player interface module)	●	●	●	※	※
2011	Meriva-B	MTCM (Mobile Telephone Control Module)	●	●	●	※	※
2011	Meriva-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2011	Meriva-B	PBCM (Parking Brake Control Module)	●	●	●	●	●
2011	Meriva-B	R&C (Radio / Chime Alarm Control Module)	●	●	●	●	※
2011	Meriva-B	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2011	Meriva-B	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	●
2011	Meriva-B	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2011	Meriva-B	TICM (Trailer Interface Control Module)	●	●	●	●	●
2011	Movano-B	CIM (CAN Interface Module)	●	●	●	●	※
2011	Movano-B	ECM (Engine Control Module)	●	●	●	●	●
2011	Movano-B	HLCM (Headlamp Control Module)	●	●	●	●	※
2011	Movano-B	RHACCM (Remote Heater and Air Conditioning Control Module 2)	※	●	●	●	※
2011	Movano-B	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	※
2011	Movano-B	Radio	●	●	●	※	※
2011	Movano-B	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	※
2011	Vauxhall-VXR8	AHL (Automatic Headlamp Levelling)	●	●	●	●	●
2011	Vauxhall-VXR8	AT (Automatic Transmission)	●	●	●	●	●
2011	Vauxhall-VXR8	Audio system	●	●	●	●	※
2011	Vauxhall-VXR8	BCM (Body Control Module)	●	●	●	●	●
2011	Vauxhall-VXR8	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2011	Vauxhall-VXR8	ECM (Engine Control Module)	●	●	●	●	●
2011	Vauxhall-VXR8	ESC (Electronic Suspension Control)	●	●	●	●	●
2011	Vauxhall-VXR8	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2011	Vauxhall-VXR8	IC (Instrument Cluster)	●	●	●	●	●
2011	Vauxhall-VXR8	IMMO (Immobiliser)	●	●	●	●	※
2011	Vauxhall-VXR8	MSM (Memory Seat And Mirrors)	●	●	●	●	●
2011	Vauxhall-VXR8	PA (Park Assist)	●	●	●	●	●
2011	Vauxhall-VXR8	RFA (Multipurpose Receiver Module)	●	●	●	●	※
2011	Vauxhall-VXR8	RSE (rear seat entertainment)	●	●	●	●	※
2011	Vauxhall-VXR8	SDM (Sensing And Diagnostic Module)	●	●	●	●	※
2011	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2011	Vivaro	CIM (CAN Interface Module)	●	●	●	●	※
2011	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2011	Vivaro	IC (Instrument Cluster)	●	●	●	●	※
2011	Vivaro	MTA (Tecshift)	●	●	●	●	※
2011	Vivaro	PP (Park Pilot)	※	●	●	●	※
2011	Zafira-B	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2011	Zafira-B	ATW (Anti Theft Warning System)	●	●	●	●	●
2011	Zafira-B	CDL (Central Door Lock)	●	●	●	●	●
2011	Zafira-B	DAB (Digital Audio Broadcast)	●	●	●	※	※

2011	Zafira-B	ECM (Engine Control Module)	●	●	●	●	●
2011	Zafira-B	EHS (Electrical Heater System)	●	●	●	●	※
2011	Zafira-B	EPS (Electric Power Steering)	●	●	●	●	※
2011	Zafira-B	IC (Instrument Cluster)	●	●	●	●	●
2011	Zafira-B	IL (Interior Lighting)	●	●	●	●	●
2011	Zafira-B	IMMO (Immobiliser)	●	●	●	●	●
2011	Zafira-B	PEPS (Open&Start)	●	●	●	●	※
2011	Zafira-B	SAC (Automatic Climate Control)	●	●	●	●	●
2011	Zafira-B	SLM (Shift Lever Module)	●	●	●	●	●
2011	Zafira-B	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2011	Zafira-B	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2011	Zafira-B	UHP (Mobile Phone Portal)	●	●	●	※	※
2011	Zafira-B	W&W (Wipers/Washer)	●	●	●	●	●
2011	Zafira-B	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2012	Agila-B	BCM (Body Control Module)	※	●	●	●	●
2012	Agila-B	ECM (Engine Control Module)	●	●	●	●	●
2012	Agila-B	IMMO (Immobiliser)	●	●	●	●	※
2012	Agila-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2012	Agila-B	S&S (Stop/Start System)	●	●	●	●	※
2012	Agila-B	TCM (Transmission Control Module)	●	●	●	●	※
2012	Ampera	ATFP (Auxiliary Transmission Fluid Pump)	●	※	※	●	※
2012	Ampera	BCCM (Battery Charger Control Module)	●	※	※	●	※
2012	Ampera	BCM (Body Control Module)	●	●	●	●	●
2012	Ampera	BECM (Battery Energy Control Module)	●	※	※	●	※
2012	Ampera	CHCM (Coolant Heater Control Module)	●	●	●	※	※
2012	Ampera	DMCM1 (Drive Motor Control Module 1)	●	※	※	●	※
2012	Ampera	DMCM2 (Drive Motor Control Module 2)	●	※	※	●	※
2012	Ampera	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2012	Ampera	EACCM (Electric A/C Compressor Control Module)	●	※	※	※	※
2012	Ampera	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2012	Ampera	ECM (Engine Control Module)	●	●	●	●	●
2012	Ampera	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2012	Ampera	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2012	Ampera	HPCM (Hybrid Powertrain Control Module 2)	●	●	●	●	●
2012	Ampera	HPCM (Hybrid Powertrain Control Module)	●	●	●	●	●
2012	Ampera	IC (Instrument Cluster)	●	●	●	●	●
2012	Ampera	KECM (Keyless Entry Control Module)	●	●	●	●	●
2012	Ampera	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2012	Ampera	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2012	Ampera	PACM (Parking Assist Control Module)	●	●	●	●	●
2012	Ampera	PBCM (Parking Brake Control Module)	●	●	●	●	●
2012	Ampera	PPM (Passenger Presence Module)	●	●	●	●	※
2012	Ampera	PSCM (Power Steering Control Module)	●	●	●	●	●
2012	Ampera	RADIO (Radio)	●	●	●	●	●
2012	Ampera	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2012	Ampera	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2012	Ampera	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2012	Ampera	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2012	Ampera	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2012	Ampera	TCM (Transmission Control Module)	●	●	●	●	●
2012	Antara	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2012	Antara	BCM (Body Control Module)	●	●	●	●	●
2012	Antara	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2012	Antara	ECM (Engine Control Module)	●	●	●	●	●
2012	Antara	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2012	Antara	HCM (Headlamp Control Module)	●	●	●	●	●

2012	Antara	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	※	●
2012	Antara	IC (Instrument Cluster)	●	●	●	●	●
2012	Antara	IDM (Info Display Module)	●	●	●	●	●
2012	Antara	MTCM (Mobile Telephone Control Module)	●	●	●	※	●
2012	Antara	PACM (Parking Assist Control Module)	●	●	●	●	●
2012	Antara	PBCM (Parking Brake Control Module)	●	●	●	●	●
2012	Antara	RADIO (Radio)	●	●	●	●	●
2012	Antara	RCDLR (Remote Control Door Lock Receiver)	●	●	●	●	●
2012	Antara	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2012	Antara	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2012	Antara	TCM (Transmission Control Module)	●	●	●	●	●
2012	Antara	TDM (Theft Deterrent Module)	●	●	●	●	※
2012	Antara	VPSCM (Variable Power Steering Control Module)	●	●	●	※	●
2012	Astra-H	AF 40-6	●	●	●	●	●
2012	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2012	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2012	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2012	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2012	Astra-H	ECM (Engine Control Module)	●	●	●	●	●
2012	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2012	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2012	Astra-H	IC (Instrument Cluster)	●	●	●	●	●
2012	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2012	Astra-H	IMMO (Immobiliser)	●	●	●	●	●
2012	Astra-H	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2012	Astra-H	PAS (Park pilot)	●	●	●	●	●
2012	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2012	Astra-H	SAC (Automatic Climate Control)	●	●	●	●	●
2012	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2012	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2012	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2012	Astra-H	UHP (Mobile Phone Portal)	●	●	●	※	※
2012	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●
2012	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2012	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2012	Astra-J	CACM (Chime Alarm Control Module)	●	●	●	※	●
2012	Astra-J	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2012	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2012	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2012	Astra-J	FICM (Fuel Injector Control Module)	●	※	※	●	●
2012	Astra-J	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2012	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2012	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2012	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2012	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2012	Astra-J	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2012	Astra-J	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2012	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2012	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2012	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	※
2012	Astra-J	RADIO (Radio)	●	●	●	●	●
2012	Astra-J	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2012	Astra-J	SCM (Suspension Control Module)	●	●	●	●	●
2012	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2012	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2012	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●

2012	Astra-J	TICM (Trailer Interface Control Module)	●	●	●	●	●
2012	Astra-J	VDCCM (Vehicle Direction Camera Control Module)	●	●	●	●	●
2012	Combo-D	AHCM (Auxiliary Heater Control Module)	●	●	●	●	●
2012	Combo-D	BCM (Body Control Module)	●	●	●	●	●
2012	Combo-D	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2012	Combo-D	ECM (Engine Control Module)	●	●	●	●	●
2012	Combo-D	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2012	Combo-D	IC (Instrument Cluster)	●	●	●	●	●
2012	Combo-D	MPIM (Multimedia Player Interface Module)	●	●	●	●	●
2012	Combo-D	PACM (Parking Assist Control Module)	●	●	●	●	※
2012	Combo-D	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2012	Combo-D	TCM (Transmission Control Module)	●	●	●	●	●
2012	Corsa-C	AF 13-II/17/20/22 CAN	※	●	●	●	●
2012	Corsa-C	AOH (Add On Heater)	※	●	●	●	●
2012	Corsa-C	ECM (Engine Control Module)	●	●	●	●	●
2012	Corsa-D	AF 13-4	●	●	●	●	●
2012	Corsa-D	AFL (Adaptive Forward Lighting)	●	●	●	●	●
2012	Corsa-D	DIS (Info Display TID,BID,GID,CID)	●	●	●	●	※
2012	Corsa-D	ECC (Electronic Climate Control)	●	●	●	※	※
2012	Corsa-D	ECM (Engine Control Module)	●	●	●	●	●
2012	Corsa-D	EHS (Electrical Heater System)	●	●	●	●	●
2012	Corsa-D	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2012	Corsa-D	PAS (Park pilot)	●	●	●	●	●
2012	Corsa-D	S&S (Stop/Start System)	●	●	●	※	※
2012	Corsa-D	TIM (Trailer Interface Module)	●	●	●	●	●
2012	Corsa-D	UHP (Mobile Phone Portal)	●	●	●	※	※
2012	Insignia	BCM (Body Control Module)	●	●	●	●	●
2012	Insignia	CACM (Chime Alarm Control Module)	●	●	●	※	●
2012	Insignia	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2012	Insignia	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2012	Insignia	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2012	Insignia	ECM (Engine Control Module)	●	●	●	●	●
2012	Insignia	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2012	Insignia	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2012	Insignia	HCM (Headlamp Control Module)	●	●	●	●	●
2012	Insignia	IC (Instrument Cluster)	●	●	●	●	●
2012	Insignia	LCM (Liftgate Control Module)	●	●	●	●	※
2012	Insignia	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2012	Insignia	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2012	Insignia	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2012	Insignia	PACM (Parking Assist Control Module)	●	●	●	●	●
2012	Insignia	PBCM (Parking Brake Control Module)	●	●	●	●	●
2012	Insignia	PSCM (Power Steering Control Module)	●	●	●	●	●
2012	Insignia	RADIO (Radio)	●	●	●	●	●
2012	Insignia	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2012	Insignia	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2012	Insignia	SCM (Suspension Control Module)	●	●	●	●	●
2012	Insignia	SMCM (Seat Memory Control Module)	●	●	●	●	●
2012	Insignia	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2012	Insignia	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2012	Insignia	TCM (Transmission Control Module)	●	●	●	●	●
2012	Insignia	TICM (Trailer Interface Control Module)	●	●	●	●	●
2012	Insignia	VDCCM (Vehicle Direction Camera Control Module)	●	●	●	●	●
2012	Meriva-B	DRCM (Digital Radio Control Module)	●	●	●	※	※
2012	Meriva-B	ECM (Engine Control Module)	●	●	●	●	●
2012	Meriva-B	EPS (Electric Power Steering)	●	●	●	●	●

2012	Meriva-B	FICM (Fuel Injector Control Module)	●	●	●	●	●
2012	Meriva-B	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2012	Meriva-B	HLCM (Headlamp Control Module)	●	●	●	●	●
2012	Meriva-B	IC (Instrument Cluster)	●	●	●	●	●
2012	Meriva-B	MPIM (Multimedia player interface module)	●	●	●	※	※
2012	Meriva-B	MTCM (Mobile Telephone Control Module)	●	●	●	※	※
2012	Meriva-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2012	Meriva-B	PBCM (Parking Brake Control Module)	●	●	●	●	●
2012	Meriva-B	R&C (Radio / Chime Alarm Control Module)	●	●	●	●	※
2012	Meriva-B	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2012	Meriva-B	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	●
2012	Meriva-B	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2012	Meriva-B	TICM (Trailer Interface Control Module)	●	●	●	●	●
2012	Movano-B	CIM (CAN Interface Module)	●	●	●	●	※
2012	Movano-B	ECM (Engine Control Module)	●	●	●	●	●
2012	Movano-B	HLCM (Headlamp Control Module)	●	●	●	●	※
2012	Movano-B	RHACCM (Remote Heater and Air Conditioning Control Module 2)	※	●	●	●	※
2012	Movano-B	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	※
2012	Movano-B	Radio	●	●	●	※	※
2012	Movano-B	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	※
2012	Vauxhall-VXR8	AHL (Automatic Headlamp Levelling)	●	●	●	●	●
2012	Vauxhall-VXR8	AT (Automatic Transmission)	●	●	●	●	●
2012	Vauxhall-VXR8	Audio system	●	●	●	●	※
2012	Vauxhall-VXR8	BCM (Body Control Module)	●	●	●	●	●
2012	Vauxhall-VXR8	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2012	Vauxhall-VXR8	ECM (Engine Control Module)	●	●	●	●	●
2012	Vauxhall-VXR8	ESC (Electronic Suspension Control)	●	●	●	●	●
2012	Vauxhall-VXR8	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2012	Vauxhall-VXR8	IC (Instrument Cluster)	●	●	●	●	●
2012	Vauxhall-VXR8	IMMO (Immobiliser)	●	●	●	●	※
2012	Vauxhall-VXR8	MSM (Memory Seat And Mirrors)	●	●	●	●	●
2012	Vauxhall-VXR8	PA (Park Assist)	●	●	●	●	●
2012	Vauxhall-VXR8	RFA (Multipurpose Receiver Module)	●	●	●	●	※
2012	Vauxhall-VXR8	RSE (rear seat entertainment)	●	●	●	●	※
2012	Vauxhall-VXR8	SDM (Sensing And Diagnostic Module)	●	●	●	●	※
2012	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2012	Vivaro	CIM (CAN Interface Module)	●	●	●	●	※
2012	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2012	Vivaro	IC (Instrument Cluster)	●	●	●	●	※
2012	Vivaro	MTA (Tecshift)	●	●	●	●	※
2012	Vivaro	PP (Park Pilot)	※	●	●	●	※
2012	Zafira-B	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2012	Zafira-B	ATW (Anti Theft Warning System)	●	●	●	●	●
2012	Zafira-B	CDL (Central Door Lock)	●	●	●	●	●
2012	Zafira-B	DAB (Digital Audio Broadcast)	●	●	●	※	※
2012	Zafira-B	ECM (Engine Control Module)	●	●	●	●	●
2012	Zafira-B	EHS (Electrical Heater System)	●	●	●	●	※
2012	Zafira-B	EPS (Electric Power Steering)	●	●	●	●	※
2012	Zafira-B	IC (Instrument Cluster)	●	●	●	●	●
2012	Zafira-B	IL (Interior Lighting)	●	●	●	●	●
2012	Zafira-B	IMMO (Immobiliser)	●	●	●	●	●
2012	Zafira-B	PEPS (Open&Start)	●	●	●	●	※
2012	Zafira-B	SAC (Automatic Climate Control)	●	●	●	●	●
2012	Zafira-B	SLM (Shift Lever Module)	●	●	●	●	●
2012	Zafira-B	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2012	Zafira-B	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2012	Zafira-B	UHP (Mobile Phone Portal)	●	●	●	※	※

2012	Zafira-B	W&W (Wipers/Washer)	●	●	●	●	●
2012	Zafira-B	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2012	Zafira-C	BCM (Body Control Module)	●	●	●	●	●
2012	Zafira-C	CACM (Chime Alarm Control Module)	●	●	●	※	●
2012	Zafira-C	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2012	Zafira-C	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2012	Zafira-C	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2012	Zafira-C	ECM (Engine Control Module)	●	●	●	●	●
2012	Zafira-C	FICM (Fuel Injector Control Module)	●	※	※	●	●
2012	Zafira-C	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2012	Zafira-C	HCM (Headlamp Control Module)	●	●	●	●	●
2012	Zafira-C	IC (Instrument Cluster)	●	●	●	●	●
2012	Zafira-C	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2012	Zafira-C	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2012	Zafira-C	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2012	Zafira-C	PACM (Parking Assist Control Module)	●	●	●	●	●
2012	Zafira-C	PBCM (Parking Brake Control Module)	●	●	●	●	●
2012	Zafira-C	PSCM (Power Steering Control Module)	●	●	●	●	●
2012	Zafira-C	RADIO (Radio)	●	●	●	●	●
2012	Zafira-C	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2012	Zafira-C	SCM (Suspension Control Module)	●	●	●	●	●
2012	Zafira-C	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2012	Zafira-C	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2012	Zafira-C	TCM (Transmission Control Module)	●	●	●	●	●
2012	Zafira-C	TICM (Trailer Interface Control Module)	●	●	●	●	●
2012	Zafira-C	VDCCM (Vehicle Direction Camera Control Module)	●	●	●	●	●
2013	Adam	BCM (Body Control Module)	●	●	●	●	●
2013	Adam	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2013	Adam	ECM (Engine Control Module)	●	●	●	●	●
2013	Adam	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2013	Adam	IC (Instrument Cluster)	●	●	●	●	●
2013	Adam	PACM (Parking Assist Control Module)	●	●	●	●	●
2013	Adam	PSCM (Power Steering Control Module)	●	●	●	●	※
2013	Adam	RADIO (Radio)	●	●	●	●	●
2013	Adam	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2013	Adam	TICM (Trailer Interface Control Module)	●	●	●	●	●
2013	Agila-B	BCM (Body Control Module)	※	●	●	●	●
2013	Agila-B	ECM (Engine Control Module)	●	●	●	●	●
2013	Agila-B	IMMO (Immobiliser)	●	●	●	●	※
2013	Agila-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2013	Agila-B	S&S (Stop/Start System)	●	●	●	●	※
2013	Agila-B	TCM (Transmission Control Module)	●	●	●	●	※
2013	Ampera	ATFP (Auxiliary Transmission Fluid Pump)	●	※	※	●	※
2013	Ampera	BCCM (Battery Charger Control Module)	●	※	※	●	※
2013	Ampera	BCM (Body Control Module)	●	●	●	●	●
2013	Ampera	BECM (Battery Energy Control Module)	●	※	※	●	※
2013	Ampera	CHCM (Coolant Heater Control Module)	●	●	●	※	※
2013	Ampera	DMCM1 (Drive Motor Control Module 1)	●	※	※	●	※
2013	Ampera	DMCM2 (Drive Motor Control Module 2)	●	※	※	●	※
2013	Ampera	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2013	Ampera	EACCM (Electric A/C Compressor Control Module)	●	※	※	※	※
2013	Ampera	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2013	Ampera	ECM (Engine Control Module)	●	●	●	●	●
2013	Ampera	FCM (Frontview Camera Module)	●	●	●	●	●
2013	Ampera	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2013	Ampera	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●

2013	Ampera	HPCM (Hybrid Powertrain Control Module 2)	●	●	●	●	●
2013	Ampera	HPCM (Hybrid Powertrain Control Module)	●	●	●	●	●
2013	Ampera	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2013	Ampera	IC (Instrument Cluster)	●	●	●	●	●
2013	Ampera	KECM (Keyless Entry Control Module)	●	●	●	●	●
2013	Ampera	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2013	Ampera	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2013	Ampera	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2013	Ampera	PACM (Parking Assist Control Module)	●	●	●	●	●
2013	Ampera	PBCM (Parking Brake Control Module)	●	●	●	●	●
2013	Ampera	PSCM (Power Steering Control Module)	●	●	●	●	※
2013	Ampera	RADIO (Radio)	●	●	●	●	●
2013	Ampera	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2013	Ampera	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2013	Ampera	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2013	Ampera	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2013	Ampera	TCM (Transmission Control Module)	●	●	●	●	●
2013	Antara	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2013	Antara	BCM (Body Control Module)	●	●	●	●	●
2013	Antara	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2013	Antara	ECM (Engine Control Module)	●	●	●	●	●
2013	Antara	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2013	Antara	HCM (Headlamp Control Module)	●	●	●	●	●
2013	Antara	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	※	●
2013	Antara	IC (Instrument Cluster)	●	●	●	●	●
2013	Antara	IDM (Info Display Module)	●	●	●	●	●
2013	Antara	MTCM (Mobile Telephone Control Module)	●	●	●	※	●
2013	Antara	PACM (Parking Assist Control Module)	●	●	●	●	●
2013	Antara	PBCM (Parking Brake Control Module)	●	●	●	●	●
2013	Antara	RADIO (Radio)	●	●	●	●	●
2013	Antara	RCDLR (Remote Control Door Lock Receiver)	●	●	●	●	●
2013	Antara	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2013	Antara	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2013	Antara	TCM (Transmission Control Module)	●	●	●	●	●
2013	Antara	TDM (Theft Deterrent Module)	●	●	●	●	※
2013	Antara	VPSCM (Variable Power Steering Control Module)	●	●	●	※	●
2013	Astra-H	AF 40-6	●	●	●	●	●
2013	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2013	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2013	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2013	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2013	Astra-H	ECM (Engine Control Module)	●	●	●	●	●
2013	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2013	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2013	Astra-H	IC (Instrument Cluster)	●	●	●	●	●
2013	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2013	Astra-H	IMMO (Immobiliser)	●	●	●	●	●
2013	Astra-H	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2013	Astra-H	PAS (Park pilot)	●	●	●	●	●
2013	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2013	Astra-H	SAC (Automatic Climate Control)	●	●	●	●	●
2013	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2013	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2013	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2013	Astra-H	UHP (Mobile Phone Portal)	●	●	●	※	※
2013	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●

2013	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2013	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2013	Astra-J	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2013	Astra-J	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2013	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2013	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2013	Astra-J	FCM (Frontview Camera Module)	●	●	●	●	●
2013	Astra-J	FICM (Fuel Injector Control Module)	●	※	※	●	●
2013	Astra-J	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2013	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2013	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2013	Astra-J	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2013	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2013	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2013	Astra-J	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2013	Astra-J	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2013	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2013	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2013	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	●
2013	Astra-J	RADIO (Radio)	●	●	●	●	●
2013	Astra-J	SCM (Suspension Control Module)	●	●	●	●	●
2013	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2013	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2013	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●
2013	Astra-J	TICM (Trailer Interface Control Module)	●	●	●	●	●
2013	Cascada	BCM (Body Control Module)	●	●	●	●	●
2013	Cascada	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2013	Cascada	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2013	Cascada	ECM (Engine Control Module)	●	●	●	●	●
2013	Cascada	FCM (Frontview Camera Module)	●	●	●	●	●
2013	Cascada	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2013	Cascada	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2013	Cascada	FTC (Folding Top Control)	●	●	●	●	●
2013	Cascada	HCM (Headlamp Control Module)	●	●	●	●	●
2013	Cascada	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2013	Cascada	IC (Instrument Cluster)	●	●	●	●	●
2013	Cascada	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2013	Cascada	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2013	Cascada	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2013	Cascada	PACM (Parking Assist Control Module)	●	●	●	●	●
2013	Cascada	PBCM (Parking Brake Control Module)	●	●	●	●	●
2013	Cascada	PSCM (Power Steering Control Module)	●	●	●	●	※
2013	Cascada	RADIO (Radio)	●	●	●	●	●
2013	Cascada	SCM (Suspension Control Module)	●	●	●	●	●
2013	Cascada	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2013	Cascada	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2013	Cascada	TCM (Transmission Control Module)	●	●	●	●	●
2013	Combo-D	AHCM (Auxiliary Heater Control Module)	●	●	●	●	●
2013	Combo-D	BCM (Body Control Module)	●	●	●	●	●
2013	Combo-D	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2013	Combo-D	ECM (Engine Control Module)	●	●	●	●	●
2013	Combo-D	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2013	Combo-D	IC (Instrument Cluster)	●	●	●	●	●
2013	Combo-D	MPIM (Multimedia Player Interface Module)	●	●	●	●	●
2013	Combo-D	PACM (Parking Assist Control Module)	●	●	●	●	※

2013	Combo-D	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2013	Combo-D	TCM (Transmission Control Module)	●	●	●	●	●
2013	Corsa-D	AF 13-4	●	●	●	●	●
2013	Corsa-D	AFL (Adaptive Forward Lighting)	●	●	●	●	●
2013	Corsa-D	DIS (Info Display TID, BID, GID, CID)	●	●	●	●	※
2013	Corsa-D	ECC (Electronic Climate Control)	●	●	●	※	※
2013	Corsa-D	ECM (Engine Control Module)	●	●	●	●	●
2013	Corsa-D	EHS (Electrical Heater System)	●	●	●	●	●
2013	Corsa-D	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2013	Corsa-D	PAS (Park pilot)	●	●	●	●	●
2013	Corsa-D	S&S (Stop/Start System)	●	●	●	※	※
2013	Corsa-D	TIM (Trailer Interface Module)	●	●	●	●	●
2013	Corsa-D	UHP (Mobile Phone Portal)	●	●	●	※	※
2013	Insignia	BCM (Body Control Module)	●	●	●	●	●
2013	Insignia	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2013	Insignia	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2013	Insignia	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2013	Insignia	ECM (Engine Control Module)	●	●	●	●	●
2013	Insignia	FCM (Frontview Camera Module)	●	●	●	●	●
2013	Insignia	FICM (Fuel Injector Control Module)	●	※	※	●	●
2013	Insignia	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2013	Insignia	FSHVC (Front Seat Heating/Venting/Cooling)	●	●	●	●	●
2013	Insignia	HCM (Headlamp Control Module)	●	●	●	●	●
2013	Insignia	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2013	Insignia	IC (Instrument Cluster)	●	●	●	●	●
2013	Insignia	LCM (Liftgate Control Module)	●	●	●	●	※
2013	Insignia	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2013	Insignia	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2013	Insignia	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2013	Insignia	PACM (Parking Assist Control Module)	●	●	●	●	●
2013	Insignia	PBCM (Parking Brake Control Module)	●	●	●	●	●
2013	Insignia	PSCM (Power Steering Control Module)	●	●	●	●	●
2013	Insignia	RADIO (Radio)	●	●	●	●	●
2013	Insignia	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2013	Insignia	SCM (Suspension Control Module)	●	●	●	●	●
2013	Insignia	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2013	Insignia	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2013	Insignia	TCM (Transmission Control Module)	●	●	●	●	●
2013	Insignia	TICM (Trailer Interface Control Module)	●	●	●	●	●
2013	Meriva-B	DRCM (Digital Radio Control Module)	●	●	●	※	※
2013	Meriva-B	ECM (Engine Control Module)	●	●	●	●	●
2013	Meriva-B	EPS (Electric Power Steering)	●	●	●	●	●
2013	Meriva-B	FICM (Fuel Injector Control Module)	●	●	●	●	●
2013	Meriva-B	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2013	Meriva-B	HLCM (Headlamp Control Module)	●	●	●	●	●
2013	Meriva-B	IC (Instrument Cluster)	●	●	●	●	●
2013	Meriva-B	MPIM (Multimedia player interface module)	●	●	●	※	※
2013	Meriva-B	MTCM (Mobile Telephone Control Module)	●	●	●	※	※
2013	Meriva-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2013	Meriva-B	PBCM (Parking Brake Control Module)	●	●	●	●	●
2013	Meriva-B	R&C (Radio / Chime Alarm Control Module)	●	●	●	●	※
2013	Meriva-B	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	●
2013	Meriva-B	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	●
2013	Meriva-B	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2013	Meriva-B	TICM (Trailer Interface Control Module)	●	●	●	●	●
2013	Mokka	BCM (Body Control Module)	●	●	●	●	●

2013	Mokka	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2013	Mokka	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2013	Mokka	ECM (Engine Control Module)	●	●	●	●	●
2013	Mokka	FCM (Frontview Camera Module)	●	●	●	●	●
2013	Mokka	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2013	Mokka	HCM (Headlamp Control Module)	●	●	●	●	●
2013	Mokka	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2013	Mokka	IC (Instrument Cluster)	●	●	●	●	●
2013	Mokka	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2013	Mokka	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2013	Mokka	PACM (Parking Assist Control Module)	●	●	●	●	●
2013	Mokka	PSCM (Power Steering Control Module)	●	●	●	●	※
2013	Mokka	RADIO (Radio)	●	●	●	●	●
2013	Mokka	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	※
2013	Mokka	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2013	Mokka	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2013	Mokka	TCM (Transmission Control Module)	●	●	●	●	●
2013	Mokka	TICM (Trailer Interface Control Module)	●	●	●	●	●
2013	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2013	Vivaro	CIM (CAN Interface Module)	●	●	●	●	※
2013	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2013	Vivaro	IC (Instrument Cluster)	●	●	●	●	※
2013	Vivaro	MTA (Tecshift)	●	●	●	●	※
2013	Vivaro	PP (Park Pilot)	※	●	●	●	※
2013	Zafira-B	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2013	Zafira-B	ATW (Anti Theft Warning System)	●	●	●	●	●
2013	Zafira-B	CDL (Central Door Lock)	●	●	●	●	●
2013	Zafira-B	DAB (Digital Audio Broadcast)	●	●	●	※	※
2013	Zafira-B	ECM (Engine Control Module)	●	●	●	●	●
2013	Zafira-B	EHS (Electrical Heater System)	●	●	●	●	※
2013	Zafira-B	EPS (Electric Power Steering)	●	●	●	●	※
2013	Zafira-B	IC (Instrument Cluster)	●	●	●	●	●
2013	Zafira-B	IL (Interior Lighting)	●	●	●	●	●
2013	Zafira-B	IMMO (Immobiliser)	●	●	●	●	●
2013	Zafira-B	PEPS (Open&Start)	●	●	●	●	※
2013	Zafira-B	SAC (Electronic Climate Control)	●	●	●	●	●
2013	Zafira-B	SLM (Shift Lever Module)	●	●	●	●	●
2013	Zafira-B	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2013	Zafira-B	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2013	Zafira-B	UHP (Mobile Phone Portal)	●	●	●	※	※
2013	Zafira-B	W&W (Wipers/Washer)	●	●	●	●	●
2013	Zafira-B	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2013	Zafira-C	BCM (Body Control Module)	●	●	●	●	●
2013	Zafira-C	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2013	Zafira-C	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2013	Zafira-C	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2013	Zafira-C	ECM (Engine Control Module)	●	●	●	●	●
2013	Zafira-C	FCM (Frontview Camera Module)	●	●	●	●	●
2013	Zafira-C	FICM (Fuel Injector Control Module)	●	※	※	●	●
2013	Zafira-C	FPCM (Fuel Pump Control Module)	●	●	●	●	●
2013	Zafira-C	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2013	Zafira-C	HCM (Headlamp Control Module)	●	●	●	●	●
2013	Zafira-C	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2013	Zafira-C	IC (Instrument Cluster)	●	●	●	●	●
2013	Zafira-C	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2013	Zafira-C	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2013	Zafira-C	MTCM (Mobile Telephone Control Module)	●	●	●	●	●

2013	Zafira-C	PACM (Parking Assist Control Module)	●	●	●	●	●
2013	Zafira-C	PBCM (Parking Brake Control Module)	●	●	●	●	●
2013	Zafira-C	PSCM (Power Steering Control Module)	●	●	●	●	※
2013	Zafira-C	RADIO (Radio)	●	●	●	●	●
2013	Zafira-C	SCM (Suspension Control Module)	●	●	●	●	●
2013	Zafira-C	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2013	Zafira-C	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2013	Zafira-C	TCM (Transmission Control Module)	●	●	●	●	●
2013	Zafira-C	TICM (Trailer Interface Control Module)	●	●	●	●	●
2014	Adam	BCM (Body Control Module)	●	●	●	●	●
2014	Adam	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2014	Adam	ECM (Engine Control Module)	●	●	●	●	●
2014	Adam	FICM (Fuel Injector Control Module)	●	※	※	●	●
2014	Adam	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2014	Adam	IC (Instrument Cluster)	●	●	●	●	●
2014	Adam	PACM (Parking Assist Control Module)	●	●	●	●	●
2014	Adam	PSCM (Power Steering Control Module)	●	●	●	●	※
2014	Adam	RADIO (Radio)	●	●	●	●	●
2014	Adam	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2014	Adam	TICM (Trailer Interface Control Module)	●	●	●	●	●
2014	Agila-B	BCM (Body Control Module)	※	●	●	●	●
2014	Agila-B	ECM (Engine Control Module)	●	●	●	●	●
2014	Agila-B	IMMO (Immobliser)	●	●	●	●	※
2014	Agila-B	PSCM (Power Steering Control Module)	※	●	●	●	※
2014	Agila-B	S&S (Stop/Start System)	●	●	●	●	※
2014	Agila-B	TCM (Transmission Control Module)	●	●	●	●	※
2014	Ampera	ATFP (Auxiliary Transmission Fluid Pump)	●	※	※	●	※
2014	Ampera	BCCM (Battery Charger Control Module)	●	※	※	●	※
2014	Ampera	BCM (Body Control Module)	●	●	●	●	●
2014	Ampera	BECM (Battery Energy Control Module)	●	※	※	●	※
2014	Ampera	CCM (Chassis Control Module)	●	●	●	●	●
2014	Ampera	CHCM (Coolant Heater Control Module)	●	●	●	※	※
2014	Ampera	DMCM1 (Drive Motor Control Module 1)	●	※	※	●	※
2014	Ampera	DMCM2 (Drive Motor Control Module 2)	●	※	※	●	※
2014	Ampera	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2014	Ampera	EACCM (Electric A/C Compressor Control Module)	●	※	※	※	※
2014	Ampera	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2014	Ampera	ECM (Engine Control Module)	●	●	●	●	●
2014	Ampera	FCM (Frontview Camera Module)	●	●	●	●	●
2014	Ampera	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2014	Ampera	HPCM (Hybrid Powertrain Control Module 2)	●	●	●	●	●
2014	Ampera	HPCM (Hybrid Powertrain Control Module)	●	●	●	●	●
2014	Ampera	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2014	Ampera	IC (Instrument Cluster)	●	●	●	●	●
2014	Ampera	KECM (Keyless Entry Control Module)	●	●	●	●	●
2014	Ampera	PACM (Parking Assist Control Module)	●	●	●	●	●
2014	Ampera	PBCM (Parking Brake Control Module)	●	●	●	●	●
2014	Ampera	PSCM (Power Steering Control Module)	●	●	●	●	※
2014	Ampera	RADIO (Radio)	●	●	●	●	●
2014	Ampera	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2014	Ampera	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2014	Ampera	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2014	Ampera	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2014	Ampera	TCM (Transmission Control Module)	●	●	●	●	●
2014	Antara	ABCM (Auxiliary Body Control Module)	●	●	●	●	●

2014	Antara	BCM (Body Control Module)	●	●	●	●	●
2014	Antara	CCM (Chassis Control Module)	●	●	●	●	●
2014	Antara	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2014	Antara	ECM (Engine Control Module)	●	●	●	●	●
2014	Antara	HCM (Headlamp Control Module)	●	●	●	●	●
2014	Antara	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	※	●
2014	Antara	IC (Instrument Cluster)	●	●	●	●	●
2014	Antara	IDM (Info Display Module)	●	●	●	●	●
2014	Antara	MTCM (Mobile Telephone Control Module)	●	●	●	※	●
2014	Antara	PACM (Parking Assist Control Module)	●	●	●	●	●
2014	Antara	PBCM (Parking Brake Control Module)	●	●	●	●	●
2014	Antara	RADIO (Radio)	●	●	●	●	●
2014	Antara	RCDLR (Remote Control Door Lock Receiver)	●	●	●	●	●
2014	Antara	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2014	Antara	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2014	Antara	TCM (Transmission Control Module)	●	●	●	●	●
2014	Antara	TDM (Theft Deterrent Module)	●	●	●	●	※
2014	Antara	VPSCM (Variable Power Steering Control Module)	●	●	●	※	●
2014	Astra-H	AF 40-6	●	●	●	●	●
2014	Astra-H	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2014	Astra-H	ATW (Anti Theft Warning System)	●	●	●	●	●
2014	Astra-H	CDL (Central Door Lock)	●	●	●	●	●
2014	Astra-H	DAB (Digital Audio Broadcast)	●	●	●	※	※
2014	Astra-H	ECM (Engine Control Module)	●	●	●	●	●
2014	Astra-H	EHS (Electrical Heater System)	●	●	●	●	※
2014	Astra-H	EPS (Electric Power Steering)	●	●	●	●	※
2014	Astra-H	IC (Instrument Cluster)	●	●	●	●	●
2014	Astra-H	IL (Interior Lighting)	●	●	●	●	●
2014	Astra-H	IMMO (Immobiliser)	●	●	●	●	●
2014	Astra-H	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2014	Astra-H	PAS (Park pilot)	●	●	●	●	●
2014	Astra-H	PEPS (Open&Start)	●	●	●	●	※
2014	Astra-H	SAC (Automatic Climate Control)	●	●	●	●	●
2014	Astra-H	SLM (Shift Lever Module)	●	●	●	●	●
2014	Astra-H	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2014	Astra-H	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2014	Astra-H	UHP (Mobile Phone Portal)	●	●	●	※	※
2014	Astra-H	W&W (Wipers/Washer)	●	●	●	●	●
2014	Astra-H	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2014	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2014	Astra-J	CCM (Chassis Control Module)	●	●	●	●	●
2014	Astra-J	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2014	Astra-J	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2014	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2014	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2014	Astra-J	FCM (Frontview Camera Module)	●	●	●	●	●
2014	Astra-J	FICM (Fuel Injector Control Module)	●	※	※	●	●
2014	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2014	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2014	Astra-J	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2014	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2014	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2014	Astra-J	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2014	Astra-J	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2014	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2014	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2014	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	※

2014	Astra-J	RADIO (Radio)	●	●	●	●	●
2014	Astra-J	SCM (Suspension Control Module)	●	●	●	●	●
2014	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2014	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2014	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●
2014	Astra-J	TICM (Trailer Interface Control Module)	●	●	●	●	●
2014	Cascada	BCM (Body Control Module)	●	●	●	●	●
2014	Cascada	CCM (Chassis Control Module)	●	●	●	●	●
2014	Cascada	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2014	Cascada	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2014	Cascada	ECM (Engine Control Module)	●	●	●	●	●
2014	Cascada	FCM (Frontview Camera Module)	●	●	●	●	●
2014	Cascada	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2014	Cascada	FTC (Folding Top Control)	●	●	●	●	●
2014	Cascada	HCM (Headlamp Control Module)	●	●	●	●	●
2014	Cascada	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2014	Cascada	IC (Instrument Cluster)	●	●	●	●	●
2014	Cascada	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2014	Cascada	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2014	Cascada	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2014	Cascada	PACM (Parking Assist Control Module)	●	●	●	●	●
2014	Cascada	PBCM (Parking Brake Control Module)	●	●	●	●	●
2014	Cascada	PSCM (Power Steering Control Module)	●	●	●	●	※
2014	Cascada	RADIO (Radio)	●	●	●	●	●
2014	Cascada	SCM (Suspension Control Module)	●	●	●	●	●
2014	Cascada	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2014	Cascada	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2014	Cascada	TCM (Transmission Control Module)	●	●	●	●	●
2014	Combo-D	AHCM (Auxiliary Heater Control Module)	●	●	●	●	●
2014	Combo-D	BCM (Body Control Module)	●	●	●	●	●
2014	Combo-D	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2014	Combo-D	ECM (Engine Control Module)	●	●	●	●	●
2014	Combo-D	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2014	Combo-D	IC (Instrument Cluster)	●	●	●	●	●
2014	Combo-D	MPIM (Multimedia Player Interface Module)	●	●	●	●	●
2014	Combo-D	PACM (Parking Assist Control Module)	●	●	●	●	※
2014	Combo-D	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2014	Combo-D	TCM (Transmission Control Module)	●	●	●	●	●
2014	Corsa-D	AF 13-4	●	●	●	●	●
2014	Corsa-D	AFL (Adaptive Forward Lighting)	●	●	●	●	●
2014	Corsa-D	DIS (Info Display TID, BID, GID, CID)	●	●	●	●	※
2014	Corsa-D	ECC (Electronic Climate Control)	●	●	●	※	※
2014	Corsa-D	ECM (Engine Control Module)	●	●	●	●	●
2014	Corsa-D	EHS (Electrical Heater System)	●	●	●	●	●
2014	Corsa-D	MTA (Easytronic Magneti Marelli)	●	●	●	●	●
2014	Corsa-D	PAS (Park pilot)	●	●	●	●	●
2014	Corsa-D	S&S (Stop/Start System)	●	●	●	※	※
2014	Corsa-D	TIM (Trailer Interface Module)	●	●	●	●	●
2014	Corsa-D	UHP (Mobile Phone Portal)	●	●	●	※	※
2014	Insignia	Amplifier	●	●	●	●	※
2014	Insignia	BCM (Body Control Module)	●	●	●	●	●
2014	Insignia	CCM (Chassis Control Module)	●	●	●	●	●
2014	Insignia	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2014	Insignia	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2014	Insignia	ECM (Engine Control Module)	●	●	●	●	●
2014	Insignia	FCM (Frontview Camera Module)	●	●	●	●	●

2014	Insignia	FICM (Fuel Injector Control Module)	●	※	※	●	●
2014	Insignia	FSHVC (Front Seat Heating/Venting/Cooling)	●	●	●	●	●
2014	Insignia	HC (HVAC Controls)	●	●	●	●	●
2014	Insignia	HCM (Headlamp Control Module)	●	●	●	●	●
2014	Insignia	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2014	Insignia	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2014	Insignia	IC (Instrument Cluster)	●	●	●	●	●
2014	Insignia	ICT (Infotainment Control Touchpad)	●	●	●	●	●
2014	Insignia	KECM (Keyless Entry Control Module)	●	●	●	●	●
2014	Insignia	LCM (Liftgate Control Module)	●	●	●	●	※
2014	Insignia	LSODI (Left Side Object Detection Indicator)	●	●	●	※	●
2014	Insignia	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2014	Insignia	PACM (Parking Assist Control Module)	●	●	●	●	●
2014	Insignia	PBCM (Parking Brake Control Module)	●	●	●	●	●
2014	Insignia	PSCM (Power Steering Control Module)	●	●	●	●	●
2014	Insignia	RADIO (Radio)	●	●	●	●	●
2014	Insignia	RC (Radio Controls)	●	●	●	●	●
2014	Insignia	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2014	Insignia	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2014	Insignia	SCM (Suspension Control Module)	●	●	●	●	●
2014	Insignia	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2014	Insignia	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2014	Insignia	TCM (Transmission Control Module)	●	●	●	●	●
2014	Insignia	TICM (Trailer Interface Control Module)	●	●	●	●	●
2014	Meriva-B	BCM (Body Control Module)	●	●	●	●	●
2014	Meriva-B	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2014	Meriva-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2014	Meriva-B	ECM (Engine Control Module)	●	●	●	●	●
2014	Meriva-B	FICM (Fuel Injector Control Module)	●	※	※	●	●
2014	Meriva-B	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2014	Meriva-B	HCM (Headlamp Control Module)	●	●	●	●	●
2014	Meriva-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2014	Meriva-B	IC (Instrument Cluster)	●	●	●	●	●
2014	Meriva-B	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2014	Meriva-B	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2014	Meriva-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2014	Meriva-B	PBCM (Parking Brake Control Module)	●	●	●	●	●
2014	Meriva-B	PSCM (Power Steering Control Module)	●	●	●	●	●
2014	Meriva-B	RADIO (Radio)	●	●	●	●	●
2014	Meriva-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2014	Meriva-B	SWASM (Steering Wheel Angle Sensor Module)	●	※	●	※	※
2014	Meriva-B	TCM (Transmission Control Module)	●	●	●	●	●
2014	Meriva-B	TICM (Trailer Interface Control Module)	●	●	●	●	●
2014	Mokka	BCM (Body Control Module)	●	●	●	●	●
2014	Mokka	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2014	Mokka	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2014	Mokka	ECM (Engine Control Module)	●	●	●	●	●
2014	Mokka	FCM (Frontview Camera Module)	●	●	●	●	●
2014	Mokka	FICM (Fuel Injector Control Module)	●	※	※	●	●
2014	Mokka	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2014	Mokka	HCM (Headlamp Control Module)	●	●	●	●	●
2014	Mokka	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2014	Mokka	IC (Instrument Cluster)	●	●	●	●	●
2014	Mokka	PACM (Parking Assist Control Module)	●	●	●	●	●
2014	Mokka	PSCM (Power Steering Control Module)	●	●	●	●	※
2014	Mokka	RADIO (Radio)	●	●	●	●	●

2014	Mokka	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	※
2014	Mokka	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2014	Mokka	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2014	Mokka	TCM (Transmission Control Module)	●	●	●	●	●
2014	Mokka	TICM (Trailer Interface Control Module)	●	●	●	●	●
2014	Movano-B	CIM (CAN Interface Module)	●	●	●	●	※
2014	Movano-B	ECM (Engine Control Module)	●	●	●	●	●
2014	Movano-B	HLCM (Headlamp Control Module)	●	●	●	●	※
2014	Movano-B	RHACCM (Remote Heater and Air Conditioning Control Module 2)	※	●	●	●	※
2014	Movano-B	RHACCM (Remote Heater and Air Conditioning Control Module)	●	●	●	●	※
2014	Movano-B	Radio	●	●	●	※	※
2014	Movano-B	SRS (Supplemental Inflatable Restraint System)	●	●	●	●	※
2014	Vivaro	AOH (Add On Heater)	※	●	●	●	●
2014	Vivaro	CIM (CAN Interface Module)	●	●	●	●	※
2014	Vivaro	ECM (Engine Control Module)	●	●	●	●	※
2014	Vivaro	IC (Instrument Cluster)	●	●	●	●	※
2014	Vivaro	MTA (Tecshift)	●	●	●	●	※
2014	Vivaro	PP (Park Pilot)	※	●	●	●	※
2014	Zafira-B	AHL/AFL (Headlamp Levelling)	●	●	●	●	●
2014	Zafira-B	ATW (Anti Theft Warning System)	●	●	●	●	●
2014	Zafira-B	CDL (Central Door Lock)	●	●	●	●	●
2014	Zafira-B	DAB (Digital Audio Broadcast)	●	●	●	※	※
2014	Zafira-B	ECM (Engine Control Module)	●	●	●	●	●
2014	Zafira-B	EHS (Electrical Heater System)	●	●	●	●	※
2014	Zafira-B	EPS (Electric Power Steering)	●	●	●	●	※
2014	Zafira-B	IC (Instrument Cluster)	●	●	●	●	●
2014	Zafira-B	IL (Interior Lighting)	●	●	●	●	●
2014	Zafira-B	IMMO (Immobiliser)	●	●	●	●	●
2014	Zafira-B	PEPS (Open&Start)	●	●	●	●	※
2014	Zafira-B	SAC (Automatic Climate Control)	●	●	●	●	●
2014	Zafira-B	SLM (Shift Lever Module)	●	●	●	●	●
2014	Zafira-B	TPMS (Tyre Pressure Monitoring System)	●	●	●	●	※
2014	Zafira-B	TPMS (Tyre Pressure Monitoring)	●	●	●	●	※
2014	Zafira-B	UHP (Mobile Phone Portal)	●	●	●	※	※
2014	Zafira-B	W&W (Wipers/Washer)	●	●	●	●	●
2014	Zafira-B	XL/TIS (Exterior Lighting/Turn Indicator System)	●	●	●	●	●
2014	Zafira-C	BCM (Body Control Module)	●	●	●	●	●
2014	Zafira-C	CCM (Chassis Control Module)	●	●	●	●	●
2014	Zafira-C	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2014	Zafira-C	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2014	Zafira-C	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2014	Zafira-C	ECM (Engine Control Module)	●	●	●	●	●
2014	Zafira-C	FCM (Frontview Camera Module)	●	●	●	●	●
2014	Zafira-C	FICM (Fuel Injector Control Module)	●	※	※	●	●
2014	Zafira-C	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2014	Zafira-C	HCM (Headlamp Control Module)	●	●	●	●	●
2014	Zafira-C	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2014	Zafira-C	IC (Instrument Cluster)	●	●	●	●	●
2014	Zafira-C	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2014	Zafira-C	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2014	Zafira-C	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2014	Zafira-C	PACM (Parking Assist Control Module)	●	●	●	●	●
2014	Zafira-C	PBCM (Parking Brake Control Module)	●	●	●	●	●
2014	Zafira-C	PSCM (Power Steering Control Module)	●	●	●	●	※
2014	Zafira-C	RADIO (Radio)	●	●	●	●	●
2014	Zafira-C	SCM (Suspension Control Module)	●	●	●	●	●

2014	Zafira-C	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2014	Zafira-C	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2014	Zafira-C	TCM (Transmission Control Module)	●	●	●	●	●
2014	Zafira-C	TICM (Trailer Interface Control Module)	●	●	●	●	●
2015	Adam	BCM (Body Control Module)	●	●	●	●	●
2015	Adam	CCM (Chassis Control Module)	●	●	●	●	●
2015	Adam	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Adam	ECM (Engine Control Module)	●	●	●	●	●
2015	Adam	FICM (Fuel Injector Control Module)	●	●	●	●	●
2015	Adam	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Adam	IC (Instrument Cluster)	●	●	●	●	●
2015	Adam	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Adam	PSCM (Power Steering Control Module)	●	●	●	●	※
2015	Adam	RADIO (Radio)	●	●	●	●	●
2015	Adam	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Adam	TCM (Transmission Control Module)	●	●	●	●	●
2015	Adam	TICM (Trailer Interface Control Module)	●	●	●	●	●
2015	Ampera	ATFP (Auxiliary Transmission Fluid Pump)	●	※	※	●	※
2015	Ampera	BCCM (Battery Charger Control Module)	●	※	※	●	※
2015	Ampera	BCM (Body Control Module)	●	●	●	●	●
2015	Ampera	BECM (Battery Energy Control Module)	●	※	※	●	※
2015	Ampera	CCM (Chassis Control Module)	●	●	●	●	●
2015	Ampera	CHCM (Coolant Heater Control Module)	●	●	●	※	※
2015	Ampera	DMCM1 (Drive Motor Control Module 1)	●	※	※	●	※
2015	Ampera	DMCM2 (Drive Motor Control Module 2)	●	※	※	●	※
2015	Ampera	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2015	Ampera	EACCM (Electric A/C Compressor Control Module)	●	※	※	※	※
2015	Ampera	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Ampera	ECM (Engine Control Module)	●	●	●	●	●
2015	Ampera	FCM (Frontview Camera Module)	●	●	●	●	●
2015	Ampera	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2015	Ampera	HPCM (Hybrid Powertrain Control Module 2)	●	●	●	●	●
2015	Ampera	HPCM (Hybrid Powertrain Control Module)	●	●	●	●	●
2015	Ampera	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Ampera	IC (Instrument Cluster)	●	●	●	●	●
2015	Ampera	KECM (Keyless Entry Control Module)	●	●	●	●	●
2015	Ampera	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Ampera	PBCM (Parking Brake Control Module)	●	●	●	●	●
2015	Ampera	PSCM (Power Steering Control Module)	●	●	●	●	※
2015	Ampera	RADIO (Radio)	●	●	●	●	●
2015	Ampera	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2015	Ampera	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Ampera	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2015	Ampera	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2015	Ampera	TCM (Transmission Control Module)	●	●	●	●	●
2015	Antara	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2015	Antara	BCM (Body Control Module)	●	●	●	●	●
2015	Antara	CCM (Chassis Control Module)	●	●	●	●	●
2015	Antara	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Antara	ECM (Engine Control Module)	●	●	●	●	●
2015	Antara	HCM (Headlamp Control Module)	●	●	●	●	●
2015	Antara	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	※	●
2015	Antara	IC (Instrument Cluster)	●	●	●	●	●
2015	Antara	IDM (Info Display Module)	●	●	●	●	●
2015	Antara	MTCM (Mobile Telephone Control Module)	●	●	●	※	●

2015	Antara	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Antara	PBCM (Parking Brake Control Module)	●	●	●	●	●
2015	Antara	RADIO (Radio)	●	●	●	●	●
2015	Antara	RCDLR (Remote Control Door Lock Receiver)	●	●	●	●	●
2015	Antara	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2015	Antara	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Antara	TCM (Transmission Control Module)	●	●	●	●	●
2015	Antara	TDM (Theft Deterrent Module)	●	●	●	●	※
2015	Antara	VPSCM (Variable Power Steering Control Module)	●	●	●	※	●
2015	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2015	Astra-J	CCM (Chassis Control Module)	●	●	●	●	●
2015	Astra-J	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2015	Astra-J	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2015	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2015	Astra-J	FCM (Frontview Camera Module)	●	●	●	●	●
2015	Astra-J	FICM (Fuel Injector Control Module)	●	※	※	●	●
2015	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2015	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2015	Astra-J	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2015	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2015	Astra-J	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2015	Astra-J	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2015	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2015	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	※
2015	Astra-J	RADIO (Radio)	●	●	●	●	●
2015	Astra-J	SCM (Suspension Control Module)	●	●	●	●	●
2015	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2015	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●
2015	Astra-J	TICM (Trailer Interface Control Module)	●	●	●	●	●
2015	Cascada	BCM (Body Control Module)	●	●	●	●	●
2015	Cascada	CCM (Chassis Control Module)	●	●	●	●	●
2015	Cascada	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2015	Cascada	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Cascada	ECM (Engine Control Module)	●	●	●	●	●
2015	Cascada	FCM (Frontview Camera Module)	●	●	●	●	●
2015	Cascada	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2015	Cascada	FTC (Folding Top Control)	●	●	●	●	●
2015	Cascada	HCM (Headlamp Control Module)	●	●	●	●	●
2015	Cascada	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Cascada	IC (Instrument Cluster)	●	●	●	●	●
2015	Cascada	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2015	Cascada	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2015	Cascada	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2015	Cascada	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Cascada	PBCM (Parking Brake Control Module)	●	●	●	●	●
2015	Cascada	PSCM (Power Steering Control Module)	●	●	●	●	※
2015	Cascada	RADIO (Radio)	●	●	●	●	●
2015	Cascada	SCM (Suspension Control Module)	●	●	●	●	●
2015	Cascada	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Cascada	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2015	Cascada	TCM (Transmission Control Module)	●	●	●	●	●
2015	Combo-D	AHCM (Auxiliary Heater Control Module)	●	●	●	●	●

2015	Combo-D	BCM (Body Control Module)	●	●	●	●	●
2015	Combo-D	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Combo-D	ECM (Engine Control Module)	●	●	●	●	●
2015	Combo-D	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Combo-D	IC (Instrument Cluster)	●	●	●	●	●
2015	Combo-D	MPIM (Multimedia Player Interface Module)	●	●	●	●	●
2015	Combo-D	PACM (Parking Assist Control Module)	●	●	●	●	※
2015	Combo-D	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Combo-D	TCM (Transmission Control Module)	●	●	●	●	●
2015	Combo-D	TPIM (Tire Pressure Indicator Module)	●	●	●	●	※
2015	Corsa-E	BCM (Body Control Module)	●	●	●	●	●
2015	Corsa-E	CCM (Chassis Control Module)	●	●	●	●	●
2015	Corsa-E	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Corsa-E	ECM (Engine Control Module)	●	●	●	●	●
2015	Corsa-E	FCM (Frontview Camera Module)	●	●	●	●	●
2015	Corsa-E	FICM (Fuel Injector Control Module)	●	●	●	●	●
2015	Corsa-E	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Corsa-E	IC (Instrument Cluster)	●	●	●	●	●
2015	Corsa-E	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Corsa-E	PSCM (Power Steering Control Module)	●	●	●	●	※
2015	Corsa-E	RADIO (Radio)	●	●	●	●	●
2015	Corsa-E	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Corsa-E	TCM (Transmission Control Module)	●	●	●	●	●
2015	Corsa-E	TICM (Trailer Interface Control Module)	●	●	●	●	●
2015	Insignia	Amplifier	●	●	●	●	※
2015	Insignia	BCM (Body Control Module)	●	●	●	●	●
2015	Insignia	CCM (Chassis Control Module)	●	●	●	●	●
2015	Insignia	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2015	Insignia	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Insignia	ECM (Engine Control Module)	●	●	●	●	●
2015	Insignia	FCM (Frontview Camera Module)	●	●	●	●	●
2015	Insignia	FICM (Fuel Injector Control Module)	●	※	※	●	●
2015	Insignia	FSHVC (Front Seat Heating/Venting/Cooling)	●	●	●	●	●
2015	Insignia	HC (HVAC Controls)	●	●	●	●	●
2015	Insignia	HCM (Headlamp Control Module)	●	●	●	●	●
2015	Insignia	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2015	Insignia	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Insignia	IC (Instrument Cluster)	●	●	●	●	●
2015	Insignia	ICT (Infotainment Control Touchpad)	●	●	●	●	●
2015	Insignia	KECM (Keyless Entry Control Module)	●	●	●	●	●
2015	Insignia	LCM (Liftgate Control Module)	●	●	●	●	※
2015	Insignia	LSODI (Left Side Object Detection Indicator)	●	●	●	※	●
2015	Insignia	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Insignia	PBCM (Parking Brake Control Module)	●	●	●	●	●
2015	Insignia	PSCM (Power Steering Control Module)	●	●	●	●	●
2015	Insignia	RADIO (Radio)	●	●	●	●	●
2015	Insignia	RC (Radio Controls)	●	●	●	●	●
2015	Insignia	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2015	Insignia	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2015	Insignia	SCM (Suspension Control Module)	●	●	●	●	●
2015	Insignia	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Insignia	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2015	Insignia	TCM (Transmission Control Module)	●	●	●	●	●
2015	Insignia	TICM (Trailer Interface Control Module)	●	●	●	●	●
2015	Meriva-B	BCM (Body Control Module)	●	●	●	●	●

2015	Meriva-B	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2015	Meriva-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Meriva-B	ECM (Engine Control Module)	●	●	●	●	●
2015	Meriva-B	FICM (Fuel Injector Control Module)	●	※	※	●	●
2015	Meriva-B	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2015	Meriva-B	HCM (Headlamp Control Module)	●	●	●	●	●
2015	Meriva-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Meriva-B	IC (Instrument Cluster)	●	●	●	●	●
2015	Meriva-B	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2015	Meriva-B	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2015	Meriva-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Meriva-B	PBCM (Parking Brake Control Module)	●	●	●	●	●
2015	Meriva-B	PSCM (Power Steering Control Module)	●	●	●	●	●
2015	Meriva-B	RADIO (Radio)	●	●	●	●	●
2015	Meriva-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Meriva-B	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2015	Meriva-B	TCM (Transmission Control Module)	●	●	●	●	●
2015	Meriva-B	TICM (Trailer Interface Control Module)	●	●	●	●	●
2015	Mokka	BCM (Body Control Module)	●	●	●	●	●
2015	Mokka	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2015	Mokka	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Mokka	ECM (Engine Control Module)	●	●	●	●	●
2015	Mokka	FCM (Frontview Camera Module)	●	●	●	●	●
2015	Mokka	FICM (Fuel Injector Control Module)	●	※	※	●	●
2015	Mokka	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2015	Mokka	HCM (Headlamp Control Module)	●	●	●	●	●
2015	Mokka	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Mokka	IC (Instrument Cluster)	●	●	●	●	●
2015	Mokka	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Mokka	PSCM (Power Steering Control Module)	●	●	●	●	※
2015	Mokka	RADIO (Radio)	●	●	●	●	●
2015	Mokka	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	※
2015	Mokka	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Mokka	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2015	Mokka	TCM (Transmission Control Module)	●	●	●	●	●
2015	Mokka	TICM (Trailer Interface Control Module)	●	●	●	●	●
2015	Movano-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2015	Movano-B	BCM (Body Control Module)	●	●	●	●	●
2015	Movano-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Movano-B	ECM (Engine Control Module)	●	●	●	●	●
2015	Movano-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Movano-B	IC (Instrument Cluster)	●	●	●	●	●
2015	Movano-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※
2015	Movano-B	NCM (Navigation Control Module)	●	●	●	●	●
2015	Movano-B	PACM (Parking Assist Control Module)	●	●	●	●	※
2015	Movano-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2015	Movano-B	RADIO (Radio)	●	●	●	●	●
2015	Movano-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2015	Movano-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2015	Movano-B	TCM (Transmission Control Module)	●	●	●	●	●
2015	Movano-B	TPIM (Tire Pressure Indicator Module)	●	●	●	●	※
2015	Vivaro-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2015	Vivaro-B	BCM (Body Control Module)	●	●	●	●	●
2015	Vivaro-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Vivaro-B	ECM (Engine Control Module)	●	●	●	●	●

2015	Vivaro-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Vivaro-B	IC (Instrument Cluster)	●	●	●	●	●
2015	Vivaro-B	IDM (Info Display Module)	●	●	●	●	●
2015	Vivaro-B	KECM (Keyless Entry Control Module)	●	●	●	●	●
2015	Vivaro-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※
2015	Vivaro-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Vivaro-B	PHCM (Parking Heater Control Module)	●	●	●	●	●
2015	Vivaro-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2015	Vivaro-B	RADIO (Radio)	●	●	●	●	●
2015	Vivaro-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2015	Vivaro-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2015	Vivaro-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2015	Zafira-C	BCM (Body Control Module)	●	●	●	●	●
2015	Zafira-C	CCM (Chassis Control Module)	●	●	●	●	●
2015	Zafira-C	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2015	Zafira-C	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2015	Zafira-C	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2015	Zafira-C	ECM (Engine Control Module)	●	●	●	●	●
2015	Zafira-C	FCM (Frontview Camera Module)	●	●	●	●	●
2015	Zafira-C	FICM (Fuel Injector Control Module)	●	※	※	●	●
2015	Zafira-C	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2015	Zafira-C	HCM (Headlamp Control Module)	●	●	●	●	●
2015	Zafira-C	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2015	Zafira-C	IC (Instrument Cluster)	●	●	●	●	●
2015	Zafira-C	MPIM (Multimedia Player Interface Module)	●	●	●	●	※
2015	Zafira-C	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2015	Zafira-C	PACM (Parking Assist Control Module)	●	●	●	●	●
2015	Zafira-C	PBCM (Parking Brake Control Module)	●	●	●	●	●
2015	Zafira-C	PSCM (Power Steering Control Module)	●	●	●	●	※
2015	Zafira-C	RADIO (Radio)	●	●	●	●	●
2015	Zafira-C	SCM (Suspension Control Module)	●	●	●	●	●
2015	Zafira-C	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2015	Zafira-C	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2015	Zafira-C	TCM (Transmission Control Module)	●	●	●	●	●
2015	Zafira-C	TICM (Trailer Interface Control Module)	●	●	●	●	●
2016	Adam	BCM (Body Control Module)	●	●	●	●	●
2016	Adam	CCM (Chassis Control Module)	●	●	●	●	●
2016	Adam	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Adam	ECM (Engine Control Module)	●	●	●	●	●
2016	Adam	FICM (Fuel Injector Control Module)	●	●	●	●	●
2016	Adam	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Adam	IC (Instrument Cluster)	●	●	●	●	●
2016	Adam	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Adam	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Adam	RADIO (Radio)	●	●	●	●	●
2016	Adam	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Adam	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2016	Adam	TCM (Transmission Control Module)	●	●	●	●	●
2016	Adam	TICM (Trailer Interface Control Module)	●	●	●	●	●
2016	Antara	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2016	Antara	BCM (Body Control Module)	●	●	●	●	●
2016	Antara	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Antara	ECM (Engine Control Module)	●	●	●	●	●
2016	Antara	HCM (Headlamp Control Module)	●	●	●	●	●

2016	Antara	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	※	●
2016	Antara	IC (Instrument Cluster)	●	●	●	●	●
2016	Antara	IDM (Info Display Module)	●	●	●	●	●
2016	Antara	MTCM (Mobile Telephone Control Module)	●	●	●	※	●
2016	Antara	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Antara	PBCM (Parking Brake Control Module)	●	●	●	●	●
2016	Antara	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Antara	RADIO (Radio)	●	●	●	●	●
2016	Antara	RCDLR (Remote Control Door Lock Receiver)	●	●	●	●	●
2016	Antara	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2016	Antara	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Antara	TCM (Transmission Control Module)	●	●	●	●	●
2016	Antara	TDM (Theft Deterrent Module)	●	●	●	●	※
2016	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2016	Astra-J	CCM (Chassis Control Module)	●	●	●	●	●
2016	Astra-J	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2016	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2016	Astra-J	FCM (Frontview Camera Module)	●	●	●	●	●
2016	Astra-J	FICM (Fuel Injector Control Module)	●	※	※	●	●
2016	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2016	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2016	Astra-J	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2016	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2016	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2016	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Astra-J	RADIO (Radio)	●	●	●	●	●
2016	Astra-J	SCM (Suspension Control Module)	●	●	●	●	●
2016	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2016	Astra-J	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2016	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●
2016	Astra-J	TICM (Trailer Interface Control Module)	●	●	●	●	●
2016	Astra-K	BCM (Body Control Module)	●	●	●	●	●
2016	Astra-K	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Astra-K	ECM (Engine Control Module)	●	●	●	●	●
2016	Astra-K	FCM (Frontview Camera Module)	●	●	●	●	※
2016	Astra-K	HC (HVAC Controls)	●	●	●	●	●
2016	Astra-K	HCM (Headlamp Control Module)	●	●	●	●	●
2016	Astra-K	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2016	Astra-K	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Astra-K	IC (Instrument Cluster)	●	●	●	●	●
2016	Astra-K	KECM (Keyless Entry Control Module)	●	●	●	●	●
2016	Astra-K	LCM (Liftgate Control Module)	●	●	●	●	※
2016	Astra-K	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Astra-K	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Astra-K	PST (Power Supply Transformer)	●	●	●	●	※
2016	Astra-K	RADIO (Radio)	●	●	●	●	●
2016	Astra-K	RC (Radio Controls)	●	●	●	●	●
2016	Astra-K	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2016	Astra-K	SMCM (Seat Memory Control Module)	●	●	●	●	●
2016	Astra-K	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●

2016	Astra-K	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2016	Astra-K	TCM (Transmission Control Module)	●	●	●	●	●
2016	Astra-K	TICM (Trailer Interface Control Module)	●	●	●	●	●
2016	Cascada	BCM (Body Control Module)	●	●	●	●	●
2016	Cascada	CCM (Chassis Control Module)	●	●	●	●	●
2016	Cascada	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2016	Cascada	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Cascada	ECM (Engine Control Module)	●	●	●	●	●
2016	Cascada	FCM (Frontview Camera Module)	●	●	●	●	●
2016	Cascada	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2016	Cascada	FTC (Folding Top Control)	●	●	●	●	●
2016	Cascada	HCM (Headlamp Control Module)	●	●	●	●	●
2016	Cascada	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Cascada	IC (Instrument Cluster)	●	●	●	●	●
2016	Cascada	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2016	Cascada	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Cascada	PBCM (Parking Brake Control Module)	●	●	●	●	●
2016	Cascada	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Cascada	RADIO (Radio)	●	●	●	●	●
2016	Cascada	SCM (Suspension Control Module)	●	●	●	●	●
2016	Cascada	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Cascada	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2016	Cascada	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2016	Cascada	TCM (Transmission Control Module)	●	●	●	●	●
2016	Combo-D	AHCM (Auxiliary Heater Control Module)	●	●	●	●	●
2016	Combo-D	BCM (Body Control Module)	●	●	●	●	●
2016	Combo-D	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Combo-D	ECM (Engine Control Module)	●	●	●	●	●
2016	Combo-D	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Combo-D	IC (Instrument Cluster)	●	●	●	●	●
2016	Combo-D	MPIM (Multimedia Player Interface Module)	●	●	●	●	●
2016	Combo-D	PACM (Parking Assist Control Module)	●	●	●	●	※
2016	Combo-D	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Combo-D	TCM (Transmission Control Module)	●	●	●	●	●
2016	Combo-D	TPIM (Tire Pressure Indicator Module)	●	●	●	●	※
2016	Corsa-E	BCM (Body Control Module)	●	●	●	●	●
2016	Corsa-E	CCM (Chassis Control Module)	●	●	●	●	●
2016	Corsa-E	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Corsa-E	ECM (Engine Control Module)	●	●	●	●	●
2016	Corsa-E	FCM (Frontview Camera Module)	●	●	●	●	●
2016	Corsa-E	FICM (Fuel Injector Control Module)	●	●	●	●	●
2016	Corsa-E	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Corsa-E	IC (Instrument Cluster)	●	●	●	●	●
2016	Corsa-E	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Corsa-E	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Corsa-E	RADIO (Radio)	●	●	●	●	●
2016	Corsa-E	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Corsa-E	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2016	Corsa-E	TCM (Transmission Control Module)	●	●	●	●	●
2016	Corsa-E	TICM (Trailer Interface Control Module)	●	●	●	●	●
2016	Insignia	Amplifier	●	●	●	●	※
2016	Insignia	BCM (Body Control Module)	●	●	●	●	●
2016	Insignia	CCM (Chassis Control Module)	●	●	●	●	●

2016	Insignia	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2016	Insignia	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Insignia	ECM (Engine Control Module)	●	●	●	●	●
2016	Insignia	FCM (Frontview Camera Module)	●	●	●	●	●
2016	Insignia	FICM (Fuel Injector Control Module)	●	※	※	●	●
2016	Insignia	FSHVC (Front Seat Heating/Venting/Cooling)	●	●	●	●	●
2016	Insignia	HC (HVAC Controls)	●	●	●	●	●
2016	Insignia	HCM (Headlamp Control Module)	●	●	●	●	●
2016	Insignia	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2016	Insignia	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Insignia	IC (Instrument Cluster)	●	●	●	●	●
2016	Insignia	KECM (Keyless Entry Control Module)	●	●	●	●	●
2016	Insignia	LCM (Liftgate Control Module)	●	●	●	●	※
2016	Insignia	LSODI (Left Side Object Detection Indicator)	●	●	●	※	●
2016	Insignia	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Insignia	PBCM (Parking Brake Control Module)	●	●	●	●	●
2016	Insignia	PSCM (Power Steering Control Module)	●	●	●	●	●
2016	Insignia	RADIO (Radio)	●	●	●	●	●
2016	Insignia	RC (Radio Controls)	●	●	●	●	●
2016	Insignia	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2016	Insignia	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2016	Insignia	SCM (Suspension Control Module)	●	●	●	●	●
2016	Insignia	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Insignia	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2016	Insignia	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2016	Insignia	TCM (Transmission Control Module)	●	●	●	●	●
2016	Insignia	TICM (Trailer Interface Control Module)	●	●	●	●	●
2016	Karl-Viva	BCM (Body Control Module)	●	●	●	●	●
2016	Karl-Viva	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Karl-Viva	ECM (Engine Control Module)	●	●	●	●	●
2016	Karl-Viva	FCM (Frontview Camera Module)	●	●	●	●	※
2016	Karl-Viva	FICM (Fuel Injector Control Module)	●	●	●	●	●
2016	Karl-Viva	HC (HVAC Controls)	●	●	●	●	●
2016	Karl-Viva	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Karl-Viva	IC (Instrument Cluster)	●	●	●	●	●
2016	Karl-Viva	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Karl-Viva	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Karl-Viva	RADIO (Radio)	●	●	●	●	●
2016	Karl-Viva	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Karl-Viva	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2016	Karl-Viva	TCM (Transmission Control Module)	●	●	●	●	●
2016	Meriva-B	BCM (Body Control Module)	●	●	●	●	●
2016	Meriva-B	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2016	Meriva-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Meriva-B	ECM (Engine Control Module)	●	●	●	●	●
2016	Meriva-B	FICM (Fuel Injector Control Module)	●	※	※	●	●
2016	Meriva-B	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2016	Meriva-B	HCM (Headlamp Control Module)	●	●	●	●	●
2016	Meriva-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Meriva-B	IC (Instrument Cluster)	●	●	●	●	●
2016	Meriva-B	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2016	Meriva-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Meriva-B	PBCM (Parking Brake Control Module)	●	●	●	●	●
2016	Meriva-B	PSCM (Power Steering Control Module)	●	●	●	●	●
2016	Meriva-B	RADIO (Radio)	●	●	●	●	●

2016	Meriva-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Meriva-B	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2016	Meriva-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2016	Meriva-B	TCM (Transmission Control Module)	●	●	●	●	●
2016	Meriva-B	TICM (Trailer Interface Control Module)	●	●	●	●	●
2016	Mokka	BCM (Body Control Module)	●	●	●	●	●
2016	Mokka	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2016	Mokka	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Mokka	ECM (Engine Control Module)	●	●	●	●	●
2016	Mokka	FCM (Frontview Camera Module)	●	●	●	●	●
2016	Mokka	FICM (Fuel Injector Control Module)	●	※	※	●	●
2016	Mokka	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2016	Mokka	HCM (Headlamp Control Module)	●	●	●	●	●
2016	Mokka	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Mokka	IC (Instrument Cluster)	●	●	●	●	●
2016	Mokka	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Mokka	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Mokka	RADIO (Radio)	●	●	●	●	●
2016	Mokka	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	※
2016	Mokka	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Mokka	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2016	Mokka	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2016	Mokka	TCM (Transmission Control Module)	●	●	●	●	●
2016	Mokka	TICM (Trailer Interface Control Module)	●	●	●	●	●
2016	Movano-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2016	Movano-B	BCM (Body Control Module)	●	●	●	●	●
2016	Movano-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Movano-B	ECM (Engine Control Module)	●	●	●	●	●
2016	Movano-B	FCM (Frontview Camera Module)	●	●	●	●	※
2016	Movano-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Movano-B	IC (Instrument Cluster)	●	●	●	●	●
2016	Movano-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※
2016	Movano-B	PACM (Parking Assist Control Module)	●	●	●	●	※
2016	Movano-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Movano-B	RADIO (Radio)	●	●	●	●	●
2016	Movano-B	RCM (Reductant Control Module)	●	●	●	●	●
2016	Movano-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2016	Movano-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2016	Movano-B	TCM (Transmission Control Module)	●	●	●	●	●
2016	Movano-B	TPIM (Tire Pressure Indicator Module)	●	●	●	●	※
2016	Vivaro-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2016	Vivaro-B	BCM (Body Control Module)	●	●	●	●	●
2016	Vivaro-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Vivaro-B	ECM (Engine Control Module)	●	●	●	●	●
2016	Vivaro-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Vivaro-B	IC (Instrument Cluster)	●	●	●	●	●
2016	Vivaro-B	IDM (Info Display Module)	●	●	●	●	●
2016	Vivaro-B	KECM (Keyless Entry Control Module)	●	●	●	●	●
2016	Vivaro-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※
2016	Vivaro-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Vivaro-B	PHCM (Parking Heater Control Module)	●	●	●	●	●
2016	Vivaro-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Vivaro-B	RADIO (Radio)	●	●	●	●	●
2016	Vivaro-B	RCM (Reductant Control Module)	●	●	●	●	●

2016	Vivaro-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2016	Vivaro-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2016	Vivaro-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2016	Zafira-C	BCM (Body Control Module)	●	●	●	●	●
2016	Zafira-C	CCM (Chassis Control Module)	●	●	●	●	●
2016	Zafira-C	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2016	Zafira-C	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2016	Zafira-C	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2016	Zafira-C	ECM (Engine Control Module)	●	●	●	●	●
2016	Zafira-C	FCM (Frontview Camera Module)	●	●	●	●	●
2016	Zafira-C	FICM (Fuel Injector Control Module)	●	※	※	●	●
2016	Zafira-C	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2016	Zafira-C	HCM (Headlamp Control Module)	●	●	●	●	●
2016	Zafira-C	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2016	Zafira-C	IC (Instrument Cluster)	●	●	●	●	●
2016	Zafira-C	PACM (Parking Assist Control Module)	●	●	●	●	●
2016	Zafira-C	PBCM (Parking Brake Control Module)	●	●	●	●	●
2016	Zafira-C	PSCM (Power Steering Control Module)	●	●	●	●	※
2016	Zafira-C	RADIO (Radio)	●	●	●	●	●
2016	Zafira-C	SCM (Suspension Control Module)	●	●	●	●	●
2016	Zafira-C	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2016	Zafira-C	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2016	Zafira-C	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2016	Zafira-C	TCM (Transmission Control Module)	●	●	●	●	●
2016	Zafira-C	TICM (Trailer Interface Control Module)	●	●	●	●	●
2017	Adam	BCM (Body Control Module)	●	●	●	●	●
2017	Adam	CCM (Chassis Control Module)	●	●	●	●	●
2017	Adam	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Adam	ECM (Engine Control Module)	●	●	●	●	●
2017	Adam	FICM (Fuel Injector Control Module)	●	●	●	●	●
2017	Adam	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Adam	IC (Instrument Cluster)	●	●	●	●	●
2017	Adam	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Adam	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Adam	RADIO (Radio)	●	●	●	●	●
2017	Adam	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Adam	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Adam	TCM (Transmission Control Module)	●	●	●	●	●
2017	Adam	TICM (Trailer Interface Control Module)	●	●	●	●	●
2017	Ampera-E	BBCM (Brake Booster Control Module)	●	●	●	●	※
2017	Ampera-E	BCM (Body Control Module)	●	●	●	●	●
2017	Ampera-E	BECM (Battery Energy Control Module)	●	※	※	●	※
2017	Ampera-E	CCM (Chassis Control Module)	●	●	●	●	●
2017	Ampera-E	EACCM (Electric A/C Compressor Control Module)	●	※	※	※	※
2017	Ampera-E	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Ampera-E	ECM (Engine Control Module)	●	●	●	●	●
2017	Ampera-E	FCM (Frontview Camera Module)	●	●	●	●	●
2017	Ampera-E	HPCM (Hybrid/EV Powertrain Control Module 1)	●	●	●	●	●
2017	Ampera-E	HPCM (Hybrid/EV Powertrain Control Module 2)	●	●	●	●	●
2017	Ampera-E	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Ampera-E	IC (Instrument Cluster)	●	●	●	●	●
2017	Ampera-E	KECM (Keyless Entry Control Module)	●	●	●	●	●
2017	Ampera-E	LSOSM (Left Side Object Sensor Module)	●	●	●	※	●

2017	Ampera-E	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Ampera-E	PASCM (Pedestrian Alert Sound Control Module)	●	●	●	●	●
2017	Ampera-E	PLCM (Power Line Communication Module)	●	※	※	●	※
2017	Ampera-E	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Ampera-E	RADIO (Radio)	●	●	●	●	●
2017	Ampera-E	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2017	Ampera-E	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2017	Ampera-E	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2017	Ampera-E	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Ampera-E	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2017	Ampera-E	TRCM (Transmission Range Control Module)	●	●	●	●	※
2017	Ampera-E	VPCM (Video Processing Control Module)	●	●	●	●	●
2017	Antara	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2017	Antara	BCM (Body Control Module)	●	●	●	●	●
2017	Antara	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Antara	ECM (Engine Control Module)	●	●	●	●	●
2017	Antara	HCM (Headlamp Control Module)	●	●	●	●	●
2017	Antara	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	※	●
2017	Antara	IC (Instrument Cluster)	●	●	●	●	●
2017	Antara	IDM (Info Display Module)	●	●	●	●	●
2017	Antara	MTCM (Mobile Telephone Control Module)	●	●	●	※	●
2017	Antara	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Antara	PBCM (Parking Brake Control Module)	●	●	●	●	●
2017	Antara	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Antara	RADIO (Radio)	●	●	●	●	●
2017	Antara	RCDLR (Remote Control Door Lock Receiver)	●	●	●	●	●
2017	Antara	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2017	Antara	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Antara	TCM (Transmission Control Module)	●	●	●	●	●
2017	Antara	TDM (Theft Deterrent Module)	●	●	●	●	※
2017	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2017	Astra-J	CCM (Chassis Control Module)	●	●	●	●	●
2017	Astra-J	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2017	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2017	Astra-J	FCM (Frontview Camera Module)	●	●	●	●	●
2017	Astra-J	FICM (Fuel Injector Control Module)	●	※	※	●	●
2017	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2017	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2017	Astra-J	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2017	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2017	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2017	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Astra-J	RADIO (Radio)	●	●	●	●	●
2017	Astra-J	SCM (Suspension Control Module)	●	●	●	●	●
2017	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2017	Astra-J	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●
2017	Astra-J	TICM (Trailer Interface Control Module)	●	●	●	●	●
2017	Astra-K	ASCM (Active Safety Control Module)	●	●	●	●	●
2017	Astra-K	BCM (Body Control Module)	●	●	●	●	●
2017	Astra-K	EBCM (Electronic Brake Control Module)	●	●	●	●	●

2017	Astra-K	ECM (Engine Control Module)	●	●	●	●	●
2017	Astra-K	FCM (Frontview Camera Module)	●	●	●	●	※
2017	Astra-K	FICM (Fuel Injector Control Module)	●	●	●	●	●
2017	Astra-K	HC (HVAC Controls)	●	●	●	●	●
2017	Astra-K	HCM (Headlamp Control Module)	●	●	●	●	●
2017	Astra-K	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2017	Astra-K	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Astra-K	IC (Instrument Cluster)	●	●	●	●	●
2017	Astra-K	KECM (Keyless Entry Control Module)	●	●	●	●	●
2017	Astra-K	LCM (Liftgate Control Module)	●	●	●	●	※
2017	Astra-K	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	※
2017	Astra-K	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2017	Astra-K	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Astra-K	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Astra-K	PST (Power Supply Transformer)	●	●	●	●	※
2017	Astra-K	RADIO (Radio)	●	●	●	●	●
2017	Astra-K	RC (Radio Controls)	●	●	●	●	●
2017	Astra-K	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2017	Astra-K	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2017	Astra-K	SMCM (Seat Memory Control Module)	●	●	●	●	●
2017	Astra-K	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Astra-K	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Astra-K	TCM (Transmission Control Module)	●	●	●	●	●
2017	Astra-K	TICM (Trailer Interface Control Module)	●	●	●	●	●
2017	Cascada	BCM (Body Control Module)	●	●	●	●	●
2017	Cascada	CCM (Chassis Control Module)	●	●	●	●	●
2017	Cascada	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2017	Cascada	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Cascada	ECM (Engine Control Module)	●	●	●	●	●
2017	Cascada	FCM (Frontview Camera Module)	●	●	●	●	●
2017	Cascada	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2017	Cascada	FTC (Folding Top Control)	●	●	●	●	●
2017	Cascada	HCM (Headlamp Control Module)	●	●	●	●	●
2017	Cascada	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Cascada	IC (Instrument Cluster)	●	●	●	●	●
2017	Cascada	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2017	Cascada	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Cascada	PBCM (Parking Brake Control Module)	●	●	●	●	●
2017	Cascada	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Cascada	RADIO (Radio)	●	●	●	●	●
2017	Cascada	SCM (Suspension Control Module)	●	●	●	●	●
2017	Cascada	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Cascada	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2017	Cascada	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Cascada	TCM (Transmission Control Module)	●	●	●	●	●
2017	Combo-D	AHCM (Auxiliary Heater Control Module)	●	●	●	●	●
2017	Combo-D	BCM (Body Control Module)	●	●	●	●	●
2017	Combo-D	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Combo-D	ECM (Engine Control Module)	●	●	●	●	●
2017	Combo-D	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Combo-D	IC (Instrument Cluster)	●	●	●	●	●
2017	Combo-D	MPIM (Multimedia Player Interface Module)	●	●	●	●	●
2017	Combo-D	PACM (Parking Assist Control Module)	●	●	●	●	※
2017	Combo-D	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●

2017	Combo-D	TCM (Transmission Control Module)	●	●	●	●	●
2017	Combo-D	TPIM (Tire Pressure Indicator Module)	●	●	●	●	※
2017	Corsa-E	BCM (Body Control Module)	●	●	●	●	●
2017	Corsa-E	CCM (Chassis Control Module)	●	●	●	●	●
2017	Corsa-E	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Corsa-E	ECM (Engine Control Module)	●	●	●	●	●
2017	Corsa-E	FCM (Frontview Camera Module)	●	●	●	●	●
2017	Corsa-E	FICM (Fuel Injector Control Module)	●	●	●	●	●
2017	Corsa-E	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Corsa-E	IC (Instrument Cluster)	●	●	●	●	●
2017	Corsa-E	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Corsa-E	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Corsa-E	RADIO (Radio)	●	●	●	●	●
2017	Corsa-E	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Corsa-E	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Corsa-E	TCM (Transmission Control Module)	●	●	●	●	●
2017	Corsa-E	TICM (Trailer Interface Control Module)	●	●	●	●	●
2017	Crossland-X	BCM (Body Control Module)	●	●	●	●	※
2017	Crossland-X	BSM (Battery Sensor Module)	●	●	●	●	※
2017	Crossland-X	DDSPCM (Driver Door Switch Panel Control Module)	●	●	●	●	●
2017	Crossland-X	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Crossland-X	ECM (Engine Control Module)	●	●	●	●	●
2017	Crossland-X	FBCP (Fuel-Borne Catalyst Pump)	●	●	●	●	※
2017	Crossland-X	FCM (Frontview Camera Module)	●	●	●	●	●
2017	Crossland-X	HC (HVAC Controls)	●	●	●	●	●
2017	Crossland-X	HCM (Headlamp Control Module)	●	●	●	●	●
2017	Crossland-X	HUDM (Head-Up Display Module)	●	●	●	●	●
2017	Crossland-X	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Crossland-X	IC (Instrument Cluster)	●	●	●	●	●
2017	Crossland-X	IDM (Info Display Module)	●	●	●	●	●
2017	Crossland-X	IFCM (Infotainment Faceplate Control Module)	●	●	●	※	※
2017	Crossland-X	LFSHCM (Left Front Seat Heating Control Module)	●	●	●	●	●
2017	Crossland-X	LSWCS (Left Steering Wheel Controls Switch)	●	●	●	●	●
2017	Crossland-X	MDP (Media Disc Player)	●	●	●	●	●
2017	Crossland-X	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Crossland-X	PSBI (Passenger Seat Belt Indicator)	●	※	※	●	●
2017	Crossland-X	PSCM (Power Steering Control Module)	●	●	●	●	●
2017	Crossland-X	PSCTDAM (Power Sounder Content Theft Deterrent Alarm Module)	●	●	●	●	●
2017	Crossland-X	PST (Power Supply Transformer)	●	●	●	※	※
2017	Crossland-X	RADIO (Radio)	●	●	●	●	●
2017	Crossland-X	RFSHCM (Right Front Seat Heating Control Module)	●	●	●	●	●
2017	Crossland-X	RLSM (Rain/Ambient Light Sensor Module)	●	●	●	●	※
2017	Crossland-X	SCCM (Steering Column Control Module)	●	●	●	●	●
2017	Crossland-X	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2017	Crossland-X	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2017	Crossland-X	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Crossland-X	TCM (Transmission Control Module)	●	●	●	●	※
2017	Crossland-X	TCS (Traction Control Switch)	●	※	※	●	※
2017	Crossland-X	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2017	Crossland-X	UIS (Ultrasonic Intrusion Sensor)	●	●	●	※	※
2017	Insignia	Amplifier	●	●	●	●	※
2017	Insignia	BCM (Body Control Module)	●	●	●	●	●
2017	Insignia	CCM (Chassis Control Module)	●	●	●	●	●
2017	Insignia	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2017	Insignia	EBCM (Electronic Brake Control Module)	●	●	●	●	●

2017	Insignia	ECM (Engine Control Module)	●	●	●	●	●
2017	Insignia	FCM (Frontview Camera Module)	●	●	●	●	●
2017	Insignia	FICM (Fuel Injector Control Module)	●	※	※	●	●
2017	Insignia	FSHVC (Front Seat Heating/Venting/Cooling)	●	●	●	●	●
2017	Insignia	HC (HVAC Controls)	●	●	●	●	●
2017	Insignia	HCM (Headlamp Control Module)	●	●	●	●	●
2017	Insignia	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2017	Insignia	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Insignia	IC (Instrument Cluster)	●	●	●	●	●
2017	Insignia	KECM (Keyless Entry Control Module)	●	●	●	●	●
2017	Insignia	LCM (Liftgate Control Module)	●	●	●	●	※
2017	Insignia	LSODI (Left Side Object Detection Indicator)	●	●	●	※	●
2017	Insignia	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Insignia	PBCM (Parking Brake Control Module)	●	●	●	●	●
2017	Insignia	PSCM (Power Steering Control Module)	●	●	●	●	●
2017	Insignia	RADIO (Radio)	●	●	●	●	●
2017	Insignia	RC (Radio Controls)	●	●	●	●	●
2017	Insignia	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2017	Insignia	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2017	Insignia	SCM (Suspension Control Module)	●	●	●	●	●
2017	Insignia	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Insignia	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2017	Insignia	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Insignia	TCM (Transmission Control Module)	●	●	●	●	●
2017	Insignia	TICM (Trailer Interface Control Module)	●	●	●	●	●
2017	Karl-Viva	BCM (Body Control Module)	●	●	●	●	●
2017	Karl-Viva	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Karl-Viva	ECM (Engine Control Module)	●	●	●	●	●
2017	Karl-Viva	FCM (Frontview Camera Module)	●	●	●	●	※
2017	Karl-Viva	FICM (Fuel Injector Control Module)	●	●	●	●	●
2017	Karl-Viva	HC (HVAC Controls)	●	●	●	●	●
2017	Karl-Viva	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Karl-Viva	IC (Instrument Cluster)	●	●	●	●	●
2017	Karl-Viva	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Karl-Viva	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Karl-Viva	RADIO (Radio)	●	●	●	●	●
2017	Karl-Viva	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2017	Karl-Viva	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Karl-Viva	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Karl-Viva	TCM (Transmission Control Module)	●	●	●	●	●
2017	Meriva-B	BCM (Body Control Module)	●	●	●	●	●
2017	Meriva-B	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2017	Meriva-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Meriva-B	ECM (Engine Control Module)	●	●	●	●	●
2017	Meriva-B	FICM (Fuel Injector Control Module)	●	※	※	●	●
2017	Meriva-B	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2017	Meriva-B	HCM (Headlamp Control Module)	●	●	●	●	●
2017	Meriva-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Meriva-B	IC (Instrument Cluster)	●	●	●	●	●
2017	Meriva-B	MTCM (Mobile Telephone Control Module)	●	●	●	●	●
2017	Meriva-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Meriva-B	PBCM (Parking Brake Control Module)	●	●	●	●	●
2017	Meriva-B	PSCM (Power Steering Control Module)	●	●	●	●	●
2017	Meriva-B	RADIO (Radio)	●	●	●	●	●

2017	Meriva-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Meriva-B	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2017	Meriva-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Meriva-B	TCM (Transmission Control Module)	●	●	●	●	●
2017	Meriva-B	TICM (Trailer Interface Control Module)	●	●	●	●	●
2017	Mokka	Amplifier	●	●	●	●	※
2017	Mokka	BCM (Body Control Module)	●	●	●	●	●
2017	Mokka	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Mokka	ECM (Engine Control Module)	●	●	●	●	●
2017	Mokka	FCM (Frontview Camera Module)	●	●	●	●	●
2017	Mokka	FICM (Fuel Injector Control Module)	●	※	※	●	●
2017	Mokka	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2017	Mokka	HCM (Headlamp Control Module)	●	●	●	●	●
2017	Mokka	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2017	Mokka	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Mokka	IC (Instrument Cluster)	●	●	●	●	●
2017	Mokka	KECM (Keyless Entry Control Module)	●	●	●	●	●
2017	Mokka	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Mokka	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Mokka	PST (Power Supply Transformer)	●	●	●	●	※
2017	Mokka	RADIO (Radio)	●	●	●	●	●
2017	Mokka	RC (Radio Controls)	●	●	●	●	●
2017	Mokka	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	※
2017	Mokka	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2017	Mokka	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2017	Mokka	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Mokka	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2017	Mokka	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Mokka	TCM (Transmission Control Module)	●	●	●	●	●
2017	Mokka	TICM (Trailer Interface Control Module)	●	●	●	●	●
2017	Movano-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2017	Movano-B	BCM (Body Control Module)	●	●	●	●	●
2017	Movano-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Movano-B	ECM (Engine Control Module)	●	●	●	●	●
2017	Movano-B	FCM (Frontview Camera Module)	●	●	●	●	※
2017	Movano-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Movano-B	IC (Instrument Cluster)	●	●	●	●	●
2017	Movano-B	IDM (Info Display Module)	●	●	●	●	●
2017	Movano-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※
2017	Movano-B	PACM (Parking Assist Control Module)	●	●	●	●	※
2017	Movano-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Movano-B	RADIO (Radio)	●	●	●	●	●
2017	Movano-B	RCM (Reductant Control Module)	●	●	●	●	●
2017	Movano-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2017	Movano-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2017	Movano-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2017	Movano-B	TCM (Transmission Control Module)	●	●	●	●	●
2017	Movano-B	TPIM (Tire Pressure Indicator Module)	●	●	●	●	※
2017	Vivaro-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2017	Vivaro-B	BCM (Body Control Module)	●	●	●	●	●
2017	Vivaro-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Vivaro-B	ECM (Engine Control Module)	●	●	●	●	●
2017	Vivaro-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●

2017	Vivaro-B	IC (Instrument Cluster)	●	●	●	●	●
2017	Vivaro-B	IDM (Info Display Module)	●	●	●	●	●
2017	Vivaro-B	KECM (Keyless Entry Control Module)	●	●	●	●	●
2017	Vivaro-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※
2017	Vivaro-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Vivaro-B	PHCM (Parking Heater Control Module)	●	●	●	●	●
2017	Vivaro-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Vivaro-B	RADIO (Radio)	●	●	●	●	●
2017	Vivaro-B	RCM (Reductant Control Module)	●	●	●	●	●
2017	Vivaro-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2017	Vivaro-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2017	Vivaro-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2017	Zafira-C	BCM (Body Control Module)	●	●	●	●	●
2017	Zafira-C	CCM (Chassis Control Module)	●	●	●	●	●
2017	Zafira-C	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2017	Zafira-C	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2017	Zafira-C	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2017	Zafira-C	ECM (Engine Control Module)	●	●	●	●	●
2017	Zafira-C	FCM (Frontview Camera Module)	●	●	●	●	●
2017	Zafira-C	FICM (Fuel Injector Control Module)	●	※	※	●	●
2017	Zafira-C	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2017	Zafira-C	HCM (Headlamp Control Module)	●	●	●	●	●
2017	Zafira-C	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2017	Zafira-C	IC (Instrument Cluster)	●	●	●	●	●
2017	Zafira-C	PACM (Parking Assist Control Module)	●	●	●	●	●
2017	Zafira-C	PBCM (Parking Brake Control Module)	●	●	●	●	●
2017	Zafira-C	PSCM (Power Steering Control Module)	●	●	●	●	※
2017	Zafira-C	RADIO (Radio)	●	●	●	●	●
2017	Zafira-C	SCM (Suspension Control Module)	●	●	●	●	●
2017	Zafira-C	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2017	Zafira-C	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2017	Zafira-C	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2017	Zafira-C	TCM (Transmission Control Module)	●	●	●	●	●
2017	Zafira-C	TICM (Trailer Interface Control Module)	●	●	●	●	●
2018	Adam	BCM (Body Control Module)	●	●	●	●	●
2018	Adam	CCM (Chassis Control Module)	●	●	●	●	●
2018	Adam	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Adam	ECM (Engine Control Module)	●	●	●	●	●
2018	Adam	FICM (Fuel Injector Control Module)	●	●	●	●	●
2018	Adam	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Adam	IC (Instrument Cluster)	●	●	●	●	●
2018	Adam	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Adam	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Adam	RADIO (Radio)	●	●	●	●	●
2018	Adam	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2018	Adam	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Adam	TCM (Transmission Control Module)	●	●	●	●	●
2018	Adam	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2018	Ampera-E	BBCM (Brake Booster Control Module)	●	●	●	●	※
2018	Ampera-E	BCM (Body Control Module)	●	●	●	●	●
2018	Ampera-E	BECM (Battery Energy Control Module)	●	※	※	●	※
2018	Ampera-E	CCM (Chassis Control Module)	●	●	●	●	●
2018	Ampera-E	EACCM (Electric A/C Compressor Control Module)	●	※	※	※	※
2018	Ampera-E	EBCM (Electronic Brake Control Module)	●	●	●	●	●

2018	Ampera-E	ECM (Engine Control Module)	●	●	●	●	●
2018	Ampera-E	FCM (Frontview Camera Module)	●	●	●	●	●
2018	Ampera-E	HPCM (Hybrid/EV Powertrain Control Module 1)	●	●	●	●	●
2018	Ampera-E	HPCM (Hybrid/EV Powertrain Control Module 2)	●	●	●	●	●
2018	Ampera-E	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Ampera-E	IC (Instrument Cluster)	●	●	●	●	●
2018	Ampera-E	KECM (Keyless Entry Control Module)	●	●	●	●	●
2018	Ampera-E	LSOSM (Left Side Object Sensor Module)	●	●	●	※	●
2018	Ampera-E	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Ampera-E	PASCM (Pedestrian Alert Sound Control Module)	●	●	●	●	●
2018	Ampera-E	PLCM (Power Line Communication Module)	●	※	※	●	※
2018	Ampera-E	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Ampera-E	RADIO (Radio)	●	●	●	●	●
2018	Ampera-E	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2018	Ampera-E	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2018	Ampera-E	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2018	Ampera-E	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Ampera-E	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2018	Ampera-E	TRCM (Transmission Range Control Module)	●	●	●	●	※
2018	Ampera-E	VPCM (Video Processing Control Module)	●	●	●	●	●
2018	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2018	Astra-J	CCM (Chassis Control Module)	●	●	●	●	●
2018	Astra-J	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2018	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2018	Astra-J	FCM (Frontview Camera Module)	●	●	●	●	●
2018	Astra-J	FICM (Fuel Injector Control Module)	●	※	※	●	●
2018	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2018	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2018	Astra-J	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2018	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2018	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2018	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Astra-J	RADIO (Radio)	●	●	●	●	●
2018	Astra-J	SCM (Suspension Control Module)	●	●	●	●	●
2018	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2018	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2018	Astra-J	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●
2018	Astra-J	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2018	Astra-K	ASCM (Active Safety Control Module)	●	●	●	●	●
2018	Astra-K	BCM (Body Control Module)	●	●	●	●	●
2018	Astra-K	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Astra-K	ECM (Engine Control Module)	●	●	●	●	●
2018	Astra-K	FCM (Frontview Camera Module)	●	●	●	●	※
2018	Astra-K	FICM (Fuel Injector Control Module)	●	●	●	●	●
2018	Astra-K	HC (HVAC Controls)	●	●	●	※	※
2018	Astra-K	HCM (Headlamp Control Module)	●	●	●	●	●
2018	Astra-K	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2018	Astra-K	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Astra-K	IC (Instrument Cluster)	●	●	●	●	●
2018	Astra-K	KECM (Keyless Entry Control Module)	●	●	●	●	●
2018	Astra-K	LCM (Liftgate Control Module)	●	●	●	●	※

2018	Astra-K	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	※
2018	Astra-K	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2018	Astra-K	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Astra-K	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Astra-K	PST (Power Supply Transformer)	●	●	●	●	※
2018	Astra-K	RADIO (Radio)	●	●	●	●	●
2018	Astra-K	RC (Radio Controls)	●	●	●	※	※
2018	Astra-K	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2018	Astra-K	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2018	Astra-K	SMCM (Seat Memory Control Module)	●	●	●	●	●
2018	Astra-K	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2018	Astra-K	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Astra-K	TCM (Transmission Control Module)	●	●	●	●	●
2018	Astra-K	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2018	Cascada	BCM (Body Control Module)	●	●	●	●	●
2018	Cascada	CCM (Chassis Control Module)	●	●	●	●	●
2018	Cascada	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2018	Cascada	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Cascada	ECM (Engine Control Module)	●	●	●	●	●
2018	Cascada	FCM (Frontview Camera Module)	●	●	●	●	●
2018	Cascada	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2018	Cascada	FTC (Folding Top Control)	●	●	●	●	●
2018	Cascada	HCM (Headlamp Control Module)	●	●	●	●	●
2018	Cascada	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Cascada	IC (Instrument Cluster)	●	●	●	●	●
2018	Cascada	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2018	Cascada	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Cascada	PBCM (Parking Brake Control Module)	●	●	●	●	●
2018	Cascada	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Cascada	RADIO (Radio)	●	●	●	●	●
2018	Cascada	SCM (Suspension Control Module)	●	●	●	●	●
2018	Cascada	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2018	Cascada	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2018	Cascada	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Cascada	TCM (Transmission Control Module)	●	●	●	●	●
2018	Combo-D	AHCM (Auxiliary Heater Control Module)	●	●	●	●	●
2018	Combo-D	BCM (Body Control Module)	●	●	●	●	●
2018	Combo-D	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Combo-D	ECM (Engine Control Module)	●	●	●	●	●
2018	Combo-D	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Combo-D	IC (Instrument Cluster)	●	●	●	●	●
2018	Combo-D	MPIM (Multimedia Player Interface Module)	●	●	●	●	●
2018	Combo-D	PACM (Parking Assist Control Module)	●	●	●	●	※
2018	Combo-D	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2018	Combo-D	TCM (Transmission Control Module)	●	●	●	●	●
2018	Combo-D	TPIM (Tire Pressure Indicator Module)	●	●	●	●	※
2018	Corsa-E	BCM (Body Control Module)	●	●	●	●	●
2018	Corsa-E	CCM (Chassis Control Module)	●	●	●	●	●
2018	Corsa-E	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Corsa-E	ECM (Engine Control Module)	●	●	●	●	●
2018	Corsa-E	FCM (Frontview Camera Module)	●	●	●	●	●
2018	Corsa-E	FICM (Fuel Injector Control Module)	●	●	●	●	●
2018	Corsa-E	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Corsa-E	IC (Instrument Cluster)	●	●	●	●	●

2018	Corsa-E	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Corsa-E	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Corsa-E	RADIO (Radio)	●	●	●	●	●
2018	Corsa-E	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2018	Corsa-E	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Corsa-E	TCM (Transmission Control Module)	●	●	●	●	●
2018	Corsa-E	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2018	Crossland-X	BCM (Body Control Module)	●	●	●	●	※
2018	Crossland-X	BSM (Battery Sensor Module)	●	●	●	●	※
2018	Crossland-X	DDSPCM (Driver Door Switch Panel Control Module)	●	●	●	●	●
2018	Crossland-X	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Crossland-X	ECM (Engine Control Module)	●	●	●	●	●
2018	Crossland-X	FBCP (Fuel-Borne Catalyst Pump)	●	●	●	●	※
2018	Crossland-X	FCM (Frontview Camera Module)	●	●	●	●	●
2018	Crossland-X	FICM (Fuel Injector Control Module)	●	●	●	※	※
2018	Crossland-X	HC (HVAC Controls)	●	●	●	●	●
2018	Crossland-X	HCM (Headlamp Control Module)	●	●	●	●	●
2018	Crossland-X	HUDM (Head-Up Display Module)	●	●	●	●	●
2018	Crossland-X	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Crossland-X	IC (Instrument Cluster)	●	●	●	●	●
2018	Crossland-X	IDM (Info Display Module)	●	●	●	●	●
2018	Crossland-X	IFCM (Infotainment Faceplate Control Module)	●	●	●	※	※
2018	Crossland-X	LFSHCM (Left Front Seat Heating Control Module)	●	●	●	●	●
2018	Crossland-X	LSWCS (Left Steering Wheel Controls Switch)	●	●	●	●	●
2018	Crossland-X	MDP (Media Disc Player)	●	●	●	●	●
2018	Crossland-X	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Crossland-X	PSBI (Passenger Seat Belt Indicator)	●	※	※	●	●
2018	Crossland-X	PSCM (Power Steering Control Module)	●	●	●	●	●
2018	Crossland-X	PSCTDAM (Power Sounder Content Theft Deterrent Alarm Module)	●	●	●	●	●
2018	Crossland-X	PST (Power Supply Transformer)	●	●	●	※	※
2018	Crossland-X	RADIO (Radio)	●	●	●	●	●
2018	Crossland-X	RFSHCM (Right Front Seat Heating Control Module)	●	●	●	●	●
2018	Crossland-X	RLSM (Rain/Ambient Light Sensor Module)	●	●	●	●	※
2018	Crossland-X	SCCM (Steering Column Control Module)	●	●	●	●	●
2018	Crossland-X	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2018	Crossland-X	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2018	Crossland-X	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Crossland-X	TCM (Transmission Control Module)	●	●	●	●	※
2018	Crossland-X	TCS (Traction Control Switch)	●	※	※	●	※
2018	Crossland-X	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2018	Crossland-X	UIS (Ultrasonic Intrusion Sensor)	●	●	●	※	※
2018	Grandland-X	AA (Audio Amplifier)	●	●	●	※	●
2018	Grandland-X	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2018	Grandland-X	BCM (Body Control Module)	●	●	●	●	※
2018	Grandland-X	BSM (Battery Sensor Module)	●	●	●	●	※
2018	Grandland-X	BVSCM (Battery Voltage Switching Control Module)	●	●	●	●	※
2018	Grandland-X	DDSPCM (Driver Door Switch Panel Control Module)	●	●	●	●	●
2018	Grandland-X	DSCM (Driver Seat Control Module)	●	●	●	●	●
2018	Grandland-X	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Grandland-X	ECM (Engine Control Module)	●	●	●	●	●
2018	Grandland-X	FBCP (Fuel-Borne Catalyst Pump)	●	●	●	●	※
2018	Grandland-X	FC-W (Frontview Camera - Windshield)	●	●	●	●	●
2018	Grandland-X	HC (HVAC Controls)	●	●	●	●	●
2018	Grandland-X	HCM (Headlamp Control Module)	●	●	●	●	●
2018	Grandland-X	HLSCM (Hands-Free Liftgate Sensor Control Module)	●	●	●	※	※

2018	Grandland-X	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Grandland-X	IC (Instrument Cluster)	●	●	●	●	●
2018	Grandland-X	IDM (Info Display Module)	●	●	●	●	●
2018	Grandland-X	IFCM (Infotainment Faceplate Control Module)	●	●	●	※	※
2018	Grandland-X	LCM (Liftgate Control Module)	●	●	●	●	●
2018	Grandland-X	LFSHCM (Left Front Seat Heating Control Module)	●	●	●	●	●
2018	Grandland-X	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	●
2018	Grandland-X	LSWCS (Left Steering Wheel Controls Switch)	●	●	●	●	●
2018	Grandland-X	LWMM (Left Windshield Wiper Motor Module)	●	●	●	●	●
2018	Grandland-X	MDP (Media Disc Player)	●	●	●	●	●
2018	Grandland-X	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Grandland-X	PSBI (Passenger Seat Belt Indicator)	●	※	※	●	●
2018	Grandland-X	PSCM (Power Steering Control Module)	●	●	●	●	●
2018	Grandland-X	PSCTDAM (Power Sounder Content Theft Deterrent Alarm Module)	●	●	●	●	●
2018	Grandland-X	PST (Power Supply Transformer)	●	●	●	※	※
2018	Grandland-X	RADIO (Radio)	●	●	●	●	●
2018	Grandland-X	RFSHCM (Right Front Seat Heating Control Module)	●	●	●	●	●
2018	Grandland-X	RLSM (Rain/Ambient Light Sensor Module)	●	●	●	●	※
2018	Grandland-X	SCCM (Steering Column Control Module)	●	●	●	●	●
2018	Grandland-X	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2018	Grandland-X	SLSCM-D (Seat Lumbar Support Control Module - Driver)	●	●	●	●	●
2018	Grandland-X	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2018	Grandland-X	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2018	Grandland-X	TCM (Transmission Control Module)	●	●	●	●	※
2018	Grandland-X	TCS (Traction Control Switch)	●	※	※	●	●
2018	Grandland-X	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2018	Grandland-X	UIS (Ultrasonic Intrusion Sensor)	●	●	●	※	※
2018	Grandland-X	VPCM (Video Processing Control Module)	●	●	●	●	●
2018	Insignia-B	AA (Audio Amplifier)	●	●	●	●	※
2018	Insignia-B	ASCM (Active Safety Control Module)	●	●	●	●	●
2018	Insignia-B	BCM (Body Control Module)	●	●	●	●	●
2018	Insignia-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Insignia-B	ECM (Engine Control Module)	●	●	●	●	●
2018	Insignia-B	FCM (Frontview Camera Module)	●	●	●	●	●
2018	Insignia-B	HC (HVAC Controls)	●	●	●	※	※
2018	Insignia-B	HCM (Headlamp Control Module)	●	●	●	●	●
2018	Insignia-B	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2018	Insignia-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Insignia-B	IC (Instrument Cluster)	●	●	●	●	●
2018	Insignia-B	KECM (Keyless Entry Control Module)	●	●	●	●	●
2018	Insignia-B	LCM (Liftgate Control Module)	●	●	●	●	※
2018	Insignia-B	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	※
2018	Insignia-B	LSOSM (Left Side Object Sensor Module)	●	●	●	※	●
2018	Insignia-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Insignia-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Insignia-B	PST (Power Supply Transformer)	●	●	●	●	※
2018	Insignia-B	RADIO (Radio)	●	●	●	●	●
2018	Insignia-B	RC (Radio Controls)	●	●	●	※	※
2018	Insignia-B	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2018	Insignia-B	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2018	Insignia-B	SCM (Suspension Control Module)	●	●	●	●	●
2018	Insignia-B	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2018	Insignia-B	SMCM-D (Seat Memory Control Module - Driver)	●	●	●	●	●
2018	Insignia-B	SMCM-P (Seat Memory Control Module - Passenger)	●	●	●	●	●
2018	Insignia-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●

2018	Insignia-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Insignia-B	TCM (Transmission Control Module)	●	●	●	●	●
2018	Insignia-B	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2018	Insignia-B	VPCM (Video Processing Control Module)	●	●	●	●	●
2018	Karl-Viva	BCM (Body Control Module)	●	●	●	●	●
2018	Karl-Viva	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Karl-Viva	ECM (Engine Control Module)	●	●	●	●	●
2018	Karl-Viva	FCM (Frontview Camera Module)	●	●	●	●	※
2018	Karl-Viva	FICM (Fuel Injector Control Module)	●	●	●	●	●
2018	Karl-Viva	HC (HVAC Controls)	●	●	●	※	※
2018	Karl-Viva	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Karl-Viva	IC (Instrument Cluster)	●	●	●	●	●
2018	Karl-Viva	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Karl-Viva	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Karl-Viva	RADIO (Radio)	●	●	●	●	●
2018	Karl-Viva	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2018	Karl-Viva	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2018	Karl-Viva	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Karl-Viva	TCM (Transmission Control Module)	●	●	●	●	●
2018	Mokka	Amplifier	●	●	●	●	※
2018	Mokka	BCM (Body Control Module)	●	●	●	●	●
2018	Mokka	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Mokka	ECM (Engine Control Module)	●	●	●	●	●
2018	Mokka	FCM (Frontview Camera Module)	●	●	●	●	●
2018	Mokka	FICM (Fuel Injector Control Module)	●	※	※	●	●
2018	Mokka	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2018	Mokka	HCM (Headlamp Control Module)	●	●	●	●	●
2018	Mokka	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2018	Mokka	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Mokka	IC (Instrument Cluster)	●	●	●	●	●
2018	Mokka	KECM (Keyless Entry Control Module)	●	●	●	●	●
2018	Mokka	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Mokka	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Mokka	PST (Power Supply Transformer)	●	●	●	●	※
2018	Mokka	RADIO (Radio)	●	●	●	●	●
2018	Mokka	RC (Radio Controls)	●	●	●	※	※
2018	Mokka	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	※
2018	Mokka	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2018	Mokka	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2018	Mokka	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2018	Mokka	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2018	Mokka	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Mokka	TCM (Transmission Control Module)	●	●	●	●	●
2018	Mokka	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2018	Movano-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2018	Movano-B	BCM (Body Control Module)	●	●	●	●	●
2018	Movano-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Movano-B	ECM (Engine Control Module)	●	●	●	●	●
2018	Movano-B	FCM (Frontview Camera Module)	●	●	●	●	※
2018	Movano-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Movano-B	IC (Instrument Cluster)	●	●	●	●	●
2018	Movano-B	IDM (Info Display Module)	●	●	●	●	●
2018	Movano-B	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	※
2018	Movano-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※

2018	Movano-B	PACM (Parking Assist Control Module)	●	●	●	●	※
2018	Movano-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Movano-B	RADIO (Radio)	●	●	●	●	●
2018	Movano-B	RCM (Reductant Control Module)	●	●	●	●	●
2018	Movano-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2018	Movano-B	SDGM-S (Serial Data Gateway Module - Secondary)	●	●	●	●	※
2018	Movano-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2018	Movano-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2018	Movano-B	TCM (Transmission Control Module)	●	●	●	●	●
2018	Movano-B	TPIM (Tire Pressure Indicator Module)	●	●	●	●	※
2018	Vivaro-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2018	Vivaro-B	BCM (Body Control Module)	●	●	●	●	●
2018	Vivaro-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Vivaro-B	ECM (Engine Control Module)	●	●	●	●	●
2018	Vivaro-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Vivaro-B	IC (Instrument Cluster)	●	●	●	●	●
2018	Vivaro-B	IDM (Info Display Module)	●	●	●	●	●
2018	Vivaro-B	KECM (Keyless Entry Control Module)	●	●	●	●	●
2018	Vivaro-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※
2018	Vivaro-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Vivaro-B	PHCM (Parking Heater Control Module)	●	●	●	●	●
2018	Vivaro-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Vivaro-B	RADIO (Radio)	●	●	●	●	●
2018	Vivaro-B	RCM (Reductant Control Module)	●	●	●	●	●
2018	Vivaro-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2018	Vivaro-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2018	Vivaro-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2018	Zafira-C	BCM (Body Control Module)	●	●	●	●	●
2018	Zafira-C	CCM (Chassis Control Module)	●	●	●	●	●
2018	Zafira-C	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2018	Zafira-C	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2018	Zafira-C	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2018	Zafira-C	ECM (Engine Control Module)	●	●	●	●	●
2018	Zafira-C	FCM (Frontview Camera Module)	●	●	●	●	●
2018	Zafira-C	FICM (Fuel Injector Control Module)	●	※	※	●	●
2018	Zafira-C	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2018	Zafira-C	HCM (Headlamp Control Module)	●	●	●	●	●
2018	Zafira-C	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2018	Zafira-C	IC (Instrument Cluster)	●	●	●	●	●
2018	Zafira-C	PACM (Parking Assist Control Module)	●	●	●	●	●
2018	Zafira-C	PBCM (Parking Brake Control Module)	●	●	●	●	●
2018	Zafira-C	PSCM (Power Steering Control Module)	●	●	●	●	※
2018	Zafira-C	RADIO (Radio)	●	●	●	●	●
2018	Zafira-C	SCM (Suspension Control Module)	●	●	●	●	●
2018	Zafira-C	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2018	Zafira-C	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2018	Zafira-C	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2018	Zafira-C	TCM (Transmission Control Module)	●	●	●	●	●
2018	Zafira-C	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2019	Adam	BCM (Body Control Module)	●	●	●	●	●
2019	Adam	CCM (Chassis Control Module)	●	●	●	●	●
2019	Adam	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Adam	ECM (Engine Control Module)	●	●	●	●	●
2019	Adam	FICM (Fuel Injector Control Module)	●	●	●	●	●

2019	Adam	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Adam	IC (Instrument Cluster)	●	●	●	●	●
2019	Adam	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Adam	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Adam	RADIO (Radio)	●	●	●	●	●
2019	Adam	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2019	Adam	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Ampera-E	BBCM (Brake Booster Control Module)	●	●	●	●	※
2019	Ampera-E	BCM (Body Control Module)	●	●	●	●	●
2019	Ampera-E	BECM (Battery Energy Control Module)	●	※	※	●	※
2019	Ampera-E	CCM (Chassis Control Module)	●	●	●	●	●
2019	Ampera-E	EACCM (Electric A/C Compressor Control Module)	●	※	※	※	※
2019	Ampera-E	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Ampera-E	ECM (Engine Control Module)	●	●	●	●	●
2019	Ampera-E	FCM (Frontview Camera Module)	●	●	●	●	●
2019	Ampera-E	HPCM (Hybrid/EV Powertrain Control Module 1)	●	●	●	●	●
2019	Ampera-E	HPCM (Hybrid/EV Powertrain Control Module 2)	●	●	●	●	●
2019	Ampera-E	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Ampera-E	IC (Instrument Cluster)	●	●	●	●	●
2019	Ampera-E	KECM (Keyless Entry Control Module)	●	●	●	●	●
2019	Ampera-E	LSOSM (Left Side Object Sensor Module)	●	●	●	※	●
2019	Ampera-E	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Ampera-E	PASCM (Pedestrian Alert Sound Control Module)	●	●	●	●	●
2019	Ampera-E	PLCM (Power Line Communication Module)	●	※	※	●	※
2019	Ampera-E	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Ampera-E	RADIO (Radio)	●	●	●	●	●
2019	Ampera-E	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2019	Ampera-E	SDGM-PA (Serial Data Gateway Module - Processor A)	●	●	●	※	※
2019	Ampera-E	SDGM-PB (Serial Data Gateway Module - Processor B)	●	●	●	※	※
2019	Ampera-E	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2019	Ampera-E	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Ampera-E	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2019	Ampera-E	TRCM (Transmission Range Control Module)	●	●	●	●	※
2019	Ampera-E	VPCM (Video Processing Control Module)	●	●	●	●	●
2019	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2019	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2019	Astra-J	FCM (Frontview Camera Module)	●	●	●	●	●
2019	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2019	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2019	Astra-J	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2019	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2019	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2019	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Astra-J	RADIO (Radio)	●	●	●	●	●
2019	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2019	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2019	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●
2019	Astra-K	ASCM (Active Safety Control Module)	●	●	●	●	●
2019	Astra-K	BCM (Body Control Module)	●	●	●	●	●
2019	Astra-K	EBCM (Electronic Brake Control Module)	●	●	●	●	●

2019	Astra-K	ECM (Engine Control Module)	●	●	●	●	●
2019	Astra-K	FCM (Frontview Camera Module)	●	●	●	●	※
2019	Astra-K	FICM (Fuel Injector Control Module)	●	●	●	●	●
2019	Astra-K	HC (HVAC Controls)	●	●	●	※	※
2019	Astra-K	HCM (Headlamp Control Module)	●	●	●	●	●
2019	Astra-K	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2019	Astra-K	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Astra-K	IC (Instrument Cluster)	●	●	●	●	●
2019	Astra-K	KECM (Keyless Entry Control Module)	●	●	●	●	●
2019	Astra-K	LCM (Liftgate Control Module)	●	●	●	●	※
2019	Astra-K	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	※
2019	Astra-K	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2019	Astra-K	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Astra-K	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Astra-K	PST (Power Supply Transformer)	●	●	●	●	※
2019	Astra-K	RADIO (Radio)	●	●	●	●	●
2019	Astra-K	RC (Radio Controls)	●	●	●	※	※
2019	Astra-K	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2019	Astra-K	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2019	Astra-K	SMCM (Seat Memory Control Module)	●	●	●	●	●
2019	Astra-K	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2019	Astra-K	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Astra-K	TCM (Transmission Control Module)	●	●	●	●	●
2019	Astra-K	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2019	Cascada	BCM (Body Control Module)	●	●	●	●	●
2019	Cascada	CCM (Chassis Control Module)	●	●	●	●	●
2019	Cascada	DRRCM (Digital Radio Receiver Control Module)	●	●	●	●	●
2019	Cascada	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Cascada	ECM (Engine Control Module)	●	●	●	●	●
2019	Cascada	FCM (Frontview Camera Module)	●	●	●	●	●
2019	Cascada	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2019	Cascada	FTC (Folding Top Control)	●	●	●	●	●
2019	Cascada	HCM (Headlamp Control Module)	●	●	●	●	●
2019	Cascada	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Cascada	IC (Instrument Cluster)	●	●	●	●	●
2019	Cascada	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2019	Cascada	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Cascada	PBCM (Parking Brake Control Module)	●	●	●	●	●
2019	Cascada	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Cascada	RADIO (Radio)	●	●	●	●	●
2019	Cascada	SCM (Suspension Control Module)	●	●	●	●	●
2019	Cascada	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2019	Cascada	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2019	Cascada	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Cascada	TCM (Transmission Control Module)	●	●	●	●	●
2019	Combo-E	BCM (Body Control Module)	●	●	●	●	※
2019	Combo-E	BSM (Battery Sensor Module)	●	●	●	●	※
2019	Combo-E	COICM (Cargo Overload Indication Control Module)	●	●	●	●	※
2019	Combo-E	DDSPCM (Driver Door Switch Panel Control Module)	●	●	●	●	●
2019	Combo-E	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Combo-E	ECM (Engine Control Module)	●	●	●	●	●
2019	Combo-E	FBCP (Fuel-Borne Catalyst Pump)	●	●	●	●	※
2019	Combo-E	FC-W (Frontview Camera - Windshield)	●	●	●	●	●
2019	Combo-E	HC (HVAC Controls)	●	●	●	●	●
2019	Combo-E	HUDEM (Head-Up Display Module)	●	●	●	●	●

2019	Combo-E	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Combo-E	IC (Instrument Cluster)	●	●	●	●	●
2019	Combo-E	IDM (Info Display Module)	●	●	●	●	●
2019	Combo-E	IFCM (Infotainment Faceplate Control Module)	●	●	●	※	※
2019	Combo-E	LSWCS (Left Steering Wheel Controls Switch)	●	●	●	●	●
2019	Combo-E	MDP (Media Disc Player)	●	●	●	●	●
2019	Combo-E	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Combo-E	PHCM (Parking Heater Control Module)	●	※	※	●	●
2019	Combo-E	PSBI (Passenger Seat Belt Indicator)	●	※	※	●	●
2019	Combo-E	PSCM (Power Steering Control Module)	●	●	●	●	●
2019	Combo-E	PSCTDAM (Power Sounder Content Theft Deterrent Alarm Module)	●	●	●	●	●
2019	Combo-E	PST (Power Supply Transformer)	●	●	●	※	※
2019	Combo-E	RADIO (Radio)	●	●	●	●	●
2019	Combo-E	RD (Rearview Display)	●	※	※	●	※
2019	Combo-E	RLSM (Rain/Ambient Light Sensor Module)	●	●	●	●	※
2019	Combo-E	SCCM (Steering Column Control Module)	●	●	●	●	●
2019	Combo-E	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2019	Combo-E	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2019	Combo-E	Special Vehicle Control Module	●	●	●	●	※
2019	Combo-E	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Combo-E	TCM (Transmission Control Module)	●	●	●	●	※
2019	Combo-E	TCS (Traction Control Switch)	●	※	※	●	●
2019	Combo-E	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2019	Combo-E	UIS (Ultrasonic Intrusion Sensor)	●	●	●	※	※
2019	Corsa-E	BCM (Body Control Module)	●	●	●	●	●
2019	Corsa-E	CCM (Chassis Control Module)	●	●	●	●	●
2019	Corsa-E	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Corsa-E	ECM (Engine Control Module)	●	●	●	●	●
2019	Corsa-E	FCM (Frontview Camera Module)	●	●	●	●	●
2019	Corsa-E	FICM (Fuel Injector Control Module)	●	●	●	●	●
2019	Corsa-E	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Corsa-E	IC (Instrument Cluster)	●	●	●	●	●
2019	Corsa-E	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Corsa-E	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Corsa-E	RADIO (Radio)	●	●	●	●	●
2019	Corsa-E	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2019	Corsa-E	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Corsa-E	TCM (Transmission Control Module)	●	●	●	●	●
2019	Corsa-E	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2019	Crossland-X	BCM (Body Control Module)	●	●	●	●	※
2019	Crossland-X	BSM (Battery Sensor Module)	●	●	●	●	※
2019	Crossland-X	DDSPCM (Driver Door Switch Panel Control Module)	●	●	●	●	●
2019	Crossland-X	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Crossland-X	ECM (Engine Control Module)	●	●	●	●	●
2019	Crossland-X	FBCP (Fuel-Borne Catalyst Pump)	●	●	●	●	※
2019	Crossland-X	FC-W (Frontview Camera - Windshield)	●	●	●	●	●
2019	Crossland-X	FICM (Fuel Injector Control Module)	●	●	●	※	※
2019	Crossland-X	HC (HVAC Controls)	●	●	●	●	●
2019	Crossland-X	HCM (Headlamp Control Module)	●	●	●	●	●
2019	Crossland-X	HUDM (Head-Up Display Module)	●	●	●	●	●
2019	Crossland-X	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Crossland-X	IC (Instrument Cluster)	●	●	●	●	●
2019	Crossland-X	IDM (Info Display Module)	●	●	●	●	●
2019	Crossland-X	IFCM (Infotainment Faceplate Control Module)	●	●	●	※	※

2019	Crossland-X	LFSHCM (Left Front Seat Heating Control Module)	●	●	●	●	●
2019	Crossland-X	LSWCS (Left Steering Wheel Controls Switch)	●	●	●	●	●
2019	Crossland-X	MDP (Media Disc Player)	●	●	●	●	●
2019	Crossland-X	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Crossland-X	PSBI (Passenger Seat Belt Indicator)	●	※	※	●	●
2019	Crossland-X	PSCM (Power Steering Control Module)	●	●	●	●	●
2019	Crossland-X	PSCTDAM (Power Sounder Content Theft Deterrent Alarm Module)	●	●	●	●	●
2019	Crossland-X	PST (Power Supply Transformer)	●	●	●	※	※
2019	Crossland-X	RADIO (Radio)	●	●	●	●	●
2019	Crossland-X	RFSHCM (Right Front Seat Heating Control Module)	●	●	●	●	●
2019	Crossland-X	RLSM (Rain/Ambient Light Sensor Module)	●	●	●	●	※
2019	Crossland-X	SCCM (Steering Column Control Module)	●	●	●	●	●
2019	Crossland-X	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2019	Crossland-X	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2019	Crossland-X	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Crossland-X	TCM (Transmission Control Module)	●	●	●	●	※
2019	Crossland-X	TCS (Traction Control Switch)	●	※	※	●	※
2019	Crossland-X	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2019	Crossland-X	UIS (Ultrasonic Intrusion Sensor)	●	●	●	※	※
2019	Grandland-X	AA (Audio Amplifier)	●	●	●	※	●
2019	Grandland-X	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2019	Grandland-X	BCM (Body Control Module)	●	●	●	●	※
2019	Grandland-X	BSM (Battery Sensor Module)	●	●	●	●	※
2019	Grandland-X	BVSCM (Battery Voltage Switching Control Module)	●	●	●	●	※
2019	Grandland-X	DDSPCM (Driver Door Switch Panel Control Module)	●	●	●	●	●
2019	Grandland-X	DSCM (Driver Seat Control Module)	●	●	●	●	●
2019	Grandland-X	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Grandland-X	ECM (Engine Control Module)	●	●	●	●	●
2019	Grandland-X	FBCP (Fuel-Borne Catalyst Pump)	●	●	●	●	※
2019	Grandland-X	FC-W (Frontview Camera - Windshield)	●	●	●	●	●
2019	Grandland-X	HC (HVAC Controls)	●	●	●	●	●
2019	Grandland-X	HCM (Headlamp Control Module)	●	●	●	●	●
2019	Grandland-X	HLSCM (Hands-Free Liftgate Sensor Control Module)	●	●	●	※	※
2019	Grandland-X	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Grandland-X	IC (Instrument Cluster)	●	●	●	●	●
2019	Grandland-X	IDM (Info Display Module)	●	●	●	●	●
2019	Grandland-X	IFCM (Infotainment Faceplate Control Module)	●	●	●	※	※
2019	Grandland-X	LCM (Liftgate Control Module)	●	●	●	●	●
2019	Grandland-X	LFSHCM (Left Front Seat Heating Control Module)	●	●	●	●	●
2019	Grandland-X	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	●
2019	Grandland-X	LSWCS (Left Steering Wheel Controls Switch)	●	●	●	●	●
2019	Grandland-X	LWMM (Left Windshield Wiper Motor Module)	●	●	●	●	●
2019	Grandland-X	MDP (Media Disc Player)	●	●	●	●	●
2019	Grandland-X	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Grandland-X	PSBI (Passenger Seat Belt Indicator)	●	※	※	●	●
2019	Grandland-X	PSCM (Power Steering Control Module)	●	●	●	●	●
2019	Grandland-X	PSCTDAM (Power Sounder Content Theft Deterrent Alarm Module)	●	●	●	●	●
2019	Grandland-X	PST (Power Supply Transformer)	●	●	●	※	※
2019	Grandland-X	RADIO (Radio)	●	●	●	●	●
2019	Grandland-X	RFSHCM (Right Front Seat Heating Control Module)	●	●	●	●	●
2019	Grandland-X	RLSM (Rain/Ambient Light Sensor Module)	●	●	●	●	※
2019	Grandland-X	SCCM (Steering Column Control Module)	●	●	●	●	●
2019	Grandland-X	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2019	Grandland-X	SLSCM-D (Seat Lumbar Support Control Module - Driver)	●	●	●	●	●

2019	Grandland-X	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2019	Grandland-X	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Grandland-X	TCM (Transmission Control Module)	●	●	●	●	※
2019	Grandland-X	TCS (Traction Control Switch)	●	※	※	●	●
2019	Grandland-X	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2019	Grandland-X	UIS (Ultrasonic Intrusion Sensor)	●	●	●	※	※
2019	Grandland-X	VPCM (Video Processing Control Module)	●	●	●	●	●
2019	Insignia-B	AA (Audio Amplifier)	●	●	●	●	※
2019	Insignia-B	ASCM (Active Safety Control Module)	●	●	●	●	●
2019	Insignia-B	BCM (Body Control Module)	●	●	●	●	●
2019	Insignia-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Insignia-B	ECM (Engine Control Module)	●	●	●	●	●
2019	Insignia-B	FCM (Frontview Camera Module)	●	●	●	●	●
2019	Insignia-B	HC (HVAC Controls)	●	●	●	※	※
2019	Insignia-B	HCM (Headlamp Control Module)	●	●	●	●	●
2019	Insignia-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Insignia-B	IC (Instrument Cluster)	●	●	●	●	●
2019	Insignia-B	KECM (Keyless Entry Control Module)	●	●	●	●	●
2019	Insignia-B	LCM (Liftgate Control Module)	●	●	●	●	※
2019	Insignia-B	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	※
2019	Insignia-B	LSOSM (Left Side Object Sensor Module)	●	●	●	※	●
2019	Insignia-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Insignia-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Insignia-B	PST (Power Supply Transformer)	●	●	●	●	※
2019	Insignia-B	RADIO (Radio)	●	●	●	●	●
2019	Insignia-B	RC (Radio Controls)	●	●	●	※	※
2019	Insignia-B	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2019	Insignia-B	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2019	Insignia-B	SCM (Suspension Control Module)	●	●	●	●	●
2019	Insignia-B	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2019	Insignia-B	SMCM-D (Seat Memory Control Module - Driver)	●	●	●	●	●
2019	Insignia-B	SMCM-P (Seat Memory Control Module - Passenger)	●	●	●	●	●
2019	Insignia-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2019	Insignia-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Insignia-B	TCM (Transmission Control Module)	●	●	●	●	●
2019	Insignia-B	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2019	Insignia-B	VPCM (Video Processing Control Module)	●	●	●	●	●
2019	Karl-Viva	BCM (Body Control Module)	●	●	●	●	●
2019	Karl-Viva	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Karl-Viva	ECM (Engine Control Module)	●	●	●	●	●
2019	Karl-Viva	FCM (Frontview Camera Module)	●	●	●	●	※
2019	Karl-Viva	HC (HVAC Controls)	●	●	●	※	※
2019	Karl-Viva	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Karl-Viva	IC (Instrument Cluster)	●	●	●	●	●
2019	Karl-Viva	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Karl-Viva	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Karl-Viva	RADIO (Radio)	●	●	●	●	●
2019	Karl-Viva	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2019	Karl-Viva	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2019	Karl-Viva	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Mokka	Amplifier	●	●	●	●	※
2019	Mokka	BCM (Body Control Module)	●	●	●	●	●
2019	Mokka	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Mokka	ECM (Engine Control Module)	●	●	●	●	●

2019	Mokka	FCM (Frontview Camera Module)	●	●	●	●	●
2019	Mokka	FICM (Fuel Injector Control Module)	●	※	※	●	●
2019	Mokka	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2019	Mokka	HCM (Headlamp Control Module)	●	●	●	●	●
2019	Mokka	HMICM (Human Machine Interface Control Module)	●	●	●	●	●
2019	Mokka	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Mokka	IC (Instrument Cluster)	●	●	●	●	●
2019	Mokka	KECM (Keyless Entry Control Module)	●	●	●	●	●
2019	Mokka	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Mokka	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Mokka	PST (Power Supply Transformer)	●	●	●	●	※
2019	Mokka	RADIO (Radio)	●	●	●	●	●
2019	Mokka	RC (Radio Controls)	●	●	●	※	※
2019	Mokka	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	※
2019	Mokka	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2019	Mokka	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2019	Mokka	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2019	Mokka	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2019	Mokka	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Mokka	TCM (Transmission Control Module)	●	●	●	●	●
2019	Mokka	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2019	Movano-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2019	Movano-B	BCM (Body Control Module)	●	●	●	●	●
2019	Movano-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Movano-B	ECM (Engine Control Module)	●	●	●	●	●
2019	Movano-B	FCM (Frontview Camera Module)	●	●	●	●	※
2019	Movano-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Movano-B	IC (Instrument Cluster)	●	●	●	●	●
2019	Movano-B	IDM (Info Display Module)	●	●	●	●	●
2019	Movano-B	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	※
2019	Movano-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※
2019	Movano-B	PACM (Parking Assist Control Module)	●	●	●	●	※
2019	Movano-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Movano-B	RADIO (Radio)	●	●	●	●	●
2019	Movano-B	RCM (Reductant Control Module)	●	●	●	●	●
2019	Movano-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2019	Movano-B	SDGM-S (Serial Data Gateway Module - Secondary)	●	●	●	●	※
2019	Movano-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2019	Movano-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2019	Movano-B	TCM (Transmission Control Module)	●	●	●	●	●
2019	Movano-B	TPIM (Tire Pressure Indicator Module)	●	●	●	●	※
2019	Vivaro-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2019	Vivaro-B	BCM (Body Control Module)	●	●	●	●	●
2019	Vivaro-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Vivaro-B	ECM (Engine Control Module)	●	●	●	●	●
2019	Vivaro-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Vivaro-B	IC (Instrument Cluster)	●	●	●	●	●
2019	Vivaro-B	IDM (Info Display Module)	●	●	●	●	●
2019	Vivaro-B	KECM (Keyless Entry Control Module)	●	●	●	●	●
2019	Vivaro-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※
2019	Vivaro-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Vivaro-B	PHCM (Parking Heater Control Module)	●	●	●	●	●
2019	Vivaro-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Vivaro-B	RADIO (Radio)	●	●	●	●	●
2019	Vivaro-B	RCM (Reductant Control Module)	●	●	●	●	●

2019	Vivaro-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2019	Vivaro-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2019	Vivaro-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2019	Zafira-C	BCM (Body Control Module)	●	●	●	●	●
2019	Zafira-C	CCM (Chassis Control Module)	●	●	●	●	●
2019	Zafira-C	DSCCM (Distance Sensing Cruise Control Module)	●	●	●	●	※
2019	Zafira-C	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2019	Zafira-C	ECM (Engine Control Module)	●	●	●	●	●
2019	Zafira-C	FCM (Frontview Camera Module)	●	●	●	●	●
2019	Zafira-C	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2019	Zafira-C	HCM (Headlamp Control Module)	●	●	●	●	●
2019	Zafira-C	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2019	Zafira-C	IC (Instrument Cluster)	●	●	●	●	●
2019	Zafira-C	PACM (Parking Assist Control Module)	●	●	●	●	●
2019	Zafira-C	PBCM (Parking Brake Control Module)	●	●	●	●	●
2019	Zafira-C	PSCM (Power Steering Control Module)	●	●	●	●	※
2019	Zafira-C	RADIO (Radio)	●	●	●	●	●
2019	Zafira-C	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2019	Zafira-C	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2019	Zafira-C	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2019	Zafira-C	TCM (Transmission Control Module)	●	●	●	●	●
2019	Zafira-C	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2020	Astra-J	BCM (Body Control Module)	●	●	●	●	●
2020	Astra-J	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2020	Astra-J	ECM (Engine Control Module)	●	●	●	●	●
2020	Astra-J	FCM (Frontview Camera Module)	●	●	●	●	●
2020	Astra-J	FSHCM (Front Seat Heating Control Module)	●	●	●	●	●
2020	Astra-J	HCM (Headlamp Control Module)	●	●	●	●	●
2020	Astra-J	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2020	Astra-J	IC (Instrument Cluster)	●	●	●	●	●
2020	Astra-J	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2020	Astra-J	PACM (Parking Assist Control Module)	●	●	●	●	●
2020	Astra-J	PBCM (Parking Brake Control Module)	●	●	●	●	●
2020	Astra-J	PSCM (Power Steering Control Module)	●	●	●	●	※
2020	Astra-J	RADIO (Radio)	●	●	●	●	●
2020	Astra-J	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2020	Astra-J	SWASM (Steering Wheel Angle Sensor Module)	●	●	●	※	※
2020	Astra-J	TCM (Transmission Control Module)	●	●	●	●	●
2020	Astra-K	AA (Audio Amplifier)	●	●	●	●	※
2020	Astra-K	ASCM (Active Safety Control Module)	●	●	●	●	●
2020	Astra-K	BCM (Body Control Module)	●	●	●	●	●
2020	Astra-K	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2020	Astra-K	ECM (Engine Control Module)	●	●	●	●	●
2020	Astra-K	FCM (Frontview Camera Module)	●	●	●	●	※
2020	Astra-K	HC (HVAC Controls)	●	●	●	※	※
2020	Astra-K	HCM (Headlamp Control Module)	●	●	●	●	●
2020	Astra-K	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2020	Astra-K	IC (Instrument Cluster)	●	●	●	●	●
2020	Astra-K	KECM (Keyless Entry Control Module)	●	●	●	●	●
2020	Astra-K	LCM (Liftgate Control Module)	●	●	●	●	※
2020	Astra-K	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	※
2020	Astra-K	MASM (Multi-Axis Acceleration Sensor Module)	●	●	●	※	※
2020	Astra-K	PACM (Parking Assist Control Module)	●	●	●	●	●
2020	Astra-K	PSCM (Power Steering Control Module)	●	●	●	●	※

2020	Astra-K	PST (Power Supply Transformer)	●	●	●	●	※
2020	Astra-K	RADIO (Radio)	●	●	●	●	●
2020	Astra-K	RC (Radio Controls)	●	●	●	※	※
2020	Astra-K	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2020	Astra-K	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2020	Astra-K	SDGM-PA (Serial Data Gateway Module - Processor A)	●	●	●	※	※
2020	Astra-K	SDGM-PB (Serial Data Gateway Module - Processor B)	●	●	●	※	※
2020	Astra-K	SMCM (Seat Memory Control Module)	●	●	●	●	●
2020	Astra-K	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2020	Astra-K	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2020	Astra-K	TCM (Transmission Control Module)	●	●	●	●	●
2020	Astra-K	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2020	Combo-E	BCM (Body Control Module)	●	●	●	●	※
2020	Combo-E	BSM (Battery Sensor Module)	●	●	●	●	※
2020	Combo-E	COICM (Cargo Overload Indication Control Module)	●	●	●	●	※
2020	Combo-E	DDSPCM (Driver Door Switch Panel Control Module)	●	●	●	●	●
2020	Combo-E	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2020	Combo-E	ECM (Engine Control Module)	●	●	●	●	●
2020	Combo-E	FBCP (Fuel-Borne Catalyst Pump)	●	●	●	●	※
2020	Combo-E	FC-W (Frontview Camera - Windshield)	●	●	●	●	●
2020	Combo-E	HC (HVAC Controls)	●	●	●	●	●
2020	Combo-E	HUDM (Head-Up Display Module)	●	●	●	●	●
2020	Combo-E	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2020	Combo-E	IC (Instrument Cluster)	●	●	●	●	●
2020	Combo-E	IDM (Info Display Module)	●	●	●	●	●
2020	Combo-E	IFCM (Infotainment Faceplate Control Module)	●	●	●	※	※
2020	Combo-E	LSWCS (Left Steering Wheel Controls Switch)	●	●	●	●	●
2020	Combo-E	MDP (Media Disc Player)	●	●	●	●	●
2020	Combo-E	PACM (Parking Assist Control Module)	●	●	●	●	●
2020	Combo-E	PHCM (Parking Heater Control Module)	●	※	※	●	●
2020	Combo-E	PSBI (Passenger Seat Belt Indicator)	●	※	※	●	●
2020	Combo-E	PSCM (Power Steering Control Module)	●	●	●	●	●
2020	Combo-E	PSCTDAM (Power Sounder Content Theft Deterrent Alarm Module)	●	●	●	●	●
2020	Combo-E	PST (Power Supply Transformer)	●	●	●	※	※
2020	Combo-E	RADIO (Radio)	●	●	●	●	●
2020	Combo-E	RD (Rearview Display)	●	※	※	●	※
2020	Combo-E	RLSM (Rain/Ambient Light Sensor Module)	●	●	●	●	※
2020	Combo-E	SCCM (Steering Column Control Module)	●	●	●	●	●
2020	Combo-E	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2020	Combo-E	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2020	Combo-E	Special Vehicle Control Module	●	●	●	●	※
2020	Combo-E	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2020	Combo-E	TCM (Transmission Control Module)	●	●	●	●	※
2020	Combo-E	TCS (Traction Control Switch)	●	※	※	●	●
2020	Combo-E	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2020	Combo-E	UIS (Ultrasonic Intrusion Sensor)	●	●	●	※	※
2020	Crossland-X	BCM (Body Control Module)	●	●	●	●	※
2020	Crossland-X	BSM (Battery Sensor Module)	●	●	●	●	※
2020	Crossland-X	DDSPCM (Driver Door Switch Panel Control Module)	●	●	●	●	●
2020	Crossland-X	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2020	Crossland-X	ECM (Engine Control Module)	●	●	●	●	●
2020	Crossland-X	FBCP (Fuel-Borne Catalyst Pump)	●	●	●	●	※
2020	Crossland-X	FC-W (Frontview Camera - Windshield)	●	●	●	●	●
2020	Crossland-X	HC (HVAC Controls)	●	●	●	●	●

2020	Crossland-X	HCM (Headlamp Control Module)	●	●	●	●	●
2020	Crossland-X	HUDD (Head-Up Display Module)	●	●	●	●	●
2020	Crossland-X	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2020	Crossland-X	IC (Instrument Cluster)	●	●	●	●	●
2020	Crossland-X	IDM (Info Display Module)	●	●	●	●	●
2020	Crossland-X	IFCM (Infotainment Faceplate Control Module)	●	●	●	※	※
2020	Crossland-X	LFSHCM (Left Front Seat Heating Control Module)	●	●	●	●	●
2020	Crossland-X	LSWCS (Left Steering Wheel Controls Switch)	●	●	●	●	●
2020	Crossland-X	MDP (Media Disc Player)	●	●	●	●	●
2020	Crossland-X	PACM (Parking Assist Control Module)	●	●	●	●	●
2020	Crossland-X	PSBI (Passenger Seat Belt Indicator)	●	※	※	●	●
2020	Crossland-X	PSCM (Power Steering Control Module)	●	●	●	●	●
2020	Crossland-X	PSCTDAM (Power Sounder Content Theft Deterrent Alarm Module)	●	●	●	●	●
2020	Crossland-X	PST (Power Supply Transformer)	●	●	●	※	※
2020	Crossland-X	RADIO (Radio)	●	●	●	●	●
2020	Crossland-X	RFSHCM (Right Front Seat Heating Control Module)	●	●	●	●	●
2020	Crossland-X	RLSM (Rain/Ambient Light Sensor Module)	●	●	●	●	※
2020	Crossland-X	SCCM (Steering Column Control Module)	●	●	●	●	●
2020	Crossland-X	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2020	Crossland-X	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2020	Crossland-X	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2020	Crossland-X	TCM (Transmission Control Module)	●	●	●	●	※
2020	Crossland-X	TCS (Traction Control Switch)	●	※	※	●	※
2020	Crossland-X	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2020	Crossland-X	UIS (Ultrasonic Intrusion Sensor)	●	●	●	※	※
2020	Grandland-X	12V BIM1 (12V Battery Isolator Module 1)	●	●	●	●	※
2020	Grandland-X	A/C-C (A/C Compressor)	●	●	●	●	※
2020	Grandland-X	AA (Audio Amplifier)	●	●	●	※	●
2020	Grandland-X	BCM (Body Control Module)	●	●	●	●	※
2020	Grandland-X	BECM (Battery Energy Control Module)	●	●	●	●	※
2020	Grandland-X	BSM (Battery Sensor Module)	●	●	●	●	※
2020	Grandland-X	BVSCM (Battery Voltage Switching Control Module)	●	●	●	●	※
2020	Grandland-X	CH (Coolant Heater)	●	●	●	●	●
2020	Grandland-X	DDSPCM (Driver Door Switch Panel Control Module)	●	●	●	●	●
2020	Grandland-X	DM1CM (Drive Motor 1 Control Module)	●	●	●	●	※
2020	Grandland-X	DM2CM (Drive Motor 2 Control Module)	●	●	●	●	※
2020	Grandland-X	DSCM (Driver Seat Control Module)	●	●	●	●	●
2020	Grandland-X	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2020	Grandland-X	ECM (Engine Control Module)	●	●	●	●	●
2020	Grandland-X	FBCP (Fuel-Borne Catalyst Pump)	●	●	●	●	※
2020	Grandland-X	FC-W (Frontview Camera - Windshield)	●	●	●	●	●
2020	Grandland-X	H/EV-PCM (Hybrid/EV Powertrain Control Module)	●	●	●	●	※
2020	Grandland-X	HC (HVAC Controls)	●	●	●	●	●
2020	Grandland-X	HCM (Headlamp Control Module)	●	●	●	●	●
2020	Grandland-X	HLSCM (Hands-Free Liftgate Sensor Control Module)	●	●	●	※	※
2020	Grandland-X	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2020	Grandland-X	IC (Instrument Cluster)	●	●	●	●	●
2020	Grandland-X	IDM (Info Display Module)	●	●	●	●	●
2020	Grandland-X	IFCM (Infotainment Faceplate Control Module)	●	●	●	※	※
2020	Grandland-X	LCM (Liftgate Control Module)	●	●	●	●	●
2020	Grandland-X	LFSHCM (Left Front Seat Heating Control Module)	●	●	●	●	●
2020	Grandland-X	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	●
2020	Grandland-X	LSWCS (Left Steering Wheel Controls Switch)	●	●	●	●	●
2020	Grandland-X	LWMM (Left Windshield Wiper Motor Module)	●	●	●	●	●
2020	Grandland-X	MDP (Media Disc Player)	●	●	●	●	●

2020	Grandland-X	PACM (Parking Assist Control Module)	●	●	●	●	●
2020	Grandland-X	PSBI (Passenger Seat Belt Indicator)	●	※	※	●	●
2020	Grandland-X	PSCM (Power Steering Control Module)	●	●	●	●	●
2020	Grandland-X	PSCTDAM (Power Sounder Content Theft Deterrent Alarm Module)	●	●	●	●	●
2020	Grandland-X	PST (Power Supply Transformer)	●	●	●	※	※
2020	Grandland-X	RADIO (Radio)	●	●	●	●	●
2020	Grandland-X	RFSHCM (Right Front Seat Heating Control Module)	●	●	●	●	●
2020	Grandland-X	RLSM (Rain/Ambient Light Sensor Module)	●	●	●	●	※
2020	Grandland-X	SCCM (Steering Column Control Module)	●	●	●	●	●
2020	Grandland-X	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2020	Grandland-X	SLSCM-D (Seat Lumbar Support Control Module - Driver)	●	●	●	●	●
2020	Grandland-X	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2020	Grandland-X	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	●
2020	Grandland-X	TCM (Transmission Control Module)	●	●	●	●	※
2020	Grandland-X	TCS (Traction Control Switch)	●	※	※	●	●
2020	Grandland-X	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2020	Grandland-X	UIS (Ultrasonic Intrusion Sensor)	●	●	●	※	※
2020	Grandland-X	VPCM (Video Processing Control Module)	●	●	●	●	●
2020	Insignia-B	AA (Audio Amplifier)	●	●	●	●	※
2020	Insignia-B	ASCM (Active Safety Control Module)	●	●	●	●	●
2020	Insignia-B	BCM (Body Control Module)	●	●	●	●	●
2020	Insignia-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2020	Insignia-B	ECM (Engine Control Module)	●	●	●	●	●
2020	Insignia-B	FCM (Frontview Camera Module)	●	●	●	●	●
2020	Insignia-B	HC (HVAC Controls)	●	●	●	※	※
2020	Insignia-B	HCM (Headlamp Control Module)	●	●	●	●	●
2020	Insignia-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●
2020	Insignia-B	IC (Instrument Cluster)	●	●	●	●	●
2020	Insignia-B	KECM (Keyless Entry Control Module)	●	●	●	●	●
2020	Insignia-B	LCM (Liftgate Control Module)	●	●	●	●	※
2020	Insignia-B	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	※
2020	Insignia-B	LSOSM (Left Side Object Sensor Module)	●	●	●	※	●
2020	Insignia-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2020	Insignia-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2020	Insignia-B	PST (Power Supply Transformer)	●	●	●	●	※
2020	Insignia-B	RADIO (Radio)	●	●	●	●	●
2020	Insignia-B	RC (Radio Controls)	●	●	●	※	※
2020	Insignia-B	RDCCM (Rear Differential Clutch Control Module)	●	●	●	●	●
2020	Insignia-B	SCLCM (Steering Column Lock Control Module)	●	●	●	●	※
2020	Insignia-B	SCM (Suspension Control Module)	●	●	●	●	●
2020	Insignia-B	SDGM (Serial Data Gateway Module)	●	●	●	※	※
2020	Insignia-B	SMCM-D (Seat Memory Control Module - Driver)	●	●	●	●	●
2020	Insignia-B	SMCM-P (Seat Memory Control Module - Passenger)	●	●	●	●	●
2020	Insignia-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	●
2020	Insignia-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2020	Insignia-B	TCM (Transmission Control Module)	●	●	●	●	●
2020	Insignia-B	TLCM (Trailer Lighting Control Module)	●	●	●	●	●
2020	Insignia-B	VPCM (Video Processing Control Module)	●	●	●	●	●
2020	Movano-B	ABCM (Auxiliary Body Control Module)	●	●	●	●	●
2020	Movano-B	BCM (Body Control Module)	●	●	●	●	●
2020	Movano-B	EBCM (Electronic Brake Control Module)	●	●	●	●	●
2020	Movano-B	ECM (Engine Control Module)	●	●	●	●	●
2020	Movano-B	FCM (Frontview Camera Module)	●	●	●	●	※
2020	Movano-B	HVAC (Heating Ventilation Air-conditioning and Cooling)	●	●	●	●	●

2020	Movano-B	IC (Instrument Cluster)	●	●	●	●	●
2020	Movano-B	LRRSM (Long Range Radar Sensor Module)	●	●	●	●	※
2020	Movano-B	MACM (Multifunction Accessory Control Module)	●	●	●	●	※
2020	Movano-B	MDWCM (Mobile Device Wireless Charger Module)	●	●	●	●	※
2020	Movano-B	PACM (Parking Assist Control Module)	●	●	●	●	●
2020	Movano-B	PHCM (Parking Heater Control Module)	●	●	●	●	●
2020	Movano-B	PSCM (Power Steering Control Module)	●	●	●	●	※
2020	Movano-B	RADIO (Radio)	●	●	●	●	●
2020	Movano-B	RCM (Reductant Control Module)	●	●	●	●	●
2020	Movano-B	SDGM (Serial Data Gateway Module)	●	●	●	●	●
2020	Movano-B	SDGM-S (Serial Data Gateway Module - Secondary)	●	●	●	●	※
2020	Movano-B	SDGM3 (Serial Data Gateway Module 3)	●	●	●	●	※
2020	Movano-B	SOSCM (Side Object Sensing Control Module)	●	●	●	●	●
2020	Movano-B	SRS (Inflatable Restraint Sensing and Diagnostic Module)	●	●	●	●	※
2020	Movano-B	TCICM (Telematics Communication Interface Control Module)	●	●	●	●	※
2020	Movano-B	TCM (Transmission Control Module)	●	●	●	●	●

VAUXHALL DPF Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Year	Model	DPF
2004	Vectra-C-Signum	●
2005	Astra-H	●
2005	Vectra-C-Signum	●
2005	Zafira-B	●
2006	Astra-H	●
2006	Combo	●
2006	Corsa-C	●
2006	Meriva	●
2006	Vectra-C-Signum	●
2006	Zafira-B	●
2007	Antara-CaptivaShort-Body	●
2007	Astra-H	●
2007	CaptivaLong-Body	●
2007	Combo	●
2007	Corsa-C	●
2007	Corsa-D	●
2007	Meriva	●
2007	Vectra-C-Signum	●
2007	Zafira-B	●
2008	Agila-B	●
2008	Antara-CaptivaShort-Body	●
2008	Astra-H	●
2008	CaptivaLong-Body	●
2008	Corsa-C	●
2008	Corsa-D	●
2008	Meriva	●
2008	Vectra-C-Signum	●
2008	Zafira-B	●
2009	Agila-B	●
2009	Antara-CaptivaShort-Body	●
2009	Astra-H	●
2009	CaptivaLong-Body	●
2009	Corsa-C	●
2009	Corsa-D	●
2009	Insignia	●
2009	Meriva	●
2009	Zafira-B	●
2010	Agila-B	●
2010	Antara-CaptivaShort-Body	●
2010	Astra-H	●
2010	Astra-J	●
2010	CaptivaLong-Body	●
2010	Corsa-C	●
2010	Corsa-D	●
2010	Insignia	●
2010	Meriva	●
2010	Meriva-B	●
2010	Zafira-B	●
2011	Agila-B	●
2011	Antara-CaptivaShort-Body	●
2011	Astra-H	●
2011	Astra-J	●

2011	CaptivaLong-Body	●
2011	Corsa-C	●
2011	Corsa-D	●
2011	Insignia	●
2011	Meriva-B	●
2011	Zafira-B	●
2012	Agila-B	●
2012	Astra-H	●
2012	Astra-J	●
2012	Corsa-C	●
2012	Corsa-D	●
2012	Insignia	●
2012	Meriva-B	●
2012	Zafira-B	●
2012	Zafira-C	●
2013	Astra-H	●
2013	Astra-J	●
2013	Cascada	●
2013	Corsa-D	●
2013	Insignia	●
2013	Meriva-B	●
2013	Zafira-B	●
2013	Zafira-C	●
2014	Astra-H	●
2014	Astra-J	●
2014	Cascada	●
2014	Corsa-D	●
2014	Insignia	●
2014	Meriva-B	●
2014	Zafira-B	●
2014	Zafira-C	●
2015	Astra-J	●
2015	Cascada	●
2015	Insignia	●
2015	Meriva-B	●
2015	Movano-B	●
2015	Vivaro-B	●
2015	Zafira-C	●
2016	Astra-J	●
2016	Movano-B	●
2016	Vivaro-B	●
2016	Zafira-C	●
2017	Astra-J	●
2017	Astra-K	●
2017	Crossland-X	●
2017	Movano-B	●
2017	Vivaro-B	●
2018	Adam	●
2018	Astra-J	●
2018	Astra-K	●
2018	Cascada	●
2018	Corsa-E	●
2018	Crossland-X	●

2018	Grandland-X	●
2018	Movano-B	●
2018	Vivaro-B	●
2018	Zafira-C	●
2019	Adam	●
2019	Astra-K	●
2019	Cascada	●
2019	Corsa-E	●
2019	Grandland-X	●
2019	Insignia-B	●
2019	Movano-B	●
2019	Combo-E	●
2019	Vivaro-B	●
2019	Zafira-C	●
2020	Astra-K	●
2020	Grandland-X	●
2020	Insignia-B	●
2020	Movano-B	●
DPF Function List		
DPF Pressure Sensor Learn		
DPF Pressure Sensor Reset		
DPF Regeneration		
DPF Reset		
DPF Service Regeneration		
Particulate Filter Pressure Sensor Reset		
Particulate Filter Reset		
Regeneration Diesel Particulate Filter		
Replace Diesel Particulate Filter		
Replace Differential-Pressure Sensor		